



Kerberos Test Procedure Definition

Report bases on file: LxiConformanceTestSuite_1.6.json Report printed at: Mo Jul 17 2023



1.0 Overview

Categories General Device

1.4.1.2.5	LXI Clock Synchronization Conformance Requirements		
Category	LXI Clock Synchronization		
Test Type	Kerberos Test, automated		
Rule	LXI Clock Synchronization Conformance Requirements		
Explanation	The rules in this document define the conformance requirements for this Extended Function. In addition to the requirements for all LXI Devices found in the LXI Device Specification, there may be cases where an Extended Function requires conformance to another Extended Function. All requirements follow below:		
	LXI Device Specification Document: All LXI Devices shall conform to the rules found in Section 1.4 and all subsections All LXI Devices shall conform to the rules found in Section 1.4 and all subsections Section 6.1.1 and 6.5 including all subsections Section 9.6 including all subsections Function element with the FunctionName attributes of "LXI Clock Synchronization" and version "1.0" in the LXIExtended Function element of the LXI identification document as described in section 10.2.5. LXI Clock Synchronization (this document):		
	Include all rules		
Test Procedu	re Computed by other tests		
	This test is computed by the result of other tests.		
Dependencie	ES 1.4.6 LXI Clock Synchronization		
1.4.4.2.3	LXI Wired Trigger Bus Conformance Requirements		
Category	LXI Wired Trigger Bus		
Test Type	Kerberos Test, automated		
Rule	LXI Wired Trigger Bus Conformance Requirements		
Explanation	All LXI Devices shall conform to the rules found in Section 1.4 and all subsections, Sections 3.5 and 3.7, including all subsections, Section 6.1.1, sections 6.3, through 6.4.2 including all subsections, and 6.4.4 through 6.4.6, including all subsections, Section 9.6 including all subsections. A Function element with the FunctionName attributes of LXI Wired Trigger Bus and version 1.0 in the LXIExtendedFunction element of the LXI identification document as described by section 10.2.5, LXI Wired Trigger Bus Extended Function Include all rules		
Test Procedu	Ire NOT SUPPORTED		
	This test is currently not implemented. If the configuration would expect this test to run, then it will fail. Otherwise it will pass with message 'not supported'.		
1.4.4.2.6	LXI Timestamped Data Conformance Requirements		
Category	LXI Timestamped Data		
Test Type	Kerberos Test, automated		
Rule	LXI Timestamped Data Conformance Requirements		



Explanation	The rules in this document define the conformance requirements for this Extended Function. In addition to the requirements for all LXI Devices found in the LXI Device Specification, there may be cases where an Extended Function requires conformance to another Extended Function. All requirements follow below:		
	LXI Device Specification Document: All LXI Devices shall conform to the rules found in Section 1.4 and all subsections A Function element with the FunctionName attributes of "LXI Timestamped Data" and version "1.0" in the LXIExtendedFunction element of the LXI identification document as described by section 10.2.5. LXI Clock Synchronization Document: Include all rules LXI Timestamped Data (this document): Include all rules		
Test Procedure	Computed by other tests		
	This test is computed by the result of other tests.		
Dependencies	1.4.6 LXI Clock Synchronization LXI Timestamped Data		
1.4.4.2.7 LXI	Event Log Conformance Requirements		
Category	LXI Event Log		
Test Type	Kerberos Test, automated		
Rule	LXI Event Log Conformance Requirements		
Explanation	All LXI Devices shall conform to the rules found in Section 1.4 and all subsections, Section 3.7 including all subsections. A Function element with the FunctionName attributes of "LXI Event Log" and version "1.0" in the LXIExtendedFunction element of the LXI identification document as described by section 10.2.5. LXI Clock Synchronization Document If using non-zero time-stamped events, then include all rules. LXI Event Includes all rules		
Test Procedure	NOT SUPPORTED		
	This test is currently not implemented. If the configuration would expect this test to run, then it will fail. Otherwise it will pass with message 'not supported'.		
1.4.6 We	b Indication of Functional Declaration		
Category	Web Interface, Device Specification		
Test Type Kerberos Test, manual			
Rule	Web Indication of Functional Declaration		



Explanation	The Functional Declaration shall be declared on the web interface and is the definitive source for Functional Declaration information for an LXI Device. See section 9.2, RULE – Welcome Web Page Display Items for additional requirements regarding this page.		
	It shall include:		
	LXI Version:		
	1.6 LXI Device Specification 2022		
	LXI Extended Functions:		
	List of supported LXI Extended Functions using the extended function names as defined in each LXI Extended Function specification (example: LXI HiSLIP). The web page shall list all the LXI Extended Functions supported.		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
Test Procedure	Query Functional Declarations		
	Query tester for the functional declarations given on the Welcome Page.		
	Validate Functional Declaration		
	Match the Functional Declaration and Extended Function tags given by user against the test configuration.		
1.4.7 Ter	ms Using the LXI Trademark		
Category	Device Specification		
Test Type	Vendor Declaration		
Rule	Terms Using the LXI Trademark		
Explanation	The LXI Trademark or registered name, LXI, shall be used to describe the LXI Device and any LXI Extended Function		



2.0 LXI Physical Specification

Categories General Device

2.4.5.1	LCI Mechanism
Category	General Device, Device Specification
Test Type	Kerberos Test, manual
Rule	LCI Mechanism
Explanation	LXI Devices shall provide an LCI Mechanism that, when activated, places its network settings in a default state. The functions performed by this mechanism are defined in Section 8.13.
Test Proced	ure Query LCI Mechanism Query tester if an LCI mechanism is found on the device. This may be either a physical button or switch or a soft implementation in the the device's user interface.
2.4.5.2	LXI Devices Without a Front-Panel Manual Data-Entry Method
Category	General Device, Device Specification
Test Type	Kerberos Test, manual
Rule	LXI Devices Without a Front-Panel Manual Data-Entry Method
Explanation	LXI Devices shall provide an LCI mechanism by either:
	a) A separate recessed mechanical LCI mechanism on the rear or front of the device (rear is preferred).
	b) A soft LCI mechanism through a permanently attached user interface (e.g., a front panel, monitor, mouse, keyboard, et cetera) that does not use the LAN as the interface.
Test Proced	ure Query LCI Mechanism Without Front-Panel Query tester if the LCI Mechanism is available for devices without a front panel manual data entry method.
2.4.5.3	LCI Mechanism Protection
Category	General Device, Device Specification
Test Type	Kerberos Test, manual
Rule	LCI Mechanism Protection
Explanation	The LCI Mechanism shall be protected by a time-delay, user query, or mechanical protection feature designed to prevent inadvertent operation.
Test Proced	ure Query LCI Mechanism Protection Query tester if the LCI Mechanism is protected by a time-delay, user query or mechanical protection feature designed to prevent applying the LCI unintentionally.
2.4.9.1	IEEE 802.3
Category	General Device, Device Specification
Test Type	Kerberos Test, manual
Rule	IEEE 802.3
Explanation	Physical Ethernet connections shall be IEEE 802.3 compliant.



Test Procedure	Query Physical Ethernet connection		
	Query tester if the device has a RJ45 connector which accepts a standard LAN cable.		
2.5.1.1 Pow	ver Indicator		
Category	General Device, Device Specification		
Test Type	Kerberos Test, manual		
Rule	Power Indicator		
Explanation	A Power Indicator shall be provided on the front panel of the device.		
Test Procedure	Query Power Indicator		
	Query tester if the device has a power indicator on its front panel.		
2.5.2.1 LAN	l Status Indicator		
Category	General Device, Device Specification		
Test Type	Kerberos Test, manual		
Rule	LAN Status Indicator		
Explanation	A LAN Status Indicator shall be provided on the device front panel.		
Test Procedure	Query LAN Status Indicator		
	Query tester if the device has a LAN status indicator on the front panel. It may be on the user interface. A permission also allows it to be on the rear panel.		
2.6.1.1 From	nt Panel Labeling Requirements		
Category	General Device, Device Specification		
Test Type	Kerberos Test, manual		
Rule	Front Panel Labeling Requirements		
Explanation	There shall be an LXI Logo on the front of the device. The logo shall conform to the specifications in the document 'LXI Consortium Trademark, Patent and Licensing Policies.'		
Test Procedure	Query LXI logo		
	Query tester if the LXI logo is on the front panel. It may also be displayed		

as part of the power up display.



3.0 LXI Device Synchronization and Events

Categories	LXI Clock Synchronization LXI Event Messaging LXI Wired Trigger Bus		
3.2.1 Im	plementation of IEEE 1588 Precision Time Protocol		
Category	egory LXI Clock Synchronization		
Test Type	Kerberos Test, automated		
Rule Implementation of IEEE 1588 Precision Time Protocol			
Explanation	Each LXI Device that implements IEEE 1588 shall provide functionality fully conformant to the standard IEEE 1588 and the LXI 1588 Profile.		
Test Procedure	Computed by other tests		
	This test is computed by the result of other tests.		
Dependencies	3.2.1.0		
	3.2.1.1		
	3.2.1.2		
	3.2.1.3		
	3.2.1.4		
	3.2.1.5		
	3 2 1 7		
	3218		
	3.2.1.9		
	3.2.1.10		
	3.2.1.11		
	3.2.1.12		
	3.2.1.13		
	3.2.1.15		
	3.2.1.16		
	3.2.1.17		
3.2.1.0 Tar	get Address		
Category	LXI Clock Synchronization		
Test Type	Kerberos Test, automated		
Rule	Target Address		
Explanation	IEEE 1588 clocks in an LXI Device shall implement the IEEE 1588 management messages specified in clause 15.2 of IEEE 1588-2008. This test checks various target address settings.		
Pre Condition	Connect DUT		

Connect the DUT to the test network

Start management node

Start up the PTP management node



Test Procedure	Test management address settings		
		Test various management message address settings, where the DUT should or should not answer.	
		Target Clock Identity	
		Target Clock Port	
		Expect Response	
		DUT Identity	
		DUT Port	
		res DUT Identity	
		0xFFFF	
		Yes	
		ff.ff.ff.ff.ff.ff.ff.ff	
		DUT Port Ves	
		ff:ff:ff:ff:ff:ff:ff	
		0xFFFF	
		Yes	
		DUT Identity Random	
		No	
		ff:ff:ff:ff:ff:ff:ff:ff	
		Random	
		Νο	
		0xFFFF	
		No	
		Random	
		0xFFFF	
Dect Condition		NO ment rede	
Post Condition	Shutdown manage	Shutdown the PTP management node	
		Shataowi the Fit Hanagement node	
3.2.1.1 Mana	agement Messages		
Category	LXI Clock Synchror	nization	
Test Type	Kerberos Test, auto	Kerberos Test, automated	
Rule	Management Mess	sages	
Explanation	IEEE 1588 clocks in an LXI Device shall implement the IEEE 1588 management messages specified in clause 15.2 of IEEE 1588-2008. This test checks the GET/SET/CMD action for all		
	neccessary manage Management mess are NOT tested.	ement messages. sages associated with IEEE 1588-2008 optional clauses that are NOT required	
Pre Condition	Connect DUT		
		Connect the DUT to the test network	
	Start management	node	
	-	Start up the PTP management node	
Test Procedure	Test management	messages	
		Test the correct functionality of the management messages for their GET/ SET/CMD action.	



Post Condition	Shutdown management node		
	Shutdown the PTP management node		
3.2.1.2 Def	ault best master clock algorithm		
Category	LXI Clock Synchronization		
Test Type	Kerberos Test, automated		
Rule	Default best master clock algorithm		
Explanation	LXI Devices shall determine the master-slave hierarchy using the IEEE 1588 specified default best master clock algorithm, clauses 9.3.2, 9.3.3, and 9.3.4, of IEEE 1588-2008.		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		
	Start management node		
	Start up the PTP management node		
	Start ordinary clock		
	Start up the PTP clock		
	Initialize all clocks		
	Get Clock Quality from DUT		
	Get the Default Data Set by sending a DEFAULT DATA SET management		
	message to the DUT. Extract the Clock Quality from response.		
	Get Announce Interval from DUT		
	Get the Log Announce Interval by sending a LOG_ANNOUNCE_INTERVAL management message to the DUT. Extract the Log Announce Interval and calculate the announce interval		
Test Procedure	Test BMC algorithm		
	Test the best master clock algorithm (BMC) by changing the clock quality and the priority of the dut, to introduce the different BMC states priority1 clock class clock accuracy offset scaled log variance priority2		
Post Condition	Shutdown management node		
	Shutdown the PTP management node		
	Shutdown ordinary clock Shutdown the PTP clock		
3.2.1.3 Tes	t BMC related timeout ANNOUNCE_RECEIPT_TIMEOUT event		
Category	LXI Clock Synchronization		
Test Type	Kerberos Test, automated		
Rule	Test BMC related timeout ANNOUNCE RECEIPT TIMEOUT event		
Explanation	The test first examines the DUT in the slave state by causing the PC Clock to cease sending Announce messages to the DUT (by moving the PC Clock to a different domain) and observing how long it takes for the DUT to start sending Announce messages. The test then examines the DUT in the listening state by first initializing it and then observing how long it takes to start Announce messages given that there are no other clocks in the domain.		



Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Start ordinary clock	
		Start up the PTP clock
	Start management r	node
		Start up the PTP management node
	Initialize all clocks	
		Send a management message INITIALIZE to all clocks.
Test Procedure	Get Announce Inter	val from DUT
		Get the Log Announce Interval by sending a LOG_ANNOUNCE_INTERVAL management message to the DUT.
		Extract the Log Announce Interval and calculate the announce interval.
	Get Announce recei	pt timeout from DUT
		Get the Announce receipt timeout by sending a ANNOUNCE_RECEIPT_TIMEOUT management message to the DUT. Extract the Announce receipt timeout value.
	Set DUT to Slave	
		Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128)
	Test master stops	
		Disable the local clock, calculate the announce receipt timeout from the timestamps of the last announce message send from the local clock and the first announce message sent from the DUT. Match this against the DUT's configured announce receipt timeout.
	Test after initializing	
		Local clock is disabled. Send an INITITALIZE management message to the DUT, calculate the announce receipt timeout from the timestamps of the Initialize response message and the first announce message sent from the DUT. Match this against the DUT's configured announce receipt timeout
	Test when master do	pes not keep to threshold
		Enable local clock with an announce interval larger than the announce receipt timeout of the DUT. Wait several announce intervals and expect the DUT to act as master, because the announce intervals of the local clock are to long.
Post Condition	Reset local clock	
		Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)
	Shutdown ordinary	clock
		Shutdown the PTP clock
	Shutdown managen	nent node
		Shutdown the PTP management node
3.2.1.4 Ignore	e irrelevant messages	
Category	LXI Clock Synchroniz	zation
Test Type	Kerberos Test, autor	nated

Ignore irrelevant messages

Rule



Explanation	There are several sections of IEEE 1588 that specify conditions under which a clock disregards all or part of a received PTP message. This test covers the following of these:		
	versionPTP: Discard versions >2 18.1, translate version 1 optional 18.2(not required by LXI). domainNumber: Discard messages from a different domain, 9.5.1 alternateMasterFlag: Discard messages with this flag TRUE, 9.1 and LXI Profile 2.10.1, 9.3.2.2 for Announce,		
	Delay_Resp message not from current master or not associated with a Delay_Req from the slave clock: Discard, 9.5.7		
Test Procedure	Computed by other tests		
	This test is computed by the result of other tests.		
Dependencies	3.2.1.4.1 3.2.1.4.2 3.2.1.4.3 3.2.1.4.4 3.2.1.4.5 3.2.1.4.6 3.2.1.4.7		
3.2.1.4.1 Ignor	e irrelevant version messages		
Category	LXI Clock Synchronization		
Test Type	Kerberos Test, automated		
Rule	Ignore irrelevant version messages		
Explanation	There are several sections of IEEE 1588 that specify conditions under which a clock disregards all or part of a received PTP message. This test covers the versionPTP: Discard versions		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		
	Start management node		
	Start ordinany dock		
	Start ordinary clock Start up the PTP clock		
	Start device 2 ordinary clock		
	Start up the PTP clock of device 2.		
	Initialize all clocks		
	Send a management message INITIALIZE to all clocks.		
	Set DUT to Slave		
	Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128)		
	Set Device2 to 2nd in line		
	Set the device2 priority so that it is second in line to become master. For example local clock priority 0, DUT priority 128, then set Device2 to 45.		
Test Procedure	Set local PTP version		
	Change the local PTP version away from Version 2		
	Change IOCAL CLOCK TIME		
	the DUT keeps to the local clock time or not.		
	Wait for the DUT to be slave and the local clock master.		



	ls Device 2 master o	f DUT
		Check if the DUT has accepted Device 2 as master.
	Is Device 2 time the	time of DUT
		Check if the DUT's time is close to the Device 2 time.
	Discard Managemer	t messages Check if the DUT is discarding management messages. Send a management message to the DUT with wrong PTP version which should not get a response as wrong PTP versions shall be discarded.
	Repeat Version test	steps
		Repeat the test steps for following PTP versions: PTP Version 1 PTP Version 3
Post Condition	Reset local clock	
		Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)
	Shutdown device 2 d	ordinary clock
		Shutdown the PTP clock of device 2.
	Shutdown ordinary	clock
		Shutdown the PTP clock
	Shutdown managen	nent node
		Shutdown the PTP management node
3.2.1.4.2 Ignore	e irrelevant messages	from alternate master
Category	LXI Clock Synchroniz	ation
Test Type	Kerberos Test, automated	
Rule	Ignore irrelevant messages from alternate master	
Explanation	There are several sections of IEEE 1588 that specify conditions under which a clock disregards all or part of a received PTP message. This test covers the alternateMasterFlag: Discard messages with this flag TRUE, 9.1 and LXI Profile 2.10.1, 9.3.2.2 for Announce	
Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Start management n	ode
		Start up the PTP management node
	Start ordinary clock	
		Start up the PTP clock
	Start device 2 ordina	iry clock
		Start up the PTP clock of device 2.
	Initialize all clocks	Cond o monogeneous initialize to all dedice
		Send a management message INITIALIZE to all clocks.
	Set DUT to Slave	Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DLT is set to a lower priority value (e.g. 128)
	Set Device2 to 2nd i	n line
		Set the device2 priority so that it is second in line to become master. For example local clock priority 0, DUT priority 128, then set Device2 to 45.



Test Procedure	Enable alternate master flag		
	Enable the alternate master flag on the local clock. Other clocks should now stop using the local clock as master.		
	Change local clock time		
	Set the local clock time to a different value then the current time, to see if the DUT keeps to the local clock time or not.		
	Ensure DUT is Slave		
	Wait for the DUT to be slave and the local clock master.		
	Is Device 2 master of DUT		
	Check if the DUT has accepted Device 2 as master.		
	Is Device 2 time the time of DUT		
	Check if the DUT's time is close to the Device 2 time.		
Post Condition	Reset local clock		
	Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)		
	Shutdown device 2 ordinary clock		
	Shutdown the PTP clock of device 2.		
	Shutdown ordinary clock		
	Shutdown the PTP clock		
	Shutdown management node		
	Shutdown the PTP management node		
3.2.1.4.3 Igno	re irrelevant Delay Resp messages		
Category	LXI Clock Synchronization		
Test Type	Kerberos Test, automated		
Rule	Ignore irrelevant Delay Resp messages		
Explanation	There are several sections of IEEE 1588 that specify conditions under which a clock disregards all or part of a received PTP message. This test covers the Delay_Resp message not from current master or not associated with a Delay_Req from the slave clock: Discard, 9.5.7		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		
	Start management node		
	Start up the PTP management node		
	Start ordinary clock		
	Start up the PTP clock		
	Start device 2 ordinary clock		
	Start up the PTP clock of device 2.		
	Initialize all clocks		
	Send a management message INITIALIZE to all clocks.		
	Set DUT to Slave		
	Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128)		
	Set Device2 to DUT priority		
	Set the device2 priority to the same priority as the DUT.		



Test Procedure	Check device 2 correc	tion field influence on message: DELAY RESP
		Set the correction field value for DELAY_RESP messages to device 2.
		The meanPathDelay of the DUT should not be influenced by this.
	Set Device2 to local cl	lock priority
		Set the device2 priority to the same priority as the local clock.
	Set local clock to rece	ive only DELAY_REQ
		Modify the local clocks behaviour to only receive DELYA_REQ messages.
	Simulate device 2 DEL	.AY RESP
		set the correction field. The DUT should not accept these messages, therefore the meanPathDelay should stay stable.
	Send DELAY RESP as I	master
		Send only delay resp messages to the DUT acting as regular master and set the correction field. The DUT should not accept these messages as local clock is not master, therefore the meanPathDelay should stay stable.
Post Condition	Reset local clock	
		Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)
	Shutdown device 2 or	rdinary clock
		Shutdown the PTP clock of device 2.
	Shutdown ordinary cl	ock
		Shutdown the PTP clock
	Shutdown manageme	ent node
		Shutdown the PTP management node
3.2.1.4.4 Ignore	irrelevant Follow Up n	nessages
Category	LXI Clock Synchroniza	tion
Test Type	Kerberos Test, automa	ated
Rule	Ignore irrelevant Follow Up messages	
Explanation	There are several sect all or part of a receive	ions of IEEE 1588 that specify conditions under which a clock disregards
	master	
Pre Condition	master Connect DUT	
Pre Condition	master Connect DUT	Connect the DUT to the test network
Pre Condition	master Connect DUT Start management no	Connect the DUT to the test network
Pre Condition	master Connect DUT Start management no	Connect the DUT to the test network de Start up the PTP management node
Pre Condition	master Connect DUT Start management no Start ordinary clock	Connect the DUT to the test network de Start up the PTP management node
Pre Condition	master Connect DUT Start management no Start ordinary clock	Connect the DUT to the test network de Start up the PTP management node Start up the PTP clock
Pre Condition	master Connect DUT Start management no Start ordinary clock Start device 2 ordinary	Connect the DUT to the test network ode Start up the PTP management node Start up the PTP clock y clock
Pre Condition	master Connect DUT Start management no Start ordinary clock Start device 2 ordinary	Connect the DUT to the test network ide Start up the PTP management node Start up the PTP clock y clock Start up the PTP clock of device 2.
Pre Condition	master Connect DUT Start management no Start ordinary clock Start device 2 ordinary Initialize all clocks	Connect the DUT to the test network ode Start up the PTP management node Start up the PTP clock y clock Start up the PTP clock of device 2.
Pre Condition	master Connect DUT Start management no Start ordinary clock Start device 2 ordinary Initialize all clocks	Connect the DUT to the test network ide Start up the PTP management node Start up the PTP clock y clock Start up the PTP clock of device 2. Start up the PTP clock of device 2.
Pre Condition	master Connect DUT Start management no Start ordinary clock Start device 2 ordinary Initialize all clocks Set DUT to Slave	Connect the DUT to the test network ide Start up the PTP management node Start up the PTP clock y clock Start up the PTP clock of device 2. Send a management message INITIALIZE to all clocks.
Pre Condition	master Connect DUT Start management no Start ordinary clock Start device 2 ordinary Initialize all clocks Set DUT to Slave	Connect the DUT to the test network ide Start up the PTP management node Start up the PTP clock y clock Start up the PTP clock of device 2. Send a management message INITIALIZE to all clocks. Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128)
Pre Condition	master Connect DUT Start management no Start ordinary clock Start device 2 ordinary Initialize all clocks Set DUT to Slave Set Device2 to local cl	Connect the DUT to the test network ide Start up the PTP management node Start up the PTP clock y clock Start up the PTP clock of device 2. Send a management message INITIALIZE to all clocks. Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128) ock priority



Test Procedure	Set local clock to send only FOLLOW_UP
	Modify the local clocks behaviour to only send FOLLOW_UP messages.
	Send FOLLOW_UP as master
	Send only follow_up messages to the DUT acting as regular master and set the correction field. The DUT should not accept these messages as local clock is not master, therefore the meanPathDelay should stay stable
	Simulate device 2 FOLLOW_UP
	Modify the local clock to simulate device 2 FOLLOW_UP messages and set the correction field. The DUT should not accept these messages, therefore the meanPathDelay should stay stable.
Post Condition	Reset local clock
	Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)
	Shutdown device 2 ordinary clock
	Shutdown the PTP clock of device 2.
	Shutdown ordinary clock
	Shutdown the PTP clock
	Shutdown management node
	Shutdown the PTP management node
3.2.1.4.5 Igno	re irrelevant Delay Req messages
Category	LXI Clock Synchronization
Test Type	Kerberos Test, automated
Rule	Ignore irrelevant Delay Req messages
Explanation	There are several sections of IEEE 1588 that specify conditions under which a clock disregards all or part of a received PTP message. This test covers the Delay req messages received when not being master.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Start management node
	Start up the PTP management node
	Start ordinary clock
	Start up the PTP clock
	Start device 2 ordinary clock
	Start up the PTP clock of device 2.
	Initialize all clocks
	Send a management message INITIALIZE to all clocks.
	Set DUT to Slave
	ensuring the DUT is set to a lower priority value (e.g. 128)
	Set Device2 to DUT priority
Test Dis duis	Set the device2 priority to the same priority as the DUT.
lest Procedure	CNECK FOR DUT DELAY_RESP messages Check if the DUT is sending any DELAY_RESP messages. DUT should not be sending any DELAY_RESP messages as it is in state Slave.



Post Condition	Reset local clock
	Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)
	Shutdown device 2 ordinary clock
	Shutdown the PTP clock of device 2.
	Shutdown ordinary clock
	Shutdown the PTP clock
	Shutdown management node
	Shutdown the PTP management node
3.2.1.4.6 Igno	re irrelevant messages in Disable state
Category	LXI Clock Synchronization
Test Type	Kerberos Test, automated
Rule	Ignore irrelevant messages in Disable state
Explanation	There are several sections of IEEE 1588 that specify conditions under which a clock disregards all or part of a received PTP message. This test covers the messages to be discarded when device is in DISABLE state.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Start management node
	Start up the PTP management node
	Start ordinary clock
	Start up the PTP clock
	Start device 2 ordinary clock
	Start up the PTP clock of device 2.
	Initialize all clocks
	Send a management message INITIALIZE to all clocks.
	Set DUT to Slave
	Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128)
	Set Device2 to DUT priority
	Set the device2 priority to the same priority as the DUT.
Test Procedure	Disable DUT
	Send a DISABLE_PORT management message to the DUT to disable the clock.
	Check for DUT messages
	Check if the DUT is sending any messages. THe DUT is disabled therefore we expect no messages to be found.
Post Condition	Reset local clock
	Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)
	Shutdown device 2 ordinary clock
	Shutdown the PTP clock of device 2.
	Shutdown ordinary clock
	Shutdown the PTP clock



Shutdown management node Shutdown the PTP management node 3.2.1.4.7 Ignore irrelevant messages with undefined TLV Category LXI Clock Synchronization Kerberos Test, automated Test Type Rule Ignore irrelevant messages with undefined TLV **Explanation** There are several sections of IEEE 1588 that specify conditions under which a clock disregards all or part of a received PTP message. This test covers the messages with undefined TLV. Pre Condition Connect DUT Connect the DUT to the test network Start management node Start up the PTP management node Start ordinary clock Start up the PTP clock Start device 2 ordinary clock Start up the PTP clock of device 2. Initialize all clocks Send a management message INITIALIZE to all clocks. Set DUT to Slave Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128) Set Device2 to Slave Set the device2 priority to a very low priority value (e.g. 255). **Test Procedure** Append Invalid TLV Append invalid TLV to all messages of the local clock. Check Slave offset is reasonable Get the offset of the slave by sending a CURRENT_DATA_SET management message to the slave. Check if the offset is reasonable. Set DUT to Master Set DUT as target, get local port identity and DUT announce interval plus the calculated interval. Subsequently Switch local clock to slave. Give the DUT time and Ensure DUT is Master and stable mean path delay. Check Slave offset is reasonable Get the offset of the slave by sending a CURRENT_DATA_SET management message to the slave. Check if the offset is reasonable. Post Condition Reset local clock Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.) Shutdown device 2 ordinary clock Shutdown the PTP clock of device 2. Shutdown ordinary clock Shutdown the PTP clock Shutdown management node Shutdown the PTP management node



3.2.1.5	Honor Delay_Req inter-message interval	
Category	LXI Clock Synchronization	
Test Type	Kerberos Test, automated	
Rule	Honor Delay_Req inter-message interval	
Explanatior	In its Delay_Resp messages, the master tells slaves how frequently slaves are allowed to sen Delay_Req messages. The master sends the minimum average inter-message time (strictly, t log2 of this time) in the Delay_Resp messages. Slaves may send slower than that, but not faster. Slaves are required to make a fresh random choice of time for each message, while honoring this minimum. If they choose to set their average to the minimum allowed, the interval over which they choose random inter-message times is [0, 2t] seconds, where t is the time published by the master. 9.5.11.2	d he ie
	This test is conducted for two values of the expected intervals to verify that the slave correc responds to different values.	tly
Pre Conditi	Connect DUT	
	Start ordinany clock	
	Start ordinary clock Start up the PTP clock	
	Start management node	
	Start up the PTP management node	
	Initialize all clocks	
	Send a management message INITIALIZE to all clocks.	
Test Proced	e Get Min Delay Request Interval from DUT	
	Get the Port Set by sending a PORT_DATA_SET management message the DUT.	to
	Extract the Log Min Delay Req Internal from response and calculate th Min Delay Request Interval.	e
	Set DUT to Slave	
	Set the local clock to master by setting a high priority value (e.g. 0) ar ensuring the DUT is set to a lower priority value (e.g. 128)	d
	Test Min Delay Request Interval	
	Evaluate the intervals between the captured Min Delay Request messa and ensure the interval is larger than the minimum delay request inter	ges val.
Post Condi	n Shutdown ordinary clock	
	Shutdown the PTP clock	
	Shutdown management node Shutdown the PTP management node	
3.2.1.6	Meet timing constraints	
Category	LXI Clock Synchronization	
Test Type	Kerberos Test, automated	

Rule Meet timing constraints



Explanation	This test checks timing requirements on Announce and Sync messages from a clock in the master state outlined in section 7.7 and 9.5 of IEEE 1588.	
	The tests will be con	ducted in the following order:
	Test Announce inter within +/- 30% of th Test Sync intervals. 9 within +/- 30% of th Test accuracy of orig actual time of maste	vals. 9.5.8 A node shall, with 90% confidence, issue messages with intervals ne value of the interval computed from portDS.logAnnounceInterval. 0.5.9.2 A node shall, with 90% confidence, issue messages with intervals ne value of the interval computed from portDS.logSyncInterval. ginTimestamp in Sync messages. 9.5.9.4 0 or no worse than 1 second from er.
Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Start ordinary clock	
		Start up the PTP clock
	Start management r	node
		Start up the PTP management node
	Initialize all clocks	
		Send a management message INITIALIZE to all clocks.
	Set DUT to Master	
		Set DUT as target, get local port identity and DUT announce interval plus the calculated interval. Subsequently Switch local clock to slave. Give the DUT time and Ensure DUT is Master and stable mean path delay.
Test Procedure	Check log interval va	alues from DUT
		Get the Port Set by sending a PORT_DATA_SET management message to the DUT.
		Extract the Log Announce and Log Sync Interval from response and make sure they are within the expected boundaries.
		Min Value
		Max Value
		Log Announce Interval
		0
		4
		Log Sync Interval
		-1
	Ensure DUT is Slave	
		Wait for the DUT to be slave and the local clock master.
	Check interval confid	dence
		Wait for a certain amount of messages. Calculate the interval between these messages and make sure 90% of the messages keep to the expected interval. Test this for SYNC and ANNOUNCE messages.
	Check Sync timestar	np quality
		Wait for a certain amount of SYNC messages or FOLLOW_UP messages if two step is active. Extract the timestamps and make sure the timestamp differences between two messages match the SYNC interval length.



Reset local clock		
	Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)	
Shutdown ordinary	clock	
	Shutdown the PTP clock	
Shutdown managen	nent node	
	Shutdown the PTP management node	
ction Field		
LXI Clock Synchroniz	zation	
Kerberos Test, autor	Kerberos Test, automated	
Correction Field	Correction Field	
The timing messages in IEEE 1588 version 2 contain a field named correctionField. These fields contain modifications of the timestamp fields and must be correctly used by a slave clock in order to properly synchronize to its parent clock. Likewise a master clock must ensure that the combination of master transmitted timestamps and correctionFields correctly indicates the time intended.		
Connect DUT		
	Connect the DUT to the test network	
Start ordinary clock		
	Start up the PTP clock	
Start management r		
Initializa all ala aka	start up the PTP management hode	
	Send a management message INITIALIZE to all clocks	
Set DUT to Slave		
	Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128)	
Ensure DUT is Slave		
	Wait for the DUT to be slave and the local clock master.	
Wait for stable mean	nPathDelay of Slave	
	Wait for the meanPathDelay to be stable. Retrieve the meanPathDelay via a CURRENT_DATA_SET management message to the Slave.	
Check correction fie	ld influence on messages: SYNC, FOLLOW UP, DELAY RESP	
	Set the correction field value for one of the following messages: SYNC, FOLLOW UP, DELAY RESP. Expect the meanPathDelay perturbation to rise by half the value set in correction field	
Set DUT to Master		
	Set DUT as target, get local port identity and DUT announce interval plus the calculated interval. Subsequently Switch local clock to slave. Give the DUT time and Ensure DUT is Master and stable mean path delay.	
Ensure DUT is Maste	2r	
	Wait for the DUT to be master and the local clock slave.	
Wait for stable mean	nPathDelay of Slave Wait for the meanPathDelay to be stable. Retrieve the meanPathDelay via a CURRENT_DATA_SET management message to the Slave.	
	Reset local clock Shutdown ordinary Shutdown manager Ction Field LXI Clock Synchronic Kerberos Test, autor Correction Field The timing message contain modification order to properly sy combination of mass intended. Connect DUT Start ordinary clock Start management r Initialize all clocks Set DUT to Slave Ensure DUT is Slave Wait for stable mean Check correction fiel Set DUT to Master Ensure DUT is Master Wait for stable mean	



	Check correction field influence on messages: DELAY REQ	
	Set the correction field value for one REQ.	of the following messages: DELAY
	Expect the meanPathDelay perturbat correction field.	tion to rise by half the value set in
Post Condition	Reset local clock	
	Reset all clock modifications done to priority, log announce interval, speci	the local clock during this test (e.g. al stack modifications etc.)
	Shutdown ordinary clock	
	Shutdown the PTP clock	
	Shutdown management node	
	Shutdown the PTP management noc	de
3.2.1.8 Sync	chronize to one-step and two-step masters	
Category	LXI Clock Synchronization	
Test Type	Kerberos Test, automated	
Rule	Synchronize to one-step and two-step masters	
Explanation	One-step clocks do not send Follow_Up messages but any clock, one- or two-step, must be able to synchronize to it. Two-step clocks do send Follow_Up messages and any clock, one- two-step, must correctly use the Follow Up message as part of synchronization. see 11.2.	
	The test is to verify that the DUT correctly synchronizes to requires:	both types of clocks. Specifically this
	A DUT in the slave state correctly synchronize to a one-ste A DUT in the slave state correctly synchronize to a two-ste	p master clock, and p master clock.
	The first test has effectively been accomplished by the exe clock is used and the measure of synchronization is the me value.	cution of test 7 in which a two-step eanPathDelay having a reasonable
Pre Condition	Connect DUT	
	Connect the DUT to the test network	< compared by the second s
	Start ordinary clock	
	Start up the PTP clock	
	Start management node	
	Start up the PTP management node	
	Initialize all clocks	
	Send a management message INITIA	LIZE to all clocks.
	Set DUT to Slave	
	Set the local clock to master by setti ensuring the DUT is set to a lower pr	ng a high priority value (e.g. 0) and riority value (e.g. 128)
Test Procedure	Set local clock to One-Step	
	Set the lock clock to act as a One-Ste will be delivering the timestamps dir sending a Follow_Up message with t	ep master. This means the local clock ectly in the SYNC message instead of he timestamp.



	Wait for stable mea	nPathDelay of Slave
		Wait for the meanPathDelay to be stable. Retrieve the meanPathDelay via a CURRENT_DATA_SET management message to the Slave.
	Set local clock to Tv	vo-Step
		Set the lock clock to act as a Two-Step master. This means the local clock will be delivering the timestamps in a Follow_Up message.
	Wait for stable mea	nPathDelay of Slave
		Wait for the meanPathDelay to be stable. Retrieve the meanPathDelay via a CURRENT_DATA_SET management message to the Slave.
Post Condition	Reset local clock	
		Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)
	Shutdown ordinary	clock
		Shutdown the PTP clock
	Shutdown manager	nent node
		Shutdown the PTP management node
3.2.1.9 Hond	or V1 HW compatibility	y bit
Category	LXI Clock Synchroni	zation
Test Type	Kerberos Test, auto	mated
Rule	Honor V1 HW com	patibility bit
Explanation	Some devices desig packet length in dea that clocks interacti the transport specif	ned under IEEE 1588-2002 but still usable with IEEE 1588-2008 use the ciding whether to timestamp packets. Annex D of IEEE 1588-2008 requires ng with such a device respond correctly to the hardwareCompatibility bit in ic fields of Announce, Sync, and Delay_Req messages.
	The test first checks this bit set. The seco with this bit set.	that a slave clock correctly responds to Announce and Sync messages with ond part of the test checks that a master correctly responds to a Delay_Req
Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Start ordinary clock	
		Start up the PTP clock
	Start management	node
		Start up the PTP management node
	Initialize all clocks	
		Send a management message INITIALIZE to all clocks.
	Set DUT to Slave	Cat the least deals to reactor by acting a birth priority value (a.g. 0) and
T (D)		ensuring the DUT is set to a lower priority value (e.g. 128)
lest Procedure	Check V1 hardware	compatibility for DELAY_REQ
		compatibility is set and that the flag is set, otherwise flag must not be set and messages are V2 size.
	Set DUT to Master	
		Set DUT as target, get local port identity and DUT announce interval plus the calculated interval. Subsequently Switch local clock to slave. Give the DUT time and Ensure DUT is Master and stable mean path delay.



	Check V1 hardware compatibility for SYNC and ANNOUNCE	
	Check the Sync messages are extended when V1 hardware compatibility is set and that the flag is set, otherwise flag must not be set and	
	Check the Announce messages have the flag set when V1 hardware compatibility is set, otherwise flag must not be set.	
Post Condition	Reset local clock	
	Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)	
	Shutdown ordinary clock	
	Shutdown the PTP clock	
	Shutdown management node Shutdown the PTP management node	
3.2.1.10 Reje	ct Rogue Frames	
Category	LXI Clock Synchronization	
Test Type	Kerberos Test, automated	
Rule	Reject Rogue Frames	
Explanation	Subsection 9.3.2.5 of IEEE 1588-2008 says to ignore Announce messages which have traversed more than 255 boundary clocks - a preposterous depth for a tree. That requirement is intended to break loops.	
Pre Condition	Connect DUT	
	Connect the DUT to the test network	
	Start ordinary clock	
	Start up the PTP clock	
	Start management node	
	Start up the PIP management node	
	Initialize all clocks	
	Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128)	
Test Procedure	Ensure DUT is Slave	
	Wait for the DUT to be slave and the local clock master.	
	Set steps removed	
	Increase the steps removed of the local clock to 255, so that the DUT does not accept the local clock as master.	
	Wait for announce intervals	
	Wait for a certain amount of announce intervals	
	Ensure DUT is Master	
Past Condition	Walt for the DUT to be master and the local clock slave.	
Post Condition	Reset local clock Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)	
	Shutdown ordinary clock	
	Shutdown the PTP clock	

Shutdown management node



Shutdown the PTP management node 3.2.1.11 Protocol not affected by sequence number rollover Category LXI Clock Synchronization Kerberos Test, automated Test Type Rule Protocol not affected by sequence number rollover **Explanation** Mandatory: testing the response of the DUT to sequence rollover in messages from the PC Clock, i.e. Announce, Sync, Follow Up. Subsection 7.3.7 of IEEE 1588-2008 requires separate sequenceld values for certain messages with rollover properties defined by the datatype UInteger16. **Pre Condition** Connect DUT Connect the DUT to the test network Start ordinary clock Start up the PTP clock Start management node Start up the PTP management node Initialize all clocks Send a management message INITIALIZE to all clocks. Set DUT to Slave Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128) Ensure DUT is Slave Wait for the DUT to be slave and the local clock master. Wait for stable meanPathDelay of Slave Wait for the meanPathDelay to be stable. Retrieve the meanPathDelay via a CURRENT_DATA_SET management message to the Slave. **Test Procedure** Check sequence ID's for rollover: ANNOUNCE and SYNC Make sure a sequence ID rollover does not disturb the clock. Increase the sequence ID on local clock close to rollover. Wait for the rollover to happen and ensure the DUT is still stable. Do this check for Announce and Sync messages. Post Condition Reset local clock Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.) Shutdown ordinary clock Shutdown the PTP clock Shutdown management node Shutdown the PTP management node 3.2.1.12 Seperate sequence number spaces maintained Category LXI Clock Synchronization Kerberos Test, automated Test Type Rule Seperate sequence number spaces maintained

Explanation Subsection 7.3.7 of IEEE 1588-2008 requires separate sequenceld number spaces for Sync, Delay_Req, Announce, Signaling and Management messages.



Pre Condition	Connect DUT	
	Connect the DUT to the test network	
	Start ordinary clock	
	Start up the PTP clock	
	Start management node	
	Start up the PTP management node	
	Initialize all clocks	
	Send a management message INITIALIZE to all clocks.	
lest Procedure	Set DUT to Master	
	the calculated interval. Subsequently Switch local clock to slave. Give the DUT time and Ensure DUT is Master and stable mean path delay.	ne
	Test sequence ID's of DUT in state Master	
	Get messages of the type sync, delay req, announce and delay resp. Sync message ID's shall match Follow_Up message ID's Delay_Req message ID's shall match Delay_Resp message ID's Announce message ID's shall not match Sync or Delay_Resp message I Delay_Resp message ID's shall not match Sync message ID's	ID's
	Set DUT to Slave	
	Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128)	d
	Test sequence ID's of DUT in state Slave	
	Get messages of the type delay req, delay_resp as well as the last DUT messages as master from type sync, delay_resp announce. Delay_Resp message ID's shall match Delay_Res message ID's last Delay_Resp message ID as master shall not match last Sync messag ID as master last Delay Resp message ID as master shall not match last Delay_Resp slave	ge as
Post Condition	Reset local clock	
	Reset all clock modifications done to the local clock during this test (e. priority, log announce interval, special stack modifications etc.)	g.
	Shutdown ordinary clock	
	Shutdown the PTP clock	
	Shutdown management node	
	Shutdown the PTP management node	
3.2.1.13 Max	nd min Sync message rate	
Category	LXI Clock Synchronization	
Test Type	Kerberos Test, automated	
Rule	Max and min Sync message rate	
Explanation	This test verifies that the DUT as a slave can synchronize to a master over the range of Sync intervals required by the LXI 1588 Profile and that as a master it can service slaves over the required range of Sync intervals. The test exercises the required minimum and maximum Sync intervals and the recommended minimum interval supported by the DUT.	۱C
Pre Condition	Connect DUT	

Connect the DUT to the test network



	Start ordinary clock	
		Start up the PTP clock
	Start management	node
		Start up the PTP management node
	Initialize all clocks	
		Send a management message INITIALIZE to all clocks.
Test Procedure	Set Sync Interval	
		Set the sync interval to the local clock and send a LOG_SYNC_INTERVAL management message to the DUT to set its sync interval as well.
	Set DUT to Slave	
		Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128)
	Check Slave offset i	s reasonable
		Get the offset of the slave by sending a CURRENT_DATA_SET management message to the slave. Check if the offset is reasonable.
	Set DUT to Master	
		Set DUT as target, get local port identity and DUT announce interval plus the calculated interval. Subsequently Switch local clock to slave. Give the DUT time and Ensure DUT is Master and stable mean path delay.
	Check Slave offset i	s reasonable
		Get the offset of the slave by sending a CURRENT_DATA_SET management message to the slave. Check if the offset is reasonable.
	Check interval confi	dence
		Wait for a certain amount of messages. Calculate the interval between these messages and make sure 90% of the messages keep to the expected interval. Test this for SYNC and ANNOUNCE messages.
	Repeat Sync test ste	eps
		Repeat the test steps for following sync values: Max Sync value: 1
		Default Min Sync value: -1
		Recommended Min Sync value: -1 to -4
		The recommended Min Sync value must first be determined. Lowest recommended value is -4.
Post Condition	Reset local clock	
		Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)
	Shutdown ordinary	clock
		Shutdown the PTP clock
	Shutdown manager	nent node
		Shutdown the PTP management node
3.2.1.15 Clock	C Description	

Category	LXI Clock Synchronization
Test Type	Kerberos Test, automated
Rule	Clock Description



Explanation	This test verifies that the DUT as a master correctly describes itself in the Announce and Sync messages.		
	The attributes related to the timescale have been tested in test 14. The contents of the datasets have been examined in test 1 as part of the testing of management messages. This test checks that the contents of the datasets for the fields listed appear correctly in the Announce and Sync messages.		
	Tested fields: versionPTP twoStepFlag grandmasterPriority1 grandmasterClockQuality grandmasterPriority2 grandmasterIdentity		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		
	Start ordinary clock		
	Start up the PTP clock		
	Start management node		
	Start up the PTP management node		
	Initialize all clocks		
	Send a management message INITIALIZE to all clocks.		
	Set DUT to Master		
	Set DUT as target, get local port identity and DUT announce interval plus the calculated interval. Subsequently Switch local clock to slave. Give the DUT time and Ensure DUT is Master and stable mean path delay.		
Test Procedure	Get default data set from DUT		
	Send a DEFAULT_DATA_SET management message to the DUT to get the default data set.		
	Get port data set from DUT		
	Send a PORT_DATA_SET management message to the DUT to get the port data set.		
	Test sync message details		
	Test sync message details against port and default data sets. Version Number Source Port Identity		
	Two Step flag		
	Test announce message details		
	Test announce message details against port and default data sets.		
	Version Number		
	Grandmaster Priority1		
	Grandmaster Priority2		
	Grandmaster Identity		
Post Condition	Reset local clock		
	Reset all clock modifications done to the local clock during this test (e.g.		
	priority, log announce interval, special stack modifications etc.)		



	Shutdown ordinary clock	
	Shutdown the PTP clock	
	Shutdown management node	
	Shutdown the PTP management node	
3.2.1.16 Time	span	
Category	LXI Clock Synchronization	
Test Type	Kerberos Test, automated	
Rule	Time span	
Explanation	This test verifies that the clock in the DUT can advance from 232-1 seconds to 232 seconds, both as master and as slave. This is best done by looking at the timestamps on the wire, since operating systems may not format the date correctly. The date is approximately 6:28:16 am Fel 7, 2106, TAI. (It's impossible to know what the UTC time is because the leap second offset for that date is unknown).	
	Correct operation when the DUT is master is observed using Wireshark.	
Test Procedure	Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	3.2.1.5 3.2.1.6	
3.2.1.17 Leap	second info passed from master to slave	
Category	LXI Clock Synchronization	
Test Type	Kerberos Test, automated	
Rule	Leap second info passed from master to slave	
Explanation	This test verifies that the DUT correctly updates the time properties data set from the Announce message from the grandmaster.	
Pre Condition	Connect DUT	
	Connect the DUT to the test network	
	Start ordinary clock	
	Start up the PTP clock	
	Start management node	
	Start up the PIP management node	
	Initialize all clocks	
	Send a management message initiAlize to all clocks.	
	Set DOT to slave Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128)	
	Ensure DUT is Slave Wait for the DUT to be slave and the local clock master.	



Test Procedure	Compare time properties between local clock and DUT
	Compare the time properties between the local clock and the DUT. Current UTC offset Current UTC offset valid flag Frequency Traceable flag Leap59 flag Leap61 flag Timescale flag
	Time traceable flag
	Modify local clock time properties
	DUT shall accept these new clock properties.
	Compare time properties between local clock and DUT
	Compare the time properties between the local clock and the DUT. Current UTC offset Current UTC offset valid flag Frequency Traceable flag Leap59 flag Leap61 flag Timescale flag Time source Time traceable flag
Post Condition	Reset local clock
	Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)
	Shutdown ordinary clock
	Shutdown the PTP clock
	Shutdown management node Shutdown the PTP management node
3.2.1.19 Co	prrect nominal clock speed
Category	LXI Clock Synchronization
Test Type	Vendor Declaration
Rule	Correct nominal clock speed
Explanation	Clause J.3.4.1 requires that the frequency of a master clock be within 0.01% of the SI second.
	This is part of the IEEE1588 standard.
3.2.1.20 Clo	ock subsystem survives time jump
Category	LXI Clock Synchronization
Test Type	Vendor Declaration
Rule	Clock subsystem survives time jump
Explanation	IEEE 1588 specifies certain changes of state and issuing of messages based on timeouts such as the ANNOUNCE_RECEIPT_TIMEOUT and the Sync and Delay_Req intervals. This declaration ensures a jump in the local clock does not disturb the accuracy of these timeouts and intervals for some common cases.
	This is part of the IEEE1588 standard.



3.2.1.22	Application of asymmetry correction
Category	LXI Clock Synchronization
Test Type	Vendor Declaration
Rule	Application of asymmetry correction
Explanation	The protocol assumes the packet travel time between master and slave is equal in both directions. If it is not, an uncorrected system will exhibit a systematic offset between slave and master equal to half the asymmetry. PTP can't measure this asymmetry, but if it is measured the implementation can be told its magnitude and sign, and PTP will correct for it.
	This test is only useful if the implementation has a mechanism for entering the value of the asymmetry of the link to its master. The appropriate corrections for this asymmetry are specified in clause 11 of IEEE 1588.
	This is part of the IEEE1588 standard.
3.2.1.23	Proper simultaneous startup of many clocks
Category LXI Clock Synchronization	
Test Type	Vendor Declaration
Rule	Proper simultaneous startup of many clocks
Explanation	The protocol is supposed to converge to 1 master and n-1 slaves under almost any conditions. This checks one of the challenging conditions: many clocks waking up at the same time. The protocol should settle, and all clocks should agree on who the master is.
	This is part of the IEEE1588 standard.
3.2.1.24	DUT uses grandmaster not parent data in BMC
Category	LXI Clock Synchronization
Test Type	Vendor Declaration
Rule	DUT uses grandmaster not parent data in BMC
Explanation	This declaration verifies that the DUT uses the grandmaster fields in Announce messages rather than parent fields as inputs to the best master clock algorithm.
	This is part of the IEEE1588 standard.
3.2.5	Must Be Able to Set UTC Time
Category	LXI Clock Synchronization
Test Type	Kerberos Test, automated
Rule	Must Be Able to Set UTC Time
Explanation	Any LXI device implementing IEEE 1588 functionality shall be capable of being made traceable to UTC in the event that it is selected as the grandmaster clock by the IEEE 1588 protocol.
Test Procedu	Computed by other tests
Dopondonci	I his test is computed by the result of other tests.
Dependence	
3.2.6	Must Be Able to Set UTC Time Manually
Category	LXI Clock Synchronization
Test Type	Kerberos Test, manual

Report bases on file: LxiConformanceTestSuite_1.6.json



Rule	Must Be Able to Set l	JTC Time Manually
Explanation	Traceability to UTC sh messages with manage TRACEABILITY_PROPE manually via manage Otherwise, using the time corresponding to the value seen in its t The timestamps can be device's Sync Configu other tests. If the time Yes. Otherwise, note w This test verifies that UTC as required by 3. or IEEE 1588 manage	hall be, at a minimum, available by the use of IEEE 1588 management gementId values of: TIME, CLOCK_ACCURACY, UTC_PROPERTIES, ERTIES, and TIMESCALE_PROPERTIES.If the test for 3.2.1.14setting time ment messages was successful, then click yes. web pages set the time to January 1, 1970, 00:00:00 UTC (this is the date/ o a timestamp of zero). The formatted time should go to that value and imestamps should go to 0.0, and then both should advance at 1 sec/sec. be seen via Wireshark in its Sync packets, and the time can be seen on the uration Web Page. Set the master to the correct time before proceeding to e was set to the correct value, and advances at 1 sec/sec then click what failed the the Test Result window and click No. the DUT as a master can have its time adjusted to be traceable to UTC. .2.5 and 3.2.6 of the LXI Standard. LXI Devices can use either the web page ment messages to set the time and the related time properties.
Pre Condition	Connect DUT	
		Connect the DUI to the test network
	Start ordinary clock	Charte up the DTD algorit
	Start management no	Start up the PTP management node
	Initialize all clocks	Start up the Fire management node
		Send a management message INITIALIZE to all clocks.
	Set DUT to Master	
		Set DUT as target, get local port identity and DUT announce interval plus the calculated interval. Subsequently Switch local clock to slave. Give the DUT time and Ensure DUT is Master and stable mean path delay.
Test Procedure	Check UTC properties against announce message	
		Set the UTC properties of the DUT and check the announce messages for these UTC properties. UTC properties: Current UTC offset Current UTC offset valid flag Leap59 flag Leap61 flag
	Check properties against sync and announce message	
		Set the Utc-, traceability-, timescale properties and time of to DUT. Check the sync message timestamp and announce messages, if properties and time have been accepted. UTC properties: Current UTC offset Current UTC offset Current UTC offset valid flag Leap59 flag Leap61 flag Traceability properties: Frequency Traceable flag Time traceable flag Timescale properties: Timescale flag
		Time source



	Check sync timespan	
	Evaluate the timespan between two received messages, the timespan should match the Sync Interval.	
	Check manual via web page	
	If time could not be set via management messages, we need to test if time can be set via the web page. Go to the web page Is time settable via web page? Set clock time to 'January 1, 1970, 00:00:00 UTC' (equivalent of timestamp 0) Check time has been accepted by evaluating the Sync message properties	
Post Condition	Reset local clock	
	Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)	
	Shutdown ordinary clock	
	Shutdown the PTP clock	
	Shutdown management node	
	Shutdown the PTP management node	
3.2.8 Com	nunication of Time Must Use IEEE 1588 Time Base	
Category	LXI Clock Synchronization	
Test Type	Kerberos Test, manual	
Rule	Communication of Time Must Use IEEE 1588 Time Base	
Explanation	All time references communicated to or from LXI Devices in an LXI system shall be based on the system-wide IEEE 1588 timescale established by the IEEE 1588 clocks in each device. Translation between the IEEE 1588 time base and UTC in an LXI Device shall only occur at the interface to another subsystem external to the portion of the system operating based wholly or in part on time (e.g. a user interface or a database). All LXI Devices required to make this translation shall use the currentUtcOffset information distributed by the IEEE 1588 protocol.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
Test Procedure	Test inter-module messages use IEEE 1588 as time base	
lest riocedure	Set the PTP time to January 1st, 1970, 00:00:00 UTC (corresponding timestamp of zero) Send a message to any destination via a time based trigger (alarm) Use a packet detector to check the timestamp to be within a few milliseconds of zero If all timestamps were close to zero timestamp, click Yes otherwise No.	
3.2.10 Inclu	sion of IEEE 1588 Time-Based Triggers	
Category		
Test Type	Kerberos Test automated	
rescrippe		



Explanation	LXI Devices containing triggerable functions or events and which implement IEEE 1588 shall include one or more time-based triggers. This is necessary for implementation of autonomous time-based event coordination in the LXI Device.
Test Procedu	re Computed by other tests
	This test is computed by the result of other tests.
Dependencie	s 3.2.8
3.2.11	Generation of Timestamps
Category	LXI Timestamped Data
Test Type Vendor Declaration	
Rule	Generation of Timestamps
Explanation	LXI Device generating timestamps based upon an IEEE 1588 clock shall provide information as to the accuracy of the timestamps that they supply. As a minimum, this information shall be available as part of the documentation that accompanies each LXI Device (whether printed or electronic).
3.2.12	Pulse-per-Second Output
Category	LXI Clock Synchronization
Test Type	Vendor Declaration
Rule	Pulse-per-Second Output
Explanation	A pulse-per-second output shall be available on all LXI Devices implementing IEEE 1588. The mechanical and electrical specifications of this output shall be vendor-defined, but the output shall generate a rising edge synchronous with the second's transitions of the IEEE 1588 clock.
	This pulse-per-second output is intended to be compared with corresponding outputs of the other clocks in the system to verify synchronization performance. The test point does not need to be available externally, although it can be brought to an external point if desired (for instance, by configuring the LXI Wired Trigger Bus to carry the signal).
3.6	Data Timestamps
Category	LXI Timestamped Data
Test Type	Vendor Declaration
Rule	Data Timestamps
Explanation	LXI Devices shall assign a timestamp to all measurement data. See Section 6.5 of the LXI Device Specification concerning driver requirements associated with LXI Timestamped Data.
	For all LXI Devices implementing IEEE 1588, all such timestamps shall be derived from the local IEEE 1588 synchronized real-time clock. LXI Devices implementing any part of the standard LXI API (see Section 6 of the LXI Device Specification document) shall return a valid data timestamp value.



4.0 Module-To-Module Data Communication of LXI Event Messages

Categories LXI Event Messaging



5.0 LXI Device Wired Trigger Bus

Categories LXI Wired Trigger Bus



6.0 LXI Programmatic Interface (Drivers)

Categories	General Device
6.1	IVI Driver Requirement
Category	General Device
Test Type	Vendor Declaration
Rule	IVI Driver Requirement
Explanatior	All LXI Devices shall provide an IVI Specific Driver. The details of this requirement are called out in Section 5 of IVI-3.1. If an LXI Device is a reasonable match to an existing IVI Class specification, its driver shall be compliant to that IVI Class10.
6.1.1	Trigger and Event Required API
Category	LXI Clock Synchronization
Test Type	Vendor Declaration
Rule	Trigger and Event Required API
Explanatior	IVI drivers for LXI Devices shall conform to the IVI-3.15 lviLxiSync specification when required by an LXI Extended Function.
6.2	Syntax of the Device Address
Category	General Device
Test Type	Vendor Declaration
Rule	Syntax of the Device Address
Explanatior	LXI IVI Drivers shall accept VISA resource names.The IVI driver provided with an LXI Device may use whatever underlying protocol is permitted by sections 8.1. However, the driver shall accept any valid VISA resource name as the network resource location as described in this section.Specifically, valid VISA resource names for LXI Devices are: TCPIP[board]::host address[::LAN device name][::INSTR]TCPIP[board]::host address[::HISLIP device name[,HISLIP port]][::INSTR]
6.5	API Shall Represent Time as Two 64-bit Floats
Category	LXI Clock Synchronization
Test Type	Vendor Declaration
Rule	API Shall Represent Time as Two 64-bit Floats
Explanatior	All IVI interfaces shall represent IEEE 1588 time, time-stamps, or alarms as two 64-bit floating point numbers. One containing the seconds portion and one containing the fractional seconds.
6.5.1	Property Names for Real-Time Representation
Category	LXI Clock Synchronization
Test Type	Vendor Declaration
Rule	Property Names for Real-Time Representation
Explanatior	All interfaces for setting or retrieving IEEE 1588 time or alarms derived from IEEE 1588 time shall have two properties of type DOUBLE named TimeSeconds and TimeFraction.


6.5.2	Property Names for Real-Time Timestamp
Category	LXI Clock Synchronization
Test Type	Vendor Declaration
Rule	Property Names for Real-Time Timestamp
Explanation	LXI Devices generating timestamps shall provide two properties of type DOUBLE named TimeStampSeconds and TimeStampFraction in all interfaces that are capable of querying measured data from the device for retrieving the timestamp associated with said data. These properties shall be read only.



7.0 LAN Specification

Categories General Device

7.1 Et	hernet Required		
Category	LAN, Device Specification		
Test Type	Kerberos Test, automated		
Rule	Ethernet Required		
Explanation	LXI Devices shall implement Ethernet For a physical connection, this shall be a minimum of 100 Mbits/second, IEEE 802.3 Type 100 BASE-TX.		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		
Test Procedure	Detect Network speed		
	Detect the current network speed. The device and the hardware are connected directly therefore the network speed of the hardware is the speed negotiated by the DUT.		
	Evaluate Network speed		
	Evaluate the network speed for 1000BaseT, 100BaseTx and 10BaseT. 10BaseT is optional and need not pass.		
7.1.2 Pr	roper Operation in Slower Networks		
Category	LAN, Device Specification		
Test Type	Kerberos Test, automated		
Rule	Proper Operation in Slower Networks		
Explanation	LXI Devices shall operate properly in Ethernet networks of equal or slower speed than themselves, at least down to 100 Mbits/sec Ethernet. If LXI Devices could operate at 10 Mbits/ second, they shall be IEEE 802.3 Type 10 BASE-T.		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
Test Procedure	Detect Network speed		
	Detect the current network speed. The device and the hardware are connected directly therefore the network speed of the hardware is the speed negotiated by the DUT.		
	Change Network speed 1000		
	Change the network speed to 1000BaseT		
	Ping the DUT for success		
	Ping the DUT via IPv4 which is expected to succeed		
	Change Network speed 100		
	Change the network speed to 100BaseTX		
	Ping the DUT for success		
	Ping the DUT via IPv4 which is expected to succeed		
	Change Network speed 10		
	Ding the DLT for success		
	Ping the DUT via IPv4 which is expected to succeed		



7.2	MAC Address Display		
Category	LAN, Device Specification		
Test Type	Kerberos Test, manual		
Rule	MAC Address Display		
Explanation	LXI Devices shall display the MAC address of the LXI Device via a user-accessible display or label affixed to the LXI Device. The MAC address is not changeable.		
Test Proced	re Query MAC address display Query the Tester for the MAC address displayed via the user interface o on a label fixed to the device.		
7.3	Ethernet Connection Monitoring		
Category	LAN, Device Specification		
Test Type	Kerberos Test, manual		
Rule	Ethernet Connection Monitoring		
Explanation	LXI Devices shall incorporate Ethernet connection monitoring (one possible implementation of which is commonly known as Media Sense in Microsoft operating systems). Upon detecting a connection event, the current IP configuration shall be validated (including duplicate IP addre detection) and, if necessary, updated.		
Test Procee	re Disconnect DUT		
	Disconnect the DUT from the test network		
	Is LAN Status Indicator showing FAULT		
	Prompt the Tester to check the LAN Status indicator for FAULT.		
	Connect DUI		
	Is LAN Status Indicator showing OK		
	Prompt the Tester to check the LAN Status indicator for OK.		
7.5	Label Required on LXI Devices Without Auto-MDIX		
Category	LAN, Device Specification		
Test Type	Kerberos Test, manual		
Rule	Label Required on LXI Devices Without Auto-MDIX		
Explanation	If Auto-MDIX is not supported the LXI Device shall be clearly labeled with a physical, human- readable label. A "soft" label, on an instrument display, for instance is insufficient.		
Pre Condit	n Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
TID	Search via mdns for a single Ixi service and retrieve its IP address		
lest Proced	re Change to MDIX off		
	Ping the DUT for success		
	Ping the DUT via IPv4 which is expected to succeed		
	Change to MDIX on		
	Change the LAN settings to MDIX on		
	Ping the DUT for success		
	Ping the DUT via IPv4 which is expected to succeed		



	Query Auto-MDIX label		
	Query tester if a label clearly notifies this device is not Auto-MDIX capable.		
Post Condition	Change to MDIX auto		
	Change the LAN settings to MDIX auto. This is the default setting.		
7.6 En	able Auto-Negotiation by Default		
Category	LAN, Device Specification		
Test Type	Kerberos Test, automated		
Rule	Enable Auto-Negotiation by Default		
Explanation	LXI Devices should support auto-negotiation by default to select the highest operating mode. In most cases, Auto-Negotiation eliminates the need for the user to explicitly set the operating modes at both ends of the cable. Most Ethernet products enable Auto-Negotiation by default.		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
Test Procedure	Detect Advertised Auto-Negotiation flag Detect whether DUT is advertising Auto-Negotiate		
7.7 Mu	ultiple LAN Interfaces		
Category	LAN, Device Specification		
Test Type	Kerberos Test, manual		
Rule	Multiple LAN Interfaces		
Explanation	If multiple LAN interfaces (NIC's) are present in an LXI Device, at least one of them shall be fully conformant with the LXI Device Specification (Rule 1.4.4.2.1). The other NIC's don't have to provide any LXI capabilities.		
	If a vendor decides that all the NIC's are LXI capable, then they shall be fully conformant with the LXI Device Specification (web server, mDNS, XML identification schema etc.) as a minimum. All NIC's claiming to be LXI conformant will be tested when submitted for LXI Compliance Testing.		
Test Procedure	Evaluate Multiple Interfaces		
	Test if only one interface shall be LXI compliant, otherwise query Tester if all interfaces have been tested and are LXI compliant.		



8.0 IPv4 LAN Configuration

Catego	ries	IPv4 DDNS		
8.1	TCP/IP,	UDP, IPv4 Network P	Protocols	
Catego	ry	IPv4, Device Specifica	ation	
Test Typ	ре	Kerberos Test, automated		
Rule		TCP/IP, UDP, IPv4 Network Protocols		
Explana	ation	LXI Devices shall support TCP/IP networking, as outlined in a number of RFCs, including 791 (IP), 793 (TCP), and 768 (UDP). IPv4 shall be supported at a minimum. LXI Devices can be controlled and communicated with using any higher-level protocol (such as RPC), as long as it is built on top of the TCP or UDP transport layers.		
Pre Cor	ndition	Enable IPv4 DHCP ro	uter	
			Enable the dhcp router for IPv4	
		Disconnect DUT		
			Disconnect the DUT from the test network	
Test Pro	ocedure	Start wireshark captu	ıre: Filter "bootp"	
			Start a wireshark capture and set the filter to "bootp", so that only bootp protocol packages are captured	
		Connect DUT		
			Connect the DUT to the test network	
		Stop wireshark captu	re	
			Stop the wireshark from further package capturing	
		Analyse wireshark ca	pture for DHCP packets	
			Analyse the wireshark capture for the presence of DHCP packets	
Post Co	ondition	Get IP from mdns		
			Search via mans for a single ixi service and retrieve its IP address	
8.2	ICMP Pi	ing Responder		
Catego	ry	IPv4, Device Specifica	ation	
Test Typ	be	Kerberos Test, autom	nated	
Rule		ICMP Ping Responder		
Explana	ation	LXI Devices shall support ICMP (Internet Control Message Protocol, used for a Ping Responder) for diagnostics. The TCP/IP stack shall be able to respond to the ICMP echo message used by the ping command. The 'ping ' or 'ping ' command is the standard way to understand whether a user's connection to an Ethernet device is working.		
Pre Cor	ndition	Connect DUT		
			Connect the DUT to the test network	
		Get IP from mdns		
			Search via mdns for a single lxi service and retrieve its IP address	
Test Pro	ocedure	Ping the DUT for suc	Cess	
			Ping the DUT via IPv4 which is expected to succeed	



8.3 IC	MP Ping Responder Enabled by Default		
Category	IPv4, Device Specification		
Test Type	Kerberos Test, manual		
Rule	ICMP Ping Responder Enabled by Default		
Explanation	ICMP Ping service ("Ping Responder") shall be enabled by default.		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
	Disable Ping Responder		
	Prompt the Tester to disable the ICMP Ping Responder		
lest Procedure	Ping the DUT for failure		
	Ping the DOT via IPv4 which is expected to fail.		
	Do LCI The tester is prompted to do a manual LAN reset on the DLIT		
	Ping the DLIT for success		
	Ping the DUT via IPv4 which is expected to succeed		
8.4 Pi	rovide Way to Disable ICMP Ping Responder		
Category	IPv4, Device Specification		
Test Type	Kerberos Test, automated		
Rule	Provide Way to Disable ICMP Ping Responder		
Explanation	LXI Devices shall provide a way to disable the IPv4 ICMP ping responder.		
Test Procedure	Computed by other tests		
	This test is computed by the result of other tests.		
Dependencies	8.3		
8.6 IP	Address Configuration Techniques		
Category	IPv4, Device Specification		
Test Type	Kerberos Test, automated		
Rule	IP Address Configuration Techniques		
Explanation	LXI Devices shall support three LAN configuration techniques: DHCP, Dynamically Configured Link Local Addressing (Auto-IP), and manual. LAN configuration refers to the mechanism that the device uses to obtain IP Address, Subnet Mask, Default Gateway IP Address, and DNS Server IP Address(es).		
	Collectively, DHCP and Dynamically Configured Link Local Addressing are considered automatic configuration methods. These automatic methods may provide additional or supplemental user entries for DNS servers as appropriate.		
	The DHCP and Manual configuration methods provide configuration for:		
	1) module IP address,		
	2) Subnet Mask, 3) Default Gateway IP Address		
	4) DNS server IP addresses.		
Test Procedure	Computed by other tests		
	This test is computed by the result of other tests.		



Dependencies	8.6.1 9.5	
8.6.1 Oj	otions for LAN configuration	
Category	IPv4, Device Specification	
Test Type	Kerberos Test, manual	
Rule	Options for LAN configuration	
Explanation	LXI Devices shall support one of the following options for LAN configuration:	
	A single configuration setting of Automatic (implying DHCP and Dynamically Configured Link Local Addressing) or Manual.	
	Individual configuration settings for: DHCP, Dynamically Configured Link Local Addressing, and Manual. If more than one is enabled, the LXI Device's LAN configuration shall proceed in the following order: 1) DHCP, 2) Dynamically Configured Link Local Addressing, 3) manual	
Pre Condition	S) manual.	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
Test Procedure	Check IPv4 configuration options	
	Prompt the Tester to check configuration options. Either a "Auto/Manual" selection method must be found or a way to individually set DHCP/Dynamically Configured Link-Local/Manual must be available.	
8.6.3 Ex	plicitly Request All Desired DHCP Parameters	
Category	IPv4, Device Specification	
Test Type	Kerberos Test, automated	
Rule	Explicitly Request All Desired DHCP Parameters	
Explanation	LXI Devices shall explicitly request all desired DHCP parameters from the DHCP server. A DHCP client uses the "parameter request list" option to request specific parameter values from a server. The LXI Device DHCP implementation should ensure that parameters like default gateway and subnet mask are in the "parameter request list".	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Disconnect DUT	
TURNEL	Disconnect the DUT from the test network	
lest Procedure	Start wireshark capture: Filter "bootp" Start a wireshark capture and set the filter to "bootp", so that only bootp	
	protocol packages are captured	
	Connect DUT	
	Connect the DUT to the test network	
	Stop Wiresnark capture Stop the wireshark from further package capturing	
	Stop the Micshark nonnarther package capturing	



	Analyse DHCP requ	est packets of wireshark capture Analyse DHCP request packets of the wireshark capture for the parameters - Subnet Mask, - Router - Domain Name Server	
Post Condition	Get IP from mdns	Search via mdns for a single lxi service and retrieve its IP address	
8.6.5 Do	Not Require Additional	DHCP Options for Normal Operations	
Category	IPv4, Device Specifi	cation	
Test Type	Kerberos Test, auto	mated	
Rule	Do Not Require Ad	ditional DHCP Options for Normal Operations	
Explanation	LXI Devices shall no is needed for IP and the LXI Device shall	LXI Devices shall not require any additional DHCP options for normal operations beyond what is needed for IP and DNS configuration. Other options may be requested, but the operation of the LXI Device shall not depend on receiving these parameters.	
Pre Condition	Enable IPv4 DHCP r	router	
		Enable the dhcp router for IPv4	
	Disconnect DUT		
		Disconnect the DUT from the test network	
Test Procedure	Start wireshark capt	ture: Filter "bootp" Start a wireshark capture and set the filter to "bootp", so that only bootp protocol packages are captured	
	Connect DUT		
		Connect the DUT to the test network	
	Stop wireshark capt	ture	
		Stop the wireshark from further package capturing	
	Analyse DHCP ack	packets of wireshark capture	
		Analyse DHCP ack packets of the wireshark capture for the parameters - IP address,	
		- Subnet Mask,	
		- Router - Domain Name Servers	
Post Condition	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
8.6.6 St	op Using IP Address If DI	HCP Lease Not Renewed	
Category	IPv4, Device Specifi	cation	
Test Type	Kerberos Test, auto	mated	
Rule	Stop Using IP Addr	Ston Using IP Address If DHCP Lesse Not Renowed	
Explanation	If an LXI Device is u	If an LXI Device is unable to renew its DHCP lease it shall stop using the DHCP supplied IP	
Pre Condition	Enable IPv4 DHCP	outer	
		Enable the dhcp router for IPv4	
	Disconnect DUT		
		Disconnect the DUT from the test network	



	Connect DUT
	Connect the DUT to the test network
Test Procedure	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	Stop IPv4 DHCP router
	Stop the IPv4 DHCP router, so that no IPv4 DHCP addresses given for lease
	Wait for DUT to loose IPv4
	Depending on the lease time (in general 5min), wait until the IP address is lost
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
8.6.7 Honor	r New DHCP Options at Lease Renewal
Category	IPv4, Device Specification
Test Type	Kerberos Test, automated
Rule	Honor New DHCP Options at Lease Renewal
Explanation	LXI Devices shall honor new DHCP options provided when renewing a lease.
Pre Condition Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4
	Disconnect DUT
	Disconnect the DUT from the test network
	Connect DUT
	Connect the DUT to the test network
Test Procedure	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	Change IPv4 DHCP range router
	Change the range of the IPv4 DHCP server
	Wait for DUT to accept new range
	Depending on the lease time (in general 5min), wait until the IP address has changed
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
8.6.10 Dynan	nic Link-Local Address
Category	IPv4, Device Specification
Test Type	Kerberos Test, automated

Rule Dynamic Link-Local Address



Explanation	LXI Devices shall conform to RFC 3927 Section 2.6.2: If the destination address is a unicast address outside the 169.254/16 prefix and the host (LXI Device) chooses to send the packet with an IPv4 Link-Local source address, then it MUST ARP for the destination address and then send its packet, with an IPv4 Link-Local source address and a routable destination IPv4 address, directly to its destination on the same physical link. The host MUST NOT send the packet to any router for forwarding.		
	In the case of a devic requirement can be	ce with a single interface and only a Link-Local IPv4 address, this paraphrased as "ARP for everything".	
	In many network stac having no primary IP 0.0.0.0, or having the IPv4 address.	cks, achieving this "ARP for everything" behaviour may be as simple as Prouter configured, having the primary IP router address configured to e primary IP router address set to be the same as the host`s own Link-Local	
Pre Condition	Stop IPv4 DHCP rout	ter	
		Stop the IPv4 DHCP router, so that no IPv4 DHCP addresses given for lease	
	Disconnect DUT		
		Disconnect the DUT from the test network	
	Connect DUT		
		Connect the DUT to the test network	
Test Procedure	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	Open web page		
		Open the web page of DUT with IPv4 or IPv6 address, depending on the test.	
8.7 Dupl	icate IP Address Detect	ion	
Category	IPv4		
Test Type	Kerberos Test, manua	al	
Rule	Duplicate IP Address	Duplicate IP Address Detection	
Explanation	LXI Devices shall perform duplicate IP address detection to ensure an LXI Device does not start using an IP address that is already in use on that network. LXI Devices shall disconnect from the network when a duplicate IP address is detected.		
Pre Condition	Connect DUT		
		Connect the DUT to the test network	
Test Procedure	Cause duplicate IP		

Cause the device to issue a duplicate IP warning by setting the device to the same address as the test hardware. This may be done via he webpage LAN configuration or via the devices frontpanel.

Is LAN Status Indicator showing FAULT

Prompt the Tester to check the LAN Status indicator for FAULT.



Evaluate duplicate IP correction

What the device does when it has detected a duplicate address can be one of the following options but whichever method you use the device must not use the duplicate IP address:

1. When the duplicate address has been detected, the device should show an assigned IP address of 0.0.0.0, in the case of IPv4, and show a LAN fault on the LXI LAN Status Indicator.

2. When the duplicate address has been detected, the device can fall back to the currently valid IP address and not show a fault on the LXI LAN Status Indicator.

3. When the duplicate address has been detected the device can fall back to an Auto-IP address (169.254.x.x) and show a fault on the LXI LAN Status Indicator.

8.10 Provide an Error Indicator for LAN Configuration Faults

Category	IPv4, Device Specification		
Test Type	Kerberos Test, manual		
Rule	Provide an Error Indicator for LAN Configuration Faults		
Explanation	LXI Devices shall make use of the LXI LAN Status Indicator to inform the user of a LAN fault or error caused by: o failure to acquire a valid IP address o detection of a duplicate IP address o failure to renew an already acquired DHCP lease (failure to obtain an initial DHCP lease is not		
	a failure) o LAN cable disconnected (as reported by Ethernet connection monitoring)		
	o Entre casic disconnected (as reported by Ethemet connection monitoring)		
	See 2.5.2 LAN Status Indicator for annunciation details.		
	The LXI LAN Status indicator indicates both the LAN error conditions above and provides an identify indication as described in Section 2.5.2. This identifying indication is initiated by the user via the Web interface, Section 9.3, or by the programmatic interface, Section 6.8. The LXI LAN Status indicator shall provide LAN Fault, Normal Operation, and Device Identify indications as shown in the state diagram below. Note that the state labeled "State Undefined" is transitory and the behaviour of the indicator is not specified.		
Pre Condition	Stop IPv4 DHCP router		
	Stop the IPv4 DHCP router, so that no IPv4 DHCP addresses given for lease		
	Disconnect DUT		
	Disconnect the DUT from the test network		
Test Procedure	Is LAN Status Indicator showing FAULT		
	Prompt the Tester to check the LAN Status indicator for FAULT.		
	Connect DUT		
	Connect the DUT to the test network		
	Is LAN Status Indicator showing OK		
	Prompt the Tester to check the LAN Status indicator for OK.		
	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		



	Disconnect DUT	
		Disconnect the DUT from the test network
	Connect DUT	
		Connect the DUT to the test network
	Is LAN Status Indica	ator showing OK
		Prompt the Tester to check the LAN Status indicator for OK.
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	Stop IPv4 DHCP rou	
		Stop the IPv4 DHCP router, so that no IPv4 DHCP addresses given for lease
	Wait for DUT to loc	ose IPv4
		Depending on the lease time (in general 5min), wait until the IP address is lost
	Is LAN Status Indica	ator showing FAULT
		Prompt the Tester to check the LAN Status indicator for FAULT.
	Do LCI	
		The tester is prompted to do a manual LAN reset on the DUT.
	Is LAN Status Indica	ator showing OK
Post Condition		Prompt the lester to check the LAN Status indicator for OK.
Post Condition	Enable IPV4 DHCP r	Enable the data router for IPv4
	Disconnect DUT	
	Disconnect Don	Disconnect the DUT from the test network
	Connect DUT	
		Connect the DUT to the test network
8.11.1.1 If Dy	namic DNS Can Be Dis	abled, Its Default State Is Enabled
Category	DDNS, Device Spec	ification
Test Type	Kerberos Test, man	ual
Rule	If Dynamic DNS Ca	n Be Disabled, Its Default State Is Enabled
Explanation	LXI Devices that allo enabled by default	ow Dynamic DNS to be turned off shall have the Dynamic DNS capability
Pre Condition	Enable IPv4 DHCP r	router
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
Test Procedure	Disable Dynamic DI	NS
		Prompt the tester to disable dynamic DNS
	Disconnect DUT	
	Start wireshark capt	ture: Filter "bootp"
		protocol packages are captured



(Connect DUT	
		Connect the DUT to the test network
9	Stop wireshark captu	re
		Stop the wireshark from further package capturing
	Analyse DHCP reques	st packets for absence of DDNS options
		Analyse DHCP request packets of the wireshark capture for the absence of option 12 and option 83.
I	Do LCI	
		The tester is prompted to do a manual LAN reset on the DUT.
I	Disconnect DUT	
		Disconnect the DUT from the test network
	Start wireshark captu	re: Filter "bootp"
		Start a wireshark capture and set the filter to "bootp", so that only bootp protocol packages are captured
(Connect DUT	
		Connect the DUT to the test network
9	Stop wireshark captu	re
		Stop the wireshark from further package capturing
	Analyse DHCP reques	st packets for presence of DDNS options
		Analyse DHCP request packets of the wireshark capture for the presence of option 12 and option 83
8.13 LAN Cont	figuration Initialize	(LCI)

- CategoryIPv4, Device SpecificationTest TypeKerberos Test, manual
 - Rule LAN Configuration Initialize (LCI)



Explanation	 LXI Devices shall provide a LCI reset mechanism, as defined in 2.4.5, that when activated places the LXI Device's network settings to a default state. These settings shall take effect when the LCI mechanism is activated, without requiring any further operator actions (e.g., if the LXI Device requires a reboot for the changes to take effect, the LXI Device shall reboot automatically). The LXI Device default state shall be fully documented and available in the manufacturer's supplied documentation. If an LXI Device has a manual user interface (physical front panel) that allows the configuration of these items plus the network configuration, then that shall be sufficient to meet the needs addressed by this button, - as long as there is a single LAN Configuration Initialize key in the manual interface that sets the items in the above table as indicated.
	Item Value Section IP address configuration DHCP AutoIP
	Enabled Enabled 8.6 ICMP Ping Responder
	Enabled
	8.3 Web Password for configuration
	Factory Default
	9.8
	Dynamic DNS (if implemented)
	Enabled
	8.11.1.1 mDNS and DNS SD
	Fnabled
	10.2, 10.4, 10.5.1, 10.7.1
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
Test Procedure	Set static IP manually
	Prompt the tester to set a static IP address
	Get IP from mdns
	Search via mons for a single lxi service and retrieve its IP address
	Disable Dynamic DNS
	Prompt the tester to disable dynamic DNS
	Disable mDNS
	Prompt the tester to disable mDNS
	Disable ICMP Ping Responder
	Disable ICMP Fing Responder Prompt the tester to disable ICMP Ding Responder
	rompt the tester to disable form ring responder



<u>)</u> .
р
ed
:



9.0 Web Interface

Categories Web Interface

9.1 W	eb Pages Using W3C Com	pliant Browsers
Category	Web Interface, Devi	ce Specification
Test Type	Kerberos Test, autor	nated
Rule	Web Pages Using W	/3C Compliant Browsers
Explanation	LXI Devices shall ser LXI Device web serv shall conform to HT	ve a HTML web page that works correctly with all W3C compliant browsers. ers shall conform to HTTP (version 1.0 or greater). The HTML pages served ML (version 4.01 or greater) or XHTML (version 1.0 or greater).
Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
Test Procedure	Validate all given we	b pages as W3C compliant Validate all configured web pages as W3C compliant. These web pages are given during the configuration process. If any web pages are missing, reconfigure test data.
9.1.4 HT	TP Transport and Port N	umber
Category	Web Interface, Devi	ce Specification
Test Type	Kerberos Test, autor	nated
Rule	HTTP Transport and	Port Number
Explanation	The default port nur over a TLS connection	mber for the web server shall be 443. The default web server shall use HTTP on, colloquially referred to as HTTPS.
Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
T (D)		Search via mdns for a single lxi service and retrieve its IP address
lest Procedure	Open web page	Open the web page of DUT with IPv4 or IPv6 address, depending on the test.
9.1.7 Al	ias for Welcome Page	
Category	Web Interface	
Test Type	Kerberos Test, manu	al
Rule	Alias for Welcome P	age
Explanation	All LXI Devices shall can be queried via a	provide an alias or redirect for the LXI Welcome Web Page document that GET at: https:///lxi.
Pre Condition	Enable IPv4 DHCP re	outer
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	Search via mdns for a single lxi service and retrieve its IP address



Test Procedure	Query LXI Welcome Page Alias
	Query the LXI Welcome Page Alias from the DUT and ensure it is the correct page. /lxi is the alias for the LXI welcome page.
9.2 We	elcome Web Page Display Items
Category	Web Interface, Device Specification
Test Type	Kerberos Test, manual
Rule	Welcome Web Page Display Items
Explanation	The primary LXI welcome page shall display the following information in a read-only format. o LXI Device Model o Manufacturer o Serial Number o Description o LXI Extended Functions o LXI version o Hostname o MAC Address o TCP/IP Address o Firmware and/or Software Revision
	o LXI Device Address String [VISA]
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
Test Procedure	Open web page in browser
	Prompt tester to open the devices web page
	Query Home Item LXI Device Model
	Prompt tester to check availability of the 'LXI Device Model' on the 'Welcome Web Page'
	Query Home Item Manufacturer
	Prompt tester to check availability of the 'LXI Device Manufacturer' on the 'Welcome Web Page'
	Query Home Item Serial Number
	Prompt tester to check availability of the 'LXI Device Serial Number' on the 'Welcome Web Page'
	Query Home Item Description
	Prompt tester to check availability of the 'LXI Device Description' on the 'Welcome Web Page'
	Query Home Item LXI Extended Functions
	Prompt tester to check availability of the 'LXI Extended Functions' on the 'Welcome Web Page'
	Query Home Item LXI version
	Prompt tester to check availability of the 'LXI Version' on the 'Welcome Web Page'
	Query Home Item Hostname
	Prompt tester to check availability of the 'Hostname' on the 'Welcome Web Page'



	Query Home Item MAC Address
	Prompt tester to check availability of the 'MAC Address' on the 'Welcome Web Page'
	Query Home Item TCP/IP Address
	Prompt tester to check availability of the 'TCP/IP Address' on the 'Welcome Web Page'
	Query Home Item Firmware and/or Software Revision
	Prompt tester to check availability of the 'Firmware and/or Software Revision' on the 'Welcome Web Page'
	Query Home Item LXI Device Address String [VISA]
	Prompt tester to check availability of the 'LXI Device Address String [VISA]' on the 'Welcome Web Page'
9.2.1 LX	I Device Address String on Welcome Page
Category	Web Interface, Device Specification
Test Type	Kerberos Test, manual
Rule	LXI Device Address String on Welcome Page
Explanation	The primary LXI welcome page shall contain an IVI I/O Resource Descriptor (a string such as a VISA Resource Descriptor), which is a string that specifies the address of the hardware asset that can be recognized by the I/O used by a software module that accesses the hardware. An example of such a Resource Descriptor is a VISA Resource
	For VISA Resources of the form
	TCPIP[board]::host address[::LAN device name]::INSTR
	or TCPIP[board]::host address::port::SOCKET The value of "[board]" must be empty since the instrument cannot know which interface board a client may be using.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
Test Procedure	Open web page in browser
	Prompt tester to open the devices web page
	Query Home Item Value LXI Device Address String
	Prompt tester for the 'LXI Device Address String' on the 'Welcome Web Page'
9.2.3 Ac	tual Hostname Display
Category	Web Interface, Device Specification
Test Type	Kerberos Test, manual
Rule	Actual Hostname Display
Explanation	LXI Devices shall display the validated hostname(s) (DNS and/or mDNS) on the LXI Welcome Web page. The hostname(s) displayed on the LAN Configuration page need not be validated since they represent desired configuration values.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address



Test Procedure	Open web page in browser
	Prompt tester to open the devices web page
	Query Home Item Value Hostname
	Prompt tester for the 'Hostname' on the 'Welcome Web Page'
9.2.3.2 Hos	stname Display
Category	Web Interface, Device Specification
Test Type	Kerberos Test, manual
Rule	Hostname Display
Explanation	If an LXI Device does not support recommendation 9.2.3.1 or if mDNS is disabled then it shall show the assigned IP address or a blank field for the hostname.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
T (D)	Search via mdns for a single lxi service and retrieve its IP address
lest Procedure	Disable mDNS
	Prompt tester to open the devices web page
	Ouerv Home Item Value Hostname
	Prompt tester for the 'Hostname' on the 'Welcome Web Page'
9.2.3.3 mD	NS Hostname Format
Category	Web Interface, Device Specification
Test Type	Kerberos Test, manual
Rule	mDNS Hostname Format
Explanation	When displaying an mDNS hostname on the LXI Welcome Web page, the fully qualified mDNS hostname shall be displayed with its domain of .local.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
Test Procedure	Open web page in browser
	Prompt tester to open the devices web page
	Query Home Item Value Hostname Prompt tector for the 'Hostname' on the 'Welcome Web Page'
	Frompt tester for the Hostname on the Welcome web Fage
9.2.3.5 Des	cription Field contains Resolved Service Name
Category	Web Interface, Device Specification
Test Type	Kerberos Test, manual
Rule	Description Field contains Resolved Service Name
Explanation	The unique and resolved service name shall be shown in the description field of the Welcome page defined in section 9.2.
Pre Condition	Connect DUT Connect the DUT to the test network



	Get IP from mdns	
	S	earch via mdns for a single lxi service and retrieve its IP address
Test Procedure	Open web page in brow	wser
	Р	rompt tester to open the devices web page
	Query Home Item Value	e Description
	Р	rompt tester for the 'Description' on the 'Welcome Web Page'
	Get service name from	mdns
	G	et the service name for the device under test from mDNS.
	Disconnect DUT	
	D	isconnect the DUT from the test network
	Register service name f	or Conflict
	R	egister a service name for the device under test to conflict against by ssigning the DUTs servicename to the Kerberos device/IP address.
	Connect DUT	
	C	onnect the DUT to the test network
	Remove service name f	or Conflict
	R	emove the service name registered by the testsuite.
	Get IP from mdns	
	S	earch via mdns for a single lxi service and retrieve its IP address
	Open web page in brow	vser
	Р	rompt tester to open the devices web page
	Query Home Item Value	e Description
	Р	rompt tester for the 'Description' on the 'Welcome Web Page'
9.3 Device	e Identification Functiona	ality on the Web Page
Category	Web Interface, Device S	Specification
Test Type	Kerberos Test, manual	
Rule	Device Identification Fu	nctionality on the Web Page
Explanation	There shall be a device LAN Status Indicator (s	identification indicator functionality on the web page to control the
Pre Condition	Connect DUT	
	C	onnect the DUT to the test network
	Get IP from mdns	
	S	earch via mdns for a single lxi service and retrieve its IP address
Test Procedure	Open web page in brov	vser
	P	rompt tester to open the devices web page
	Activate LAN ID indicat	or
	P	rompt tester to activate the LAN ID indicator on web page
	Is LAN ID indicator activ	ve
	Q	uery tester if LAN ID indicator is showing on device
	Deactivate LAN ID indic	cator
	Ρ	rompt tester to deactivate the LAN ID indicator on web page
	Is LAN ID indicator dea	ctivated
	C	uery tester if LAN ID indicator is not showing on device



9.4	LAN and Sync Configuration Links on the Welcome Page	
Category	Web Interface, Device Specification	
Test Type	Kerberos Test, manual	
Rule	LAN and Sync Configuration Links on the Welcome Page	
Explanation	The Welcome page shall contain at least two hyperlinks/buttons to provide further information or to allow the user to configure LXI Device settings. The first linked web page shall contain the information as described in section 9.5 and the second linked webpage shall contain the information as described in Section 9.6. The second link (Synchronization web page contents) is applicable for LXI Devices implementing any of following LXI Extended Functions: LXI Clock Synchronization (IEEE 1588), LXI Event Messaging, or the LXI Device Wired Trigger Bus. Refer to those external documents for more specific information.	
Pre Conditi	on Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
Test Proced	ure Open web page in browser	
	Prompt tester to open the devices web page	
	Open LAN configuration web page	
	Prompt tester to open the LAN configuration web page	
	Open 1588 Sync configuration web page	
	Prompt tester to open the 1588 Sync configuration web page	
	Open Event Sync configuration web page	
	Prompt tester to open the Event Messaging Sync configuration web page	
	Open WTB Sync configuration web page Prompt tester to open the Wired Trigger Bus Sync configuration web page	
9.5	LAN Configuration Web Page Contents	
Category	Web Interface, Device Specification	
Test Type	Kerberos Test, manual	
Rule	LAN Configuration Web Page Contents	
Explanation	The LAN configuration page shall contain the following parameters to configure the LAN settings: o Hostname o Description o TCP/IP Configuration Mode o Static IP address o Subnet mask o Default Gateway o DNS Server(s) The TCP/IP configuration field controls how the IP address for the instrument is assigned. For the manual configuration mode, the static IP address, subnet mask, and default gateway are used to configure the LAN. The automatic configuration mode uses DHCP server or Dynamic Link Local Addressing (Automatic IP), as described in Rule 8.6 to obtain the instrument IP address.	
Pre Conditi	on Connect DUT	
	Connect the DUT to the test network	



	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
Test Procedure	Open web page in browser		
	Prompt tester to open the devices web page		
	Open LAN configuration web page		
	Prompt tester to open the LAN configuration web page		
	Query LAN Item Hostname		
	Prompt tester to check availability to configure the 'Hostname' on the 'LAN Configuration Web Page'		
	Query LAN Item Description		
	Prompt tester to check availability to configure the 'Description' on the 'LAN Configuration Web Page'		
	Query LAN Item TCP/IP Configuration Mode		
	Prompt tester to check availability to configure the 'TCP/IP Configuratior Mode' on the 'LAN Configuration Web Page'		
	Query LAN Item Static IP address		
	Prompt tester to check availability to configure the 'Static IP address' on the 'LAN Configuration Web Page'		
	Query LAN Item Subnet mask		
	Prompt tester to check availability to configure the 'Subnet mask' on the 'LAN Configuration Web Page'		
	Query LAN Item Default Gateway		
	Prompt tester to check availability to configure the 'Default Gateway' on the 'LAN Configuration Web Page'		
	Query LAN Item DNS Server(s)		
	Prompt tester to check availability to configure the 'DNS Server(s)' on the 'LAN Configuration Web Page'		
9.5.6 mDN	IS Enable/Disable Through Web Page		
Category	Web Interface, Device Specification		
Test Type	Kerberos Test, manual		
Rule	mDNS Enable/Disable Through Web Page		
Explanation	If the LXI Device implements mDNS enable/disable, then it shall be exposed through the web		
	page.		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
Test Procedure	Open web page in browser		
	Prompt tester to open the devices web page		
	Disable mDNS		
	Prompt the tester to disable mDNS		
	Wait for service name to disappear from mdns		
	Wait until the service name has disappeared from mdns.		
	Enable mDNS		
	Prompt the tester to enable mDNS		



Get IP from mdns

Search via mdns for a single lxi service and retrieve its IP address

9.5.7	Reverting Hostname to Factory Default
Category	Web Interface, Device Specification
Test Type	Kerberos Test, manual
Rule	Reverting Hostname to Factory Default
Explanation	Setting the hostname field to the empty string (i.e., a string of length zero, or one consisting entirely of whitespace characters) shall revert the hostname to the factory default value.
Pre Condit	ion Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
Test Procee	dure Get hostname from mdns
	Get the hostname for the device under test from mDNS.
	Open web page in browser
	Prompt tester to open the devices web page
	Open LAN configuration web page
	Prompt tester to open the LAN configuration web page
	Modify hostname
	Prompt tester to modify the hostname to another value
	Get hostname from mdns
	Get the hostname for the device under test from mDNS.
	Open LAN configuration web page Prompt tester to open the LAN configuration web page
	Clear hostname
	Prompt tester to configure hostname to 'empty' or a 'single blank space on the 'LAN Configuration Web Page'
	Get hostname from mdns
	Get the hostname for the device under test from mDNS.
	Is hostname factory default
	Query if the hostname on the welcome page is factory default value
9.5.8	Reverting Device Description to Factory Default
Category	Web Interface, Device Specification
Test Type	Kerberos Test, manual
Rule	Reverting Device Description to Factory Default
Explanation	Setting the Device Description field to the empty string (i.e., a string of length zero, or one consisting entirely of whitespace characters) shall revert the Device Description to the factory default.
Pre Condit	on Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
Test Procee	dure Get service name from mdns
	Get the service name for the device under test from mDNS.



	Open web page in browser
	Prompt tester to open the devices web page
	Open LAN configuration web page
	Prompt tester to open the LAN configuration web page
	Modify service name
	Prompt the tester to modify the service name via the webpage or interface.
	Get service name from mdns
	Get the service name for the device under test from mDNS.
	Open LAN configuration web page
	Prompt tester to open the LAN configuration web page
	Clear service name
	Prompt tester to configure service name to 'empty' or a 'single blank space' on the 'LAN Configuration Web Page'
	Get service name from mdns
	Get the service name for the device under test from mDNS.
	Is service name factory default
	Query if the service name on the welcome page is factory default value
9.6	Sync Configuration Web Page Contents
Category	LXI Clock Synchronization, LXI Event Messaging, LXI Wired Trigger Bus
Test Type	Kerberos Test, manual
Rule	Sync Configuration Web Page Contents



Explanation	For LXI Devices implementing any of the following Extended Functions, the sync configuration web page is required and shall be populated with information as in the table below: LXI Clock Synchronization Extended Function (IEEE 1588) LXI Event Messages Extended Function LXI Wired Trigger Bus Extended Function	
	IEEE 1588 Parameters	
	Current grandmaster clock	
	Hostname, IP address, or MAC address	
	Parent clock	
	Hostname, IP address, or MAC address	
	State Master, Slave, Faulty, Disabled, Passive, Uncalibrated, Other (Initializing, Listening, Pre-master) Current PTP time	
	Seconds since 0 hours, 1 January 1970 TAO (represented as a string of the form "seconds.fractional seconds")	
	Current local time (if available)	
	Date/time	
	Current grandmaster traceability to UTC	
	defined in Table 7 of IEEE 1588 e.g. GPS_NTP_HAND_SET or ATOM	
	Current observed variance of parent clock	
	In (nanoseconds)^2	
	Current source of time	
	String representing clock in use (e.g. IEEE-1588 PTP)	
	IEEE 1588 Domain The integer, domainNumber, as defined by IEEE 1588	
	IFEE 1588 Version	
	The integer, versionNumber, as defined by IEEE 1588, e.g. 2 for IEEE 1588-2008.	
	LXI Event Parameters	
	LXI Domain	
	As defined in Section 4 of the LXI Event Messaging Extended Function document. LXI Wired Trigger Bus Parameters	
	Wired-Or Bias	
	Enabled or Disabled(default) for each LXI0 to LXI7	
Pre Condition		
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mons for a single ly service and retrieve its IP address	
Test Procedure	Open web page in browser	
lest rocedure	Open web page in blowser Prompt tester to open the devices web page	
	Open 1599 Sums configuration web page	
	Open 1500 Sync configuration web page Prompt tester to open the 1588 Sync configuration web page	
	Quary 1599 Sync Itom Grandmaster Clack	
	Query 1566 Sync item Grandmaster Clock	
	'1588 Sync Configuration Web Page'	



	Query 1588 Sync Ite	m Parent Clock
		Prompt tester to check availability of the 'Parent Clock' on the '1588 Sync Configuration Web Page'
	Query 1588 Sync Ite	m State
		Prompt tester to check availability of the 'State' on the '1588 Sync Configuration Web Page'
	Query 1588 Sync Ite	m PTP Time
		Prompt tester to check availability of the 'PTP Time' on the '1588 Sync Configuration Web Page'
	Query 1588 Sync Ite	m Local Time
		Prompt tester to check availability of the 'Local Time' on the '1588 Sync Configuration Web Page'
	Query 1588 Sync Ite	m Traceability To UTC
		Prompt tester to check availability of the 'Traceability To UTC' on the '1588 Sync Configuration Web Page'
	Query 1588 Sync Ite	m Observed Variance
		Prompt tester to check availability of the 'Observed Variance' on the '1588 Sync Configuration Web Page'
	Query 1588 Sync Ite	m Time Source
		Prompt tester to check availability of the 'Time Source' on the '1588 Sync Configuration Web Page'
	Query 1588 Sync Ite	m Domain
		Prompt tester to check availability of the 'Domain' on the '1588 Sync Configuration Web Page'
	Query 1588 Sync Ite	m Version
		Prompt tester to check availability of the 'Version' on the '1588 Sync Configuration Web Page'
	Open Event Sync co	nfiguration web page
		Prompt tester to open the Event Messaging Sync configuration web page
	Query Event Sync Ite	em Domain
		Prompt tester to check availability of the 'Domain' on the 'Event Sync Configuration Web Page'
	Open WTB Sync con	figuration web page
		Prompt tester to open the Wired Trigger Bus Sync configuration web page
	Query WTB Sync Iter	n WiredOr Bias
		Prompt tester to check availability of the 'Wired-Or Bias' on the 'WTB Sync Configuration Web Page'
Web Pa	ge Password Protect	ion
	Web Interface, Devic	e Specification
	Kerberos Test, manu	al
	Web Page Password	Protection
	Any page(s) that allo user changeable def	ows user to change the instrument's settings shall be password protected; ault passwords are acceptable. Blank passwords are forbidden.

Pre Condition Connect DUT

9.8

Category Test Type Rule

Explanation

Connect the DUT to the test network



	Get IP from mdns		
	Search via r	ndns for a single lxi service and retrieve its IP address	
Test Procedure	Open web page in browser		
	Prompt test	er to open the devices web page	
	Open LAN configuration web page	le	
	Prompt test	er to open the LAN configuration web page	
	Is password requested		
	Query if pa be on load, requested c cahnged da	sword was requested when opening the web page. This may meaning that before the webpage is shown a password is or on submit where the password is first requested once tat is submitted to the device, e.g. via submit button.	
	Open 1588 Sync configuration we	eb page	
	Prompt test	er to open the 1588 Sync configuration web page	
	ls password requested		
	Query if pas be on load, requested c cahnged da	sword was requested when opening the web page. This may meaning that before the webpage is shown a password is or on submit where the password is first requested once tat is submitted to the device, e.g. via submit button.	
	Open Event Sync configuration w	eb page	
	Prompt test	er to open the Event Messaging Sync configuration web page	
	Is password requested		
	Query if pas be on load, requested c cahnged da	ssword was requested when opening the web page. This may meaning that before the webpage is shown a password is or on submit where the password is first requested once tat is submitted to the device, e.g. via submit button.	
	Open WTB Sync configuration we	b page	
	Prompt test page	er to open the Wired Trigger Bus Sync configuration web	
	Is password requested		
	Query if pas be on load, requested c cahnged da	sword was requested when opening the web page. This may meaning that before the webpage is shown a password is or on submit where the password is first requested once tat is submitted to the device, e.g. via submit button.	
	Open Any Other configuration web pages		
	Prompt test settings	er to open any other web pages which can change device	
	ls password requested		
	Query if pas be on load, requested of cohomod da	sword was requested when opening the web page. This may meaning that before the webpage is shown a password is or on submit where the password is first requested once	
	Cannyed da		
	Prompt test on the web	er to modify the password, either on the device or if available page	
	Open LAN configuration web page	le	
	Prompt test	er to open the LAN configuration web page	



	ls password requested		
	Query if passw be on load, m requested or c cahnged data	ord was requested when opening the web page. This may eaning that before the webpage is shown a password is on submit where the password is first requested once is submitted to the device, e.g. via submit button.	
	Open 1588 Sync configuration web	page	
	Prompt tester	to open the 1588 Sync configuration web page	
	Is password requested		
	Query if passw be on load, m requested or c cahnged data	ord was requested when opening the web page. This may eaning that before the webpage is shown a password is on submit where the password is first requested once is submitted to the device, e.g. via submit button.	
	Open Event Sync configuration web	page	
	Prompt tester	to open the Event Messaging Sync configuration web page	
	ls password requested		
	Query if passw be on load, m requested or c cahnged data	ord was requested when opening the web page. This may eaning that before the webpage is shown a password is on submit where the password is first requested once is submitted to the device, e.g. via submit button.	
	Open WTB Sync configuration web	bage	
	Prompt tester page	to open the Wired Trigger Bus Sync configuration web	
	ls password requested		
	Query if passw be on load, m requested or c cahnged data	ord was requested when opening the web page. This may eaning that before the webpage is shown a password is on submit where the password is first requested once is submitted to the device, e.g. via submit button.	
	Open Any Other configuration web	pages	
	Prompt tester settings	to open any other web pages which can change device	
	ls password requested		
	Query if passw be on load, m requested or c cahnged data	ord was requested when opening the web page. This may eaning that before the webpage is shown a password is on submit where the password is first requested once is submitted to the device, e.g. via submit button.	
	Logo		
Category	Web Interface, Device Specification		
Test Type	Kerberos Test, manual		
Rule	LXI Logo		
Explanation	All the required web pages for an L Trademark and Logo Usage Guidelir	All the required web pages for an LXI Device shall contain the LXI Logo (see LXI Consortium Trademark and Logo Usage Guidelines).	
Pre Condition	Connect DUT		
	Connect the D	UT to the test network	
	Get IP from mdns		
	Search via md	ns for a single lxi service and retrieve its IP address	
Test Procedure	Open web page in browser		

Prompt tester to open the devices web page

9.9



	Is LXI Logo on web page
	Query if LXI Logo is on the web page
	Open LAN configuration web page
	Prompt tester to open the LAN configuration web page
	Is LXI Logo on web page
	Query if LXI Logo is on the web page
	Open 1588 Sync configuration web page
	Prompt tester to open the 1588 Sync configuration web page
	Is LXI Logo on web page
	Query if LXI Logo is on the web page
	Open Event Sync configuration web page
	Prompt tester to open the Event Messaging Sync configuration web page
	Is LXI Logo on web page
	Query if LXI Logo is on the web page
	Open WTB Sync configuration web page
	Prompt tester to open the Wired Trigger Bus Sync configuration web page
	Is LXI Logo on web page
	Query if LXI Logo is on the web page
	Open logging web page
	Prompt tester to open the logging web page
	Is LXI Logo on web page
	Query if LXI Logo is on the web page
	Open LANv6 configuration web page
	Prompt tester to open the IPv6 LAN configuration web page
	Is LXI Logo on web page
	Query if LXI Logo is on the web page
4 All U	JRLs Beginning With "LXI" Are Reserved by the LXI Consortium
Category	Web Interface
Test Type	Vendor Declaration
Rule	All URLs Beginning With "LXI" Are Reserved by the LXI Consortium
Explanation	RFC 1738 defines the HTTP URL as the following: http:// <host>:Any URL with a that begins with the strings 'lxi' or 'LXI' or any combination of lowercase and uppercase letters combined to spell LXI are reserved for Consortium-defined uses. This includes the directory-like syntax in which the first part of is any combination of lowercase and uppercase letters that spell LXI terminated with a '/': http://<host>:<port>/lxi/<path>?<searchpart></searchpart></path></port></host></host>

9.14



10.0	LAN Disco	very and Identification
Cate	egories	mDNS Identification
10.1	Suppo	rt VXI-11 Discovery Protocol
Cate	egory	LXI VXI-11 Discovery and Identification
Test	Туре	Kerberos Test, automated
Rule	9	Support VXI-11 Discovery Protocol
Expl	anation	The VXI-11 protocol should be supported by all LXI Devices for discovery purposes. If an LXI Device supports the VXI-11 Discovery Protocol, it shall be accomplished by issuing a broadcast RPC call on the host's subnet. The broadcast RPC shall be to either the port-mapper itself on port 111 (querying for VXI-11 support) or the NULL procedure (procedure 0) on the Program Number assigned to the VXI-11 Core Service (0x0607AF).
Pre	Condition	Connect DUT
		Connect the DUT to the test network
		Get IP from mdns
Test	Due ee duure	Search via mons for a single IXI service and retrieve its IP address
Test	Procedure	Discover DUT via VXI-TT Discover the device under test (DUT) using the VXI-11 protocol
		Evaluate VXI-11 Discovery response
		Evaluate the responses received from the VXI-11 Discovery. During testing only one device should be found, the device under test (DUT).
10.1.1	VXI-1	Servers Respond Within One Second
Cate	egory	LXI VXI-11 Discovery and Identification
Test	Туре	Kerberos Test, automated
Rule	9	VXI-11 Servers Respond Within One Second
Expl	anation	If the VXI-11 discovery protocol is supported, it shall respond to a broadcast RPC to the NULL procedure within 1 second.
Pre	Condition	Connect DUT
		Connect the DUT to the test network
		Get IP from mdns
Test	Due ee duue	Search via mons for a single IXI service and retrieve its IP address
lest	Procedure	Discover DUT via VXI-TT Discover the device under test (DUT) using the VXI-11 protocol
		Evaluate VXI-11 Discovery response time
		Evaluate the time frame from when the VXI-11 discovery was initiated until the device responded. This should not be more than 1 second.
10.1.2	SCPI *	IDN?
Cate	egory	LXI VXI-11 Discovery and Identification
Test	Туре	Kerberos Test, automated

SCPI *IDN?

Rule



Explanation	If the LXI Device support the VXI-11 Discovery Protocol at a minimum an LXI Device that supports VXI-11 shall be able to respond to the IEEE 488.2 '*IDN?' command. This is a simple query that returns four comma-separated fields, which indicate manufacturer, model, serial number, and firmware version.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	Establish VXI-11 connection
	Establish a connection to the DUT using the VXI-11 protocol.
Test Procedure	Send '*IDN?' command over VXI-11
	Send a '*IDN?'-request via the VXI-11 protocol to the device under test (DUT).
	Evaluate VXI-11 response
	Evaluate the response to a send command which was received via the VXI-11 protocol.
10.1.3 Inc	ude 'LXI VXI-11 Discovery and Identification' in Welcome Web Page "LXI Extended Functions"
Category	LXI VXI-11 Discovery and Identification
Test Type	Kerberos Test, automated
Rule	Include 'LXI VXI-11 Discovery and Identification' in Welcome Web Page "LXI Extended Functions"
Explanation	Devices implementing the LXI VXI-11 Discovery and Identification extended function shall include 'LXI VXI-11 Discovery and Identification' in the 'LXI Extended Functions' display item of the welcome web page.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	1.4.6
10.1.4 Incl	ude the LXI VXI-11 Function in the <lxiextendedfunctions> element</lxiextendedfunctions>
Category	LXI VXI-11 Discovery and Identification
Test Type	Kerberos Test, automated
Rule	Include the LXI VXI-11 Function in the <lxiextendedfunctions> element</lxiextendedfunctions>
Explanation	LXI devices implementing VXI-11 Discovery and Identification extended function shall include a element in the XML element with the FunctionName attribute of "LXI VXI-11 Discovery and Identification" and a Version attribute containing the version number of the documentation.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	10.2.5
10.2 XM	L Identification Document
Category	Identification, Device Specification
Test Type	Kerberos Test, automated
Rule	XML Identification Document



Explanation	All LXI Devices shall provide an XML identification document that can be queried via a GET at "http://:/lxi/identification" that conforms to the LXI XSD Schema (available at http:// www.lxistandard.org/InstrumentIdentification/1.0) and the W3C XML Schema Standards (http:// www.w3.org/XML/Schema).
Pre Condition	Connect DUT
	Connect the DUT to the test network
Test Procedure	Get identification file
	Get the identification file from the device under test
	Validate identification file
	Validate the identification file from the device under test
10.2.2 Cont	ent Type Header
Category	Identification, Device Specification
Test Type	Kerberos Test, automated
Rule	Content Type Header
Explanation	The response to the GET request on the URL defined in 10.2 or to the URL that actually returns the XML document after possible redirection(s) shall include the "Content-Type" header with "text/xml" as the value.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get identification file
	Get the identification file from the device under test
Test Procedure	Validate Content header Validate the identification files content header for type : "text/xml"
10.2.3 Sche	ma Location Attribute
Category	Identification, Device Specification
Test Type	Kerberos Test, automated
Rule	Schema Location Attribute
Explanation	The xsi:schemaLocation attribute of the root element of the identification document shall contain an entry for the LXI XSD namespace with an accompanying absolute URI on the instrument that shall return the actual XSD schema document from the instrument (https://www.w3.org/standards/xml/schema). The W3C XSD Schema itself does not need to be available via a URI on the instrument. Example:
Des Condition	LXIDevice xmlns="http://www.lxistandard.org/InstrumentIdentification/1.0" xmlns:xsi="http:// www.w3.org/2001/XMLSchema-instance" xsi:schemaLocation="http://www.lxistandard.org/ InstrumentIdentification/1.0 http://1.2.3.4/identification.xsd">
Pre Condition	Connect DUI
	Get identification file
	Get the identification file from the device under test
Test Procedure	Validate Schema Location
	Validate the identification files Schema Location



10.2.4	Connected Device URLs
Category	Identification, Device Specification
Test Type	Kerberos Test, automated
Rule	Connected Device URLs
Explanation	Devices that support connected devices (e.g., bridges) shall provide base URLs for all connected devices in the ConnectedDevices element of the identification document. A base URL is defined as a URL with a "url-path" that clearly identifies the connected device and one onto which a suffix path may be added to access properties of that connected device. The base URL allows clients to enumerate devices connected to the bridge device. For example, the base URL for a connected device might be "http://hostname/device0" while another connected device might have a base URL of "http://hostname/device5". The format and path naming conventions for these connected device base URLs are left up to the vendor. The following is an example snippet from an identification document with connected device DeviceURI elements: http://10.1.2.60/devices/LogicalAddress/0/ http://10.1.2.60/devices/LogicalAddress/1/
Pre Conditi	on Connect DUT
	Connect the DUT to the test network
	Get identification file
	Get the identification file from the device under test
Test Proced	lure Get Connected Devices
	Get the connected devices from the identification file of the device under test
	Get identification files for Connected Devices Get the connected devices identification files of the device under test
10.2.4.1	Connected Device XML Identification Document URLs
Category	Identification, Device Specification
Test Type	Kerberos Test, automated
Rule	Connected Device XML Identification Document URLs
Explanatior	Devices that support connected devices shall provide identification documents that can be queried via a GET on /lxi/identification that conform to the LXI XSD Schema or one derived from that Schema according to the rules of XSD inheritance. The values may be found in DeviceURI elements of the ConnectedDevice element of the root element of the identification document of Rule 10.2. This rule coupled with Rule 10.2.4 allows clients to enumerate (discover) and identify all connected devices.
Pre Conditi	on Connect DUT
	Connect the DUT to the test network
	Get identification file
	Get the identification file from the device under test
	Get Connected Devices Get the connected devices from the identification file of the device under test
Test Proced	lure Validate identification files for Connected Devices
	Get the connected devices identification files of the device under test



10.2.4.2	Connected Device XML Identification Document Schema Location Attribute
Category	Identification, Device Specification
Test Type	Kerberos Test, automated
Rule	Connected Device XML Identification Document Schema Location Attribute
Explanation	The xsi:schemaLocation attribute of the root element of the identification document shall contain an entry for the LXI XSD namespace with an accompanying absolute URI on the instrument that shall return the actual XSD schema document from the instrument (https://www.w3.org/standards/xml/schema)). The W3C XSD Schema itself does not need to be available via a URI on the instrument.
Pre Conditio	n Connect DUT
	Connect the DUT to the test network
	Get identification file
	Get the identification file from the device under test
	Get Connected Devices Get the connected devices from the identification file of the device under test
Test Procedu	Validate schema location for Connected Devices Validate the schema locations of the connected devices given by their identification files
10.2.5	LXI Extended Function Elements
Category	Identification, Device Specification
Test Type	Kerberos Test, automated
Rule	LXI Extended Function Elements
Explanation	Devices that support LXI Extended Functions shall provide Function elements within the LXIExtendedFunctions element, and a string containing the version number specifying the implementation of that extended function. In addition, some extended functions may provide additional information within their Function element. This allows clients to enumerate the set of extended functions associated with the device.
Pre Conditio	n Connect DUT
	Connect the DUT to the test network
	Get identification file
	Get the identification file from the device under test
Test Procedu	Ire Validate Extended Functions
	Validate the Extended Functions given by the identification file
10.3	Support mDNS
Category	mDNS, Device Specification
Test Type	Kerberos Test, automated
Rule	Support mDNS
Explanation	LXI Devices shall support Multicast DNS (mDNS) as defined by RFC6762 and RFC6763
Test Procedu	re Computed by other tests

This test is computed by the result of other tests.



Dependencies	10.3.1 10.3.1.1 10.3.3 10.3.4
10.3.1 Clai	ming Hostnames
Category	mDNS, Device Specification
Test Type	Kerberos Test, automated
Rule	Claiming Hostnames
Explanation	LXI Devices shall assign themselves an mDNS hostname and shall automatically resolve mDNS hostname conflicts.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
T (D)	Connect the DUT to the test network
lest Procedure	Get hostname from mdns
	Get the hostname for the device under test norm mbhs.
10.3.1.1 Hos	tname Conflicts
Category	mDNS, Device Specification
Test Type	Kerberos Test, automated
Rule	Hostname Conflicts
Explanation	If an mDNS hostname conflict occurs, the LXI Device shall assign itself a new hostname and retry until the conflict is resolved. New hostnames shall be generated by appending a number to the end of the hostname. For example, a conflict on "Instr-ABC" would become "Instr-ABC-2" after the first collision, "Instr-ABC-3" on the second, and so on.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
Test Procedure	Get hostname from mdns
	Get the nostname for the device under test from mDNS.
	Disconnect the DUT from the test network
	Register hostname for Conflict
	Register a hostname for the device under test to conflict against by assigning the DUTs hostname to the Kerberos device/IP address.
	Connect DUT
	Connect the DUT to the test network
	Get hostname from mdns
	Get the hostname for the device under test from mDNS.
	Evaluate for resolved hostname Evaluate the hostname retrieved from mdns has resolved after creating a conflict.
Post Condition	Remove hostname for Conflict Remove the hostname registered by the testsuite.



10.3.3	Dynamic	: DNS Update and mDNS Hostname
Category		DDNS, Device Specification
Test Type		Kerberos Test, automated
Rule		Dynamic DNS Update and mDNS Hostname
Explanatio	n	LXI Devices that support Dynamic DNS Update shall use the user-configured hostname as the mDNS hostname.
Test Procee	dure	Computed by other tests
		This test is computed by the result of other tests.
Dependen	cies	10.3.4
10.3.4	DHCP "H	lost Name" Option and mDNS Hostname
Category		mDNS, Device Specification
Test Type		Kerberos Test, manual
Rule		DHCP "Host Name" Option and mDNS Hostname
Explanatio	n	Regardless of any value, a DHCP server may return as the DHCP "Host Name" option (option code 12); an LXI Device shall use the user configured or factory default hostname for mDNS hostname registration. (See Section 10.7)
Test Proced	dure	Open web page
		Open the web page of DUT with IPv4 or IPv6 address, depending on the test.
		Compare hostname on Welcome Page and Configuration Page
		Compare hostname on Welcome Page and Configuration Page. The welcome page should match the Configuration page hostname entry with an added ".local." suffix.
10.4	Support	mDNS Service Discovery
Category		mDNS, Device Specification
Test Type		Kerberos Test, automated
Rule		Support mDNS Service Discovery
Explanatio	n	LXI Devices shall support shall support Service discovery based on mDNS and DNS as defined by RFC6762 (Multicast mDNS) and RFC6763 (DNS based Service Discovery).
Test Procee	dure	Computed by other tests
		This test is computed by the result of other tests.
Dependen	cies	10.4.1 10.4.2 10.4.2.3
10.4.1	Claiming	J Service Name
Category		mDNS, Device Specification
Test Type		Kerberos Test, automated
Rule		Claiming Service Name
Explanatio	n	LXI Devices shall assign themselves a service name used to advertise services defined within this standard and shall automatically resolve service name conflicts.
Pre Condit	ion	Enable IPv4 DHCP router

Enable the dhcp router for IPv4


	Connect DUT	
	Connect the DUT to the test network	
Test Procedure	Get service name from mdns	
	Get the service name for the device under test from mDNS.	
10.4.2 Sing	gle Service Instance Name for LXI Defined Services	
Category	mDNS	
Test Type	Kerberos Test, automated	
Rule	Single Service Instance Name for LXI Defined Services	
Explanation	LXI Devices shall assign themselves a single service name for use in advertising all required and recommended LXI services, as below, and shall resolve service name conflicts. The service instance name is the "instance" portion of a service name as follows:	
	 Thus, an HTTP service with an instance name of "Instrument ABC" in the ".local" domain will have "Instrument ABChttptcp.local" as the service name.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get service name from mdns	
Test Due se dune	Get the service name for the device under test from mDNS.	
lest Procedure	Validate service name against all registered services All registered services for the device under test must have matching service-names.	
10.4.2.1 Use	r Configurable Service Name	
Category	mDNS, Device Specification	
Test Type	Kerberos Test, manual	
Rule	User Configurable Service Name	
Explanation	LXI Devices shall allow a user to modify the non-volatile service name via the web interface, truncated to the first 63 bytes of UTF-8. When a user modifies a service name, the LXI Device shall unregister all services and then reregister using the new service name.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
Test Procedure	Get service name from mdns	
	Get the service name for the device under test from mDNS.	
	Modify service name	
	Prompt the tester to modify the service name via the webpage or interface.	
	Get service name from mdns	
	Get the service name for the device under test from mDNS.	
	Query tester if new service name is the modified service name	
	Prompt the tester to inquire whether the new service name is the recently entered modified service name.	



10.4.2.3 Serv	vice Name Conflicts		
Category	mDNS, Device Specification		
Test Type	Kerberos Test, automated		
Rule	Service Name Conflicts		
Explanation	If an mDNS service name conflict occurs, the LXI Device shall assign itself a new service name and retry until the conflict is resolved. New service names shall be generated by appending a number to the end of the service name. For example, a conflict on "Vendor Instrument" would become "Vendor Instrument (2)" after the first collision, "Vendor Instrument (3)" on the second, and so on.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
Test Procedure	Get service name from mdns		
	Get the service name for the device under test from mDNS.		
	Disconnect DUI		
	Disconnect the DOT from the test network		
	Register service name for the device under test to conflict against by		
	assigning the DUTs servicename to the Kerberos device/IP address.		
	Connect DUT		
	Connect the DUT to the test network		
	Get service name from mdns		
	Get the service name for the device under test from mDNS.		
	Evaluate for resolved servicename		
	a conflict.		
Post Condition	Remove service name for Conflict		
	Remove the service name registered by the testsuite.		
10.4.3 Req	uired Service Advertisements and TXT Record Keys		
Category	mDNS, Device Specification		
Test Type	Kerberos Test, automated		
Rule	Required Service Advertisements and TXT Record Keys		
Explanation	LXI Devices shall, at a minimum, advertise the following services via mDNS and shall provide the related keys in the TXT records for the service. Please refer to 10.4.3.5 for Permission on TXT Record Keys with default values. _httptcp txtvers=1 path=/ (default values) _lxitcp txtvers=1 Manufacturer= Model= SerialNumber= FirmwareVersion=		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
Test Procedure	Get txt records from required services from mdns Get the txt records from the required services: _lxitcp and _httptcp		



	Validate txt records	
	Validate the given txt records for required keys	
10.4.3.1 TX	(T Records Are Required	
Category	mDNS, Device Specification	
Test Type	Kerberos Test, automated	
Rule	TXT Records Are Required	
Explanation	The LXI Device shall provide a TXT record for every service instance being advertised. If there are no TXT record entries for a service (see Permission 10.4.3.5), an empty TXT record shall be provided.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
Test Procedure	Get txt records for all advertised services from mdns Get the txt records from all services advertised by the device under test: _httptcp _lxitcp _hisliptcp _scpi-rawtcp _scpi-telnettcp	
	Validate txt records	
	Validate the given txt records for required keys	
10.4.3.2 TX	(T Records Consist of Key/Value Pairs	
Category	mDNS, Device Specification	
Test Type	Kerberos Test, automated	
Rule	TXT Records Consist of Key/Value Pairs	
Explanation	TXT records shall consist of key/value pairs of the form "name=value" (without quotes). The value begins after the first ASCII equal sign "=" and continues to the end of the string. The maximum length of a key/value pair is 255 bytes.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
Tost Drocoduro	Connect the DOT to the test network	
lest Procedure	Get txt records for all advertised services from mons Get the txt records from all services advertised by the device under test: _httptcp _hisliptcp _scpi-rawtcp _vxi-11tcp scpi-telnet. tcp	
	Validate txt record entries	
	Validate the given txt records for key/value entries. The maximum length is 255 bytes. name=value	



10.4.3.3	TXT Record Keys Are Case-Insensitive ASCII	
Category	mDNS, Device Specification	
Test Type	Kerberos Test, automated	
Rule	TXT Record Keys Are Case-Insensitive ASCII	
Explanation	All TXT record keys (names) shall be printable ASCII characters (0x20-0x7E), excluding "=" (0x3D), and shall be case-insensitive.	
Pre Conditi	on Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
Test Proced	ure Get txt records for all advertised services from mdns	
	Get the txt records from all services advertised by the device under test: _httptcp _lxitcp _scpi-rawtcp _vxi-11tcp _scrpi-telpet_tcp	
	Validate tyt record keys	
	Validate the given txt records keys for printable ASCII characters (0x20-0x7E), excluding "=" (0x3D) and shall be case-insensitive.	
10.4.3.4	TXT Record Values	
Category	mDNS, Device Specification	
Test Type	Kerberos Test, automated	
Rule	TXT Record Values	
Explanation	TXT record values (data beginning after the ASCII equal sign "=" [0x3D]) in general shall be opaque binary data, but may be ASCII or UTF-8 for particular keys.	
Pre Conditi	on Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
Iest Proced	Get txt records for all advertised services from mdns Get the txt records from all services advertised by the device under test: _httptcp _lxitcp _hisliptcp _scpi-rawtcp _scpi-telnettcp Validate txt record values	
	Validate the given txt records values for opaque binary data, but may be	
	ASCII or UTF-8 for particular keys.	
10.4.3.6	TXT Record Key Order	

- Category mDNS, Device Specification
- Test Type Kerberos Test, automated



Rule	TXT Record Key Order	
Explanation	For any service that has a defined TXT record key of "txtvers" the "txtvers" key, if present, shall be the first key in the TXT record.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
Test Procedure	Get txt records for all advertised services from mdns	
	Get the txt records from all services advertised by the device under test: _httptcp _lxitcp	
	_hisliptcp	
	vxi-11. tcp	
	_scpi-telnettcp	
	Validate txt record order	
	Validate the given txt records that, if present, the key "txtvers" is the first TXT record.	
10.4.3.7 LXI C	onsortium TXT Record Keys	
Category	mDNS, Device Specification	
Test Type	Kerberos Test, automated	
Rule	LXI Consortium TXT Record Keys	
Explanation	All TXT record keys beginning with "LXI" or "lxi" are reserved for Consortium-defined usage.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
Test Procedure	Get txt records for all advertised services from mdns	
	Get the txt records from all services advertised by the device under test: _httptcp _vi_tcn	
	_ixiucp hislin_tcn	
	scpi-rawtcp	
	_vxi-11tcp	
	_scpi-telnettcp	
	Validate txt record lxi keys	
	Validate the given txt records that none start with the reserved beginnings of "LXI" or "lxi"	
10.4.3.8 Vend	or Defined TXT Record Keys	
Category	mDNS, Device Specification	
Test Type	Kerberos Test, automated	
Rule	Vendor Defined TXT Record Keys	



Explanation	All TXT record keys (names) used with LXI Consortium required or recommended services shall be either keys (names) as defined by this standard or vendor-specific keys. Vendor-specific keys shall end with the vendor's domain name in accordance with section 6.4 of http://files.dns- sd.org/draft-cheshire-dnsext-dns-sd.txt. That is, vendor-defined keys shall be of the form "keyname.company.com=."		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
Test Procedure	Get txt records for all advertised services from mdns		
	Get the txt records from all services advertised by the device under test: _httptcp _hisliptcp _scpi-rawtcp _vxi-11tcp		
	_scpi-temet_tcp		
	Validate txt record vehiclor keys Validate the given txt records that vendor keys are formatted as following: "keyname.company.com="		
10.5 mDNS	and DNS-SD Enabled by Default		
Category	mDNS, Device Specification		
Test Type	Kerberos Test, automated		
Rule	mDNS and DNS-SD Enabled by Default		
Explanation	Both mDNS and DNS-SD shall be enabled by default on LXI Devices.		
Test Procedure	Computed by other tests		
	This test is computed by the result of other tests.		
Dependencies	10.3 10.4		
10.5.1 mDNS	and DNS-SD Enabled by LAN Configuration Initialize (LCI)		
Category	mDNS, Device Specification		
Test Type	Kerberos Test, manual		
Rule	mDNS and DNS-SD Enabled by LAN Configuration Initialize (LCI)		
Explanation	When the LCI reset mechanism is activated, it shall enable mDNS and DNS-SD.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get hostname from mdns		
	Get the hostname for the device under test from mDNS.		
	Get service name from mdns		
	Get the service name for the device under test from mDNS.		
	Disable mDNS		
	Prompt the tester to disable mDNS		



	Wait for service name to disappear from mdns	
	Wait until the service name has disappeared from mdns.	
Test Procedure	Do LCI	
	The tester is prompted to do a manual LAN reset on the DUT.	
	Get hostname from mons	
	Get the hostilane for the device under test non-mons.	
	Get the service name for the device under test from mDNS.	
10.5.2 Prov	ride way to Disable mDNS and DNS-SD	
Category	mDNS, Device Specification	
Test Type	Kerberos Test automated	
Rule	Provide way to Disable mDNS and DNS-SD	
Explanation	Devices shall provide a way to enable and disable mDNS and DNS-SD	
Test Procedure	Computed by other tests	
lest roccure	This test is computed by the result of other tests.	
Dependencies	9.5.6	
10.6 mDN	S Name Resolution	
Category	mDNS	
Test Type	Vendor Declaration	
Rule	mDNS Name Resolution	
Explanation	LXI Devices shall use mDNS for name resolution of hostnames in the ".local." domain. Reverse lookups of addresses in the 169.254/16 subnet (Dynamic Link-Local Addresses) shall be resolved via mDNS.	
10.7 Non	volatile Hostnames and Service Names	
Category	mDNS, Device Specification	
Test Type	Kerberos Test, manual	
Rule	Nonvolatile Hostnames and Service Names	
Explanation	To promote stability, if a hostname conflict occurs and the LXI Device chooses a new hostname, the device shall save the new hostname in nonvolatile storage for use the next time the device is powered on. Similarly, if a service name conflict occurs and the LXI Device chooses a new service name, it shall save the new service name in nonvolatile storage for use the next time the device is powered on.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get hostname from mdns	
	Get the hostname for the device under test from mDNS.	
	Get the convice name for the device under test from mDNS	
	Disconnect DUT	
	Disconnect the DUT from the test network	



	Register hostname for Conflict	
	Register a hostname for the device under test to conflict against by assigning the DUTs hostname to the Kerberos device/IP address.	
	Register service name for Conflict	
	Register a service name for the device under test to conflict against by assigning the DUTs servicename to the Kerberos device/IP address.	
	Connect DUT	
	Connect the DUT to the test network	
	Remove hostname for Conflict	
	Remove the hostname registered by the testsuite.	
	Remove service name for Conflict	
	Remove the service name registered by the testsuite.	
Test Procedure	Get hostname from mdns	
	Get the hostname for the device under test from mDNS.	
	Get service name from mdns	
	Get the service name for the device under test from mDNS.	
	Cycle power on device	
	Prompt the tester to cycle the power on the device.	
	Get hostname from mdns	
	Get the hostname for the device under test from mDNS.	
	Get service name from mdns	
	Get the service name for the device under test from mDNS.	
10.7.1 Host	name and Service Name Revert to Default	
Category	mDNS, Device Specification	
Test Type	Kerberos Test, manual	
Rule	Hostname and Service Name Revert to Default	
Explanation	When the LCI mechanism is activated, the hostname and the service name shall revert to th last user-configured values, if available, or factory defaults otherwise.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get hostname from mdns	
	Get the hostname for the device under test from mDNS.	
	Get service name from mdns	
	Get the service name for the device under test from mDNS.	
	Disconnect DUT	
	Disconnect the DUT from the test network	
	Register hostname for Conflict	
	Register a hostname for the device under test to conflict against by assigning the DUTs hostname to the Kerberos device/IP address.	
	Register service name for Conflict	
	Register a service name for the device under test to conflict against by assigning the DUTs servicename to the Kerberos device/IP address.	



	Connect DUT	
	Connect the DUT to the test network	
	Remove hostname for Conflict	
	Remove the hostname registered by the testsuite.	
	Remove service name for Conflict	
	Remove the service name registered by the testsuite.	
Test Procedure	Get hostname from mdns	
	Get the hostname for the device under test from mDNS.	
	Get service name from mdns	
	Get the service name for the device under test from mDNS.	
	Do LCI	
	The tester is prompted to do a manual LAN reset on the DUT.	
	Get hostname from mdns	
	Get the hostname for the device under test from mDNS.	
	Get service name from mdns	
	Get the service name for the device under test from mDNS.	
10.8 Link	Changes	
Category	mDNS, Device Specification	
Test Type	Kerberos Test, automated	
Rule	Link Changes	
Explanation	When a network "link change" occurs (e.g., an Ethernet cable is plugged in), the LXI Device shall verify that its hostname and service name are unique and shall re-register its services.	
Pre Condition	Connect DUT	
	Connect the DUT to the test network	
	Get service name from mdns	
	Get the service name for the device under test from mDNS.	
Test Procedure	Disconnect DUT	
	Disconnect the DUT from the test network	
	Wait for service name to disappear from mdns	
	Wait until the service name has disappeared from mdns.	
	Connect DUT	
	Connect the DUT to the test network	
	Get service name from mdns	
	Get the service name for the device under test from mDNS.	



11.0 Documentation

Categories General Device

11.1	Full Documentation on IVI Interface	
Category	General Device	
Test Type	Vendor Declaration	
Rule	Full Documentation on IVI Interface	
Explanation	For each LXI Device, the manufacturer shall provide the documentation on the IVI driver, which is required in the Conformance Requirements section of the IVI 3.1 Driver Architecture Specification.	
11.2	Registration of the IVI Driver	
Category	General Device	
Test Type	Vendor Declaration	
Rule	Registration of the IVI Driver	

ExplanationThe IVI driver shall be registered at the IVI Foundation website and be listed on the IVI
Foundation driver registration database.



20.0 LXI HiSLIP Extended Function

Categories	LXI HISLIP				
20.4.1 Co	mply with LXI Device Sp	pecification			
Category	LXI HISLIP				
Test Type	Kerberos Test, auto	Kerberos Test, automated			
Rule	Comply with LXI Device Specification				
Explanation	Devices implement Specification.	ing the LXI HiSLIP extended function shall comply with the LXI Device			
Test Procedure	Computed by othe	er tests			
		This test is computed by the result of other tests.			
Dependencies	Device Specificatio	n			
20.4.2 De	vices that implement IP	v6 shall conform to LXI IPv6 Extended Function connections on IPv6			
Category	LXI HISLIP				
Test Type	Kerberos Test, auto	omated			
Rule	Devices that imple	ment IPv6 shall conform to LXI IPv6 Extended Function connections on IPv6			
Explanation	If devices support Function.	If devices support IPv6 HiSLIP connections, they shall also conform to the LXI IPv6 Extended Function.			
Test Procedure	Computed by othe	er tests			
		This test is computed by the result of other tests.			
Dependencies	LXI IPv6				
20.4.4 Re	set to Default HiSLIP Po	ort and Close Connections on LCI			
Category	LXI HISLIP				
Test Type	Kerberos Test, man	ual			
Rule	Reset to Default Hi	Reset to Default HiSLIP Port and Close Connections on LCI			
Explanation	The devices HiSLIP HiSLIP locks should	configuration shall not be impacted by LCI. The state of the connection and I not be changed by LCI unless necessary as part of network reconfiguration.			
Pre Condition	Connect DUT				
		Connect the DUT to the test network			
	Get IP from mdns				
		Search via mdns for a single lxi service and retrieve its IP address			
	GET Common Con	figuration			
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.			
	Check the device s	upports HiSLIP			
		Check the device supports HiSLIP. This is validated by checking the test configuration input from the Tester.			
	Enable HiSLIP				
		Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIF element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.			



	Disable HiSLIP attributes mustStartEncrypted and encryptionMandatory		
		Disable the HiSLIP attribues mustStartEncrypted and encryptionMandatory attributes to establish HiSLIP connection without encryption. This may only be required if LXI Security is supported.	
	PUT Common Confi	guration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Get HiSLIP Port		
		Get the HiSLIP port, which is advertised via the mDNS service.	
	Modify HiSLIP port		
		Prompt tester to modify the HiSLIP port to anything other than the default port number (4880).	
		Note: This step might not be executed if test configuration claims the device is not able to modify HiSLIP port.	
	Get HiSLIP Port		
		Get the HiSLIP port, which is advertised via the mDNS service.	
	Create HiSLIP conne	ction, expect success	
		Create a HiSLIP connection to the device-under-test (DUT) and expect a valid connection.	
Test Procedure	Do LCI		
		The tester is prompted to do a manual LAN reset on the DUT.	
	Get HiSLIP Port		
		Get the HiSLIP port, which is advertised via the mDNS service.	
	Evaluate Port and Co	onnection	
		connections to the DUT have been closed.	
20.5.1 Conf	ormance Requirements		
Category	LXI HISLIP		
Test Type	Kerberos Test, auton	nated	
Rule	Conformance Requi	rements	
Explanation	ExplanationThe LXI HiSLIP function is an optional function for devices conforming to specification, as defined in section 1.4.4.2 of 'LXI Device Specification 201		
	All LXI Devices imple Specification 2011' s document in additio	ementing the LXI HiSLIP function as permitted by 1.4.4.1 of the 'LXI Device shall implement and conform to the requirements of all sections in this in to any relevant requirements of 'LXI Device Specification 2011'.	
Test Procedure	Computed by other	tests	
		This test is computed by the result of other tests.	
Dependencies	Device Specification LXI HiSLIP		
20.6.1 Impl	ement the IVI 6.1 HiSLI	P Protocol	
Category	LXI HISLIP		
Test Type	Kerberos Test auton	nated	
Rule	Implement the IVI 6.	1 HiSLIP Protocol	
		Implement the IVI 6.1 HISLIP Protocol	



Explanation	Devices implementing the LXI HiSLIP Function shall implement the HiSLIP protocol version 1.1, as defined in 'IVI 6.1: High-speed LAN Instrument Protocol (HiSLIP) February 24, 2011'.	
Pre Condition	Enable IPv4 DHCP router	
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	CET Common Conf	figuration
	GET COMMON COM	GET the Common Configuration from the device. Expect the call to
		succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check the device su	upports HiSLIP
		Check the device supports HiSLIP. This is validated by checking the test configuration input from the Tester.
	Enable HiSLIP	
		Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIP element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.
	Disable HiSLIP attri	butes mustStartEncrypted and encryptionMandatory
		Disable the HiSLIP attribues mustStartEncrypted and encryptionMandatory attributes to establish HiSLIP connection without encryption. This may only be required if LXI Security is supported.
	PUT Common Conf	figuration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Test Procedure	Test SRO and statu	s hvte
		Connect using a HiSLIP address string
		Enable SRQ for data-available (MAV): Send "*ESE 32;*SRE 48" Send *IDN?
		Wait to observe SRQ sent to RQ handler in VISA program. Read the status byte (viReadSTB). The MAV bit (0x10) should be set. Read the response.
		Read the status byte (viReadSTB). The MAV bit (0x10) should not be set.
	Test Device Clear	
		Connect using a HiSLIP address string.
		Send *IDN?
		Perform Device Clear (viClear)
		Observe viRead times out (response no longer waiting).
	Test Interrupted handling	
		Connect using a HiSLIP address string.
		Set VI_ATTR_TCPIP_HISLIP_OVERLAP_EN = VI_FALSE
		Get VI_AI IK_ICPIP_HISLIP_OVERLAP_EN. If = VI_FALSE, continue test
		Send *IDN?
		Send *OPC?
		viRead "1" (and not the identification string).



Test Overlapped mode		
	Connect using HiSLIP address string. Set VI_ATTR_TCPIP_HISLIP_OVERLAP_EN = VI_TRUE Get VI_ATTR_TCPIP_HISLIP_OVERLAP_EN. If = VI_TRUE, continue test (device supports Overlapped mode, so test it). Send *IDN? Send *OPC? viRead ID string viRead "1"	
Test Locking		
	Connect using a HiSLIP address string. viLock (exclusive lock). Start a child process: (test exclusive lock works) Connect using same HiSLIP address string. Send *IDN? viRead returns VI_ERROR_RSRC_LOCKED after a delay (>= VISA timeout) Get the status byte (viReadSTB). Observe this returns with no error. Set the device to local (viGpibControlRen(go to remote). Observe this returns with no error. (note the change is deferred until after the parent lock is released) viUnlock Start a child process: (test exclusive lock released) Connect using same HiSLIP address string. Send *IDN? viRead response should get the ID string. viLock(shared lock) Start a child process: (test shared lock works) Connect using same HiSLIP address string. Send *IDN? viRead returnsVI_ERROR_RSRC_LOCKED after a delay (>= VISA timeout) Start a child process: (shared lock can be shared) Connect using same HiSLIP address string. viLock (same shared lock ID) Send *IDN? viRead returnsVI_ERROR_RSRC_LOCKED after a delay (>= VISA timeout) Start a child process: (shared lock can be shared) Connect using same HiSLIP address string. viLock (same shared lock ID) Send *IDN? viRead response should get the ID string. viUnlock Start a child process:(test shared lock released) Connect using same HiSLIP address string. Send *IDN? viRead response should get the ID string. viLock (sharedlock) viLock (same should get the ID string. Send *IDN? viReadresponse should get the ID string. Send *IDN? viReadresponse should get the ID string.	



	Test Lock Info	
		Connect using HiSLIP address string.
		viLock(Shared lock)
		Check ViGetAttr(VI_ALTR_RSRC_LOCK_STATE) returns VI_SHARED_LOCK
		Check viGetAttr(VLATTR RSRC LOCK STATE) returns VLEXCLUSIVE LOCK
		viUnlock
		Check viGetAttr(VI_ATTR_RSRC_LOCK_STATE) returns VI_ SHARED_LOCK
		viUnlock
		Check viGetAttr(VI_ALTR_RSRC_LOCK_STATE) returns VI_ NO_LOCK
20.6.2 Acce	ept IPv4 HiSLIP Conne	ctions
Category	LXI HiSLIP	
Test Type	Kerberos Test, auto	omated
Rule	Accept IPv4 HiSLIP	Connections
Explanation	LXI HiSLIP Devices	shall accept HiSLIP connections over the IPv4 network.
Pre Condition	Enable IPv4 DHCP	router
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	GET Common Con	figuration
		GET the Common Configuration from the device. Expect the call to
		succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check the device s	upports HiSLIP
		Check the device supports HiSLIP. This is validated by checking the test configuration input from the Tester.
	Enable HiSLIP	
		Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIP
		element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.
	Disable HiSLIP attr	ibutes mustStartEncrypted and encryptionMandatory
		Disable the HiSLIP attribues mustStartEncrypted and
		encryptionMandatory attributes to establish HiSLIP connection without encryption. This may only be required if LXI Security is supported.
	PUT Common Con	figuration
		PUT Common Configuration and expect a valid response from the DUT.
		A valid port is used, authorization is given and the correct URL is being used.
Test Procedure	Test for basic HiSL	P connection
		Connect using a HiSLIP address string (viOpen).
		Send *IDN? (viWrite)
		Read to string response (pass if any string is returned).



20.7.1	Advertise the HiSLIP DNS-SD Service
Category	LXI HISLIP
Test Type	Kerberos Test, automated
Rule	Advertise the HiSLIP DNS-SD Service
Explanation	Devices implementing the LXI HiSLIP Function shall advertise that they accept HiSLIP connections via the HiSLIP DNS-SD service announcement.
Pre Condition	on Connect DUT
	Connect the DUT to the test network
Test Proced	ure Get HiSLIP service name
	Get the service name which was used to advertise the HiSLIP service (_hisliptcp).
20.7.2	Use the LXI Single Service Instance Name
Category	LXI HISLIP
Test Type	Kerberos Test, automated
Rule	Use the LXI Single Service Instance Name
Explanation	LXI devices shall use the same service name for all LXI DNS-SD services, including HiSLIP.
Pre Condition	on Connect DUT
	Connect the DUT to the test network
	Get service name from mdns
	Get the service name for the device under test from mDNS.
lest Proced	ure Get HiSLIP service name
	Get the service name which was used to advertise the HISLIP service (_hisliptcp).
20.7.3	Use Service Type Name '_hisliptcp'
Category	LXI HISLIP
Test Type	Kerberos Test, automated
Rule	Use Service Type Name '_hisliptcp'
Explanation	HiSLIP DNS-SD service announcements shall use the mDNS service type name '_hisliptcp'.
Test Proced	ure Computed by other tests
	This test is computed by the result of other tests.
Dependenci	es 20.7.1
20.7.4	Include Required TXT Record Keys
Category	LXI HISLIP
Test Type	Kerberos Test, automated
Rule	Include Required TXT Record Keys



Explanation	HiSLIP DNS-SD service announcements shall have the following TXT record keys: - txtvers=		
	o If included, must be the first TXT record key		
	- Manufacturer=		
	- Model=		
	- SerialNumber=		
	- FirmwareVersion=		
Pre Condition	Connect DUT		
Test Procedure	Cot tyt records for HiSLIP convice from mdns		
lest Flocedule	Get the TXT records attached to the advertised HiSLIP service		
	Validate tyt records		
	Validate the given txt records for required keys		
2076 Adv	vertise HiSLIP DNS-SD Service with HiSLIP Port		
Catagony			
Category			
Test Type	Kerberos Test, manual		
Rule	Advertise HiSLIP DNS-SD Service with HiSLIP Port		
Explanation	The HiSLIP DNS-SD service advertisement shall use the currently-configured HiSLIP port.		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		
Test Procedure	Get HiSLIP Port		
	Get the HISLIP port, which is advertised via the mDNS service.		
	Query LAN Item Value HISLIP port		
	Frompt tester for the Histir port of the LAN Computation web rage		
20.8.1 Inc	lude 'LXI HiSLIP' in Welcome Web Page "LXI Extended Functions"		
Category	LXI HiSLIP		
Test Type	Kerberos Test, automated		
Rule	Include 'LXI HiSLIP' in Welcome Web Page "LXI Extended Functions"		
Explanation	Devices implementing the LXI HiSLIP function shall include 'LXI HiSLIP' in the 'LXI Extended Functions' display item of the welcome web page.		
Test Procedure	Computed by other tests		
	This test is computed by the result of other tests.		
Dependencies	1.4.6		
20.8.2 Inc	lude HiSLIP Address String in Welcome Web Page "LXI Device Address String"		
Category	LXI HiSLIP		
Test Type	Kerberos Test, manual		
Rule	Include HiSLIP Address String in Welcome Web Page "LXI Device Address String"		
Explanation	The Welcome Web Page 'LXI Device Address String' display item shall contain the HiSLIP		
	address string necessary to request a HiSLIP connection that conforms with the VISA 5.0 HiSLIP address string format as specified in section 4.3.1 of 'VPP-4.3: The VISA Library'.		
Pre Condition	Connect DUT		
	Connect the DUT to the test network		



		Get IP from mdns	
			Search via mdns for a single lxi service and retrieve its IP address
	Test Procedure	Open web page in b	prowser
			Prompt tester to open the devices web page
		Query Home Item Va	alue LXI Device Address String
			Prompt tester for the 'LXI Device Address String' on the 'Welcome Web Page'
		Evaluate LXI Device	Address Strings for HiSLIP Address String
			Evaluate the given LXI Device Address Strings for HiSLIP Address Strings. Searching for following format:
			TCPIP[board]::host address[::HiSLIP device name[,HiSLIP port]][::INSTR] Where:
			Board is the network interface number (default 0).
			Host address is the hostname or IP address of the LXI device.
			HISLIP device name begins with hislip . Typically, hislip is used. HISLIP port is the port number to use for connections, defaulting to 4880.

20.8.3 Include HiSLIP port on the LXI LAN Configuration Web Page

Category	LXI HISLIP
Test Type	Kerberos Test, manual
Rule	Include HiSLIP port on the LXI LAN Configuration Web Page
Explanation	The HiSLIP port shall be displayed on the LAN Configuration Web Page.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
Test Procedure	Open web page in browser
	Prompt tester to open the devices web page
	Query LAN Item HiSLIP port
	Prompt tester to check if the 'HiSLIP port' is displayed on the 'LAN Configuration Web Page'

20.8.4 Preserve HiSLIP port across power cycles

Category	LXI HISLIP	
Test Type	Kerberos Test, manu	al
Rule	Preserve HiSLIP port	t across power cycles
Explanation	The HiSLIP port sett	ing shall be preserved across power cycles.
Pre Condition	Connect DUT	
		Connect the DUT to the test network
Test Procedure	Modify HiSLIP port	
		Prompt tester to modify the HiSLIP port to anything other than the default port number (4880).
		Note: This step might not be executed if test configuration claims the device is not able to modify HiSLIP port.



	Get HiSLIP Port
	Get the HiSLIP port, which is advertised via the mDNS service.
	Cycle power on device
	Prompt the tester to cycle the power on the device.
	Get HiSLIP Port
	Get the HiSLIP port, which is advertised via the mDNS service.
	Ensure unchanged port
	Ensure the port did not change after the power cycle.
20.9.1 Incl	ude the HiSLIP Address String in LXI Identification XML
Category	LXI HISLIP
Test Type	Kerberos Test, automated
Rule	Include the HiSLIP Address String in LXI Identification XML
Explanation	LXI devices implementing HiSLIP shall include an 'InstrumentAddressString' XML element with the HiSLIP address string.
Pre Condition	Connect DUT
	Connect the DUT to the test network
Test Procedure	Get identification file
	Get the identification file from the device under test
	Get all 'InstrumentAddressString' tags
	Get all the LXI Device Strings given by the LXI identification file.
	Evaluate LXI Device Address Strings for HiSLIP Address String
	Evaluate the given LXI Device Address Strings for HiSLIP Address Strings.
	TCPIP[board]::host address[::HiSLIP device name[,HiSLIP port]][::INSTR]
	Where:
	Board is the network interface number (default 0).
	Host address is the hostname or IP address of the LXI device.
	HisLiP port is the port number to use for connections, defaulting to
	4880.
20.9.2 Incl	ude the LXI HiSLIP Function in the <lxiextendedfunctions> element</lxiextendedfunctions>
Category	LXI HISLIP
Test Type	Kerberos Test, automated
Rule	Include the LXI HiSLIP Function in the <lxiextendedfunctions> element</lxiextendedfunctions>
Explanation	LXI devices implementing HiSLIP shall include a element in the XML element with the FunctionName attribute of 'LXI HiSLIP' and a Version attribute containing the version number of this document. If the port number used for HiSLIP is other than the standard HiSLIP port (4880), the element shall include a element with the value of the custom port number.
Pre Condition	Connect DUT

Connect the DUT to the test network

Get the identification file from the device under test

Get all Extended Functions given by the LXI identification file.

Test Procedure

Get identification file

Get 'ExtendedFunctions'



Evaluate HiSLIP extended function

Evaluate the HiSLIP extended function tag from the XML identification file. Ensure the port is given if the currently configured port is anything other than the default value 4880.



21.0 IPv	6 LAN Configuration
Categories	LXI IPv6
21.1.1	IPv6 Network Stack Compliance
Category	LXI IPv6
Test Type	Vendor Declaration
Rule	IPv6 Network Stack Compliance
Explanatio	n All LXI IPv6 capable devices shall have IPv6 compliant network stacks. The vendor of the device must disclose to the LXI Conformance tester why they think their IPv6 stack is IPv6 compliant. This information will be kept confidential and need only be communicated to the LXI Conformance Committee Chairman.
21.1.2	Interoperate with IPv4 networks
Category	LXI IPv6
Test Type	Kerberos Test, automated
Rule	Interoperate with IPv4 networks
Explanatio	n LXI compliant IPv6 devices shall be able to interoperate with other IPv6 capable devices on networks supporting only IPv4, only IPv6, or both IPv4 and IPv6.
	A compliant dual stack (IPv4 & IPv6) approach will accomplish this.
Test Proced	dure Computed by other tests
	This test is computed by the result of other tests.
Dependen	cies IPv4 LXI IPv6
21.1.3	IPv6 Instrument Control Connections
Category	LXI IPv6
Test Type	Kerberos Test, automated
Rule	IPv6 Instrument Control Connections
Explanatio	n LXI IPv6 Devices shall support instrument control connections using at least one TCP/IP IPv6- based protocol.
Pre Condit	ion Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mons for a single ixi service and retrieve its IP address
	Enable IPv6 via Common Configuration Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv is supported)
	Enable IPv6 DHCPEnabled attribute
	Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnabled attribute
	Enable IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticAddressEnabled
	Disable IPv6 staticAddressEnabled attribute via Common Configuration.



	Enable IPv6 RA rou	Enable IPv6 RA router	
		Enable IPv6 RA address assignment on the router. Ensure the DUT has no DHCP address any more. Ensure the DUT has a RA address.	
	Connect DUT		
		Connect the DUT to the test network	
	Get IPv6 from mdn	S	
		Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.	
	Get service name fr	om mdns	
		Get the service name for the device under test from mDNS.	
	GET Common Conf	iguration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Check the device supports HiSL		apports HiSLIP	
		Check the device supports HiSLIP. This is validated by checking the test configuration input from the Tester.	
	Enable HiSLIP		
		Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIP element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.	
	Disable HiSLIP attri	butes mustStartEncrypted and encryptionMandatory	
		Disable the HiSLIP attribues mustStartEncrypted and encryptionMandatory attributes to establish HiSLIP connection without encryption. This may only be required if LXI Security is supported.	
	PUT Common Conf	iguration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Enable SCPIRaw		
		Enable SCPIRaw on the device by setting the Enabled attribute of the SCPIRaw element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and SCPIRaw not supported.	
	PUT Common Conf	iguration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
Test Procedure	Evaluate IPv6 HiSLI	P Connection	
		Only run if IPv6 HiSLIP is configured. 1. Get HiSLIP port via mDNS 2. For each IPv6 address: a) Create a HiSLIP connection to the device-under-test (DUT): b) Query *IDN:	

c) Close Connection



	Evaluate IPv6 TCP (Connection
		1. Get TCP port via mDNS (using _scpi-raw)
		2. For each IPv6 address:
		a) Create a TCP connection to the device-under-test (DUT):
		c) Close Connection
	Evaluate TCP/IP IPv	6-based connection
		Evaluate the TCP/IP IPv6-based connections such as HiSLIP, raw TCP. At least one connection method must be possible.
21.1.6 IPv6	HTTP Web Access	
Category	LXI IPv6	
Test Type	Kerberos Test, auto	mated
Rule	IPv6 HTTP Web Ace	Cess
Explanation	LXI IPv6 Devices sh and 21.11) and the	all support IPv6 HTTP connections to the instrument web pages (Sections 9 LXI XML Identification Document (Section 10.2 and 21.14).
Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Get IPv6 from mdn	S
		Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Open web page	
		Open the web page of DUT with IPv4 or IPv6 address, depending on the test.
21.1.7 Supp	oort IPv6 Operations w	vith Extended Functions
Category	LXI IPv6	
Test Type	Kerberos Test, auto	mated
Rule	Support IPv6 Opera	ations with Extended Functions
Explanation	LXI IPv6 conformar operations required by this specificatior	It devices that implement LXI Extended Functions shall support IPv6 for all IP d by the extended function unless explicitly permitted to omit IPv6 support n.
Test Procedure	Computed by othe	r tests
		This test is computed by the result of other tests.
Dependencies	21.12.2	
	21.12.3	
	21.12.4 21.13.2	
21 1 9 Prov	ida Way ta Disabla IB	<i>1</i> 6
Catagoria		
Category	LXI IPV6	
Test Type	Kerberos Test, man	ual
Rule	Provide Way to Dis	able IPv6
Explanation	Devices shall provid IPv4 traffic on their disabling the IPv6 s method.	te a way to enable and disable IPv6 traffic. IT administrators may prefer only networks and prefer to disable IPv6 traffic. This could be done by enabling/ stack, blocking all IPv6 traffic in and out using a firewall or any other suitable



Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Get IPv6 from mdns	5
		Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Disable IPv6 stack	
		Prompt the tester to disable the IPv6 stack on the DUT. This may not be possible. Note: Some devices may not be able to disable the stack, but traffic can
		still be prevented via the firewall.
	Ping the DUT via IP	v6 for failure
		Ping the DUT via IPv6 using the gloabal IPv6 address and expect it to fail.
	Call webpage via IP	v6 and expect failure response
		Call webpage via IPv6 and expect failure response.
	Enable IPv6 stack	Enable the IPv6 stack. Prompt the user to enable the stack via webpage, GUI or API.
	Ping the DUT via IP	v6 for success
	5	Ping the DUT via IPv6 for success using the global IPv6 address.
	Call webpage via IP	v6 and expect success response
		Call webpage via IPv6 and expect success response.
21.1.9 IPv6	Enabled by Default or	LCI
Category	LXI IPv6	
Test Type	Kerberos Test, manu	Jal
Rule	IPv6 Enabled by De	fault or LCI
Explanation	IPv6 traffic shall be	enabled by default. I CI shall enable IPv6 if disabled
Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Get IPv6 from mdns	5
		Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Disable IPv6 stack	
		Prompt the tester to disable the IPv6 stack on the DUT. This may not be possible. Note: Some devices may not be able to disable the stack, but traffic can still be prevented via the firewall
	Ping the DLIT via IP	
		Ping the DUT via IPv6 using the gloabal IPv6 address and expect it to fail
	Call webnade via IP	v6 and expect failure response
	cui webpuge via ii	Call webpage via IPv6 and expect failure response.
	Do LCI	
		The tester is prompted to do a manual LAN reset on the DUT.
	Ping the DUT via IP	v6 for success
	2	Ping the DLIT via IPv6 for success using the global IPv6 address



Call webpage via IPv6 and expect success response

Call webpage via IPv6 and expect success response.

21.1.10 Prov	ide Way to Disable IPv	4		
Category	LXI IPv6			
Test Type	Kerberos Test, man	ual		
Rule	Provide Way to Dis	Provide Way to Disable IPv4		
Explanation	Devices shall provic and users of LXI de enabling/disabling other suitable meth	le a way to enable and disable IPv4 traffic. IPv6 is becoming more prevalent vices may want to eliminate IPv4 traffic on their network. This could be by the IPv4 stack, blocking all IPv4 traffic in and out using a firewall or any nod.		
Pre Condition	Connect DUT			
		Connect the DUT to the test network		
	Get IPv6 from mdn	S		
		Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.		
Test Procedure	Disable IPv4 stack			
		Prompt the tester to disable the IPv4 stack on the DUT. Note: Some devices may not be able to disable the stack, but traffic can still be prevented via the firewall.		
	Ping the DUT for fa	ilure		
		Ping the DUT via IPv4 which is expected to fail.		
	Call webpage via IP	v4 and expect failure response Call webpage via IPv4 and expect failure response.		
	Enable IPv4 stack			
		Enable IPv4 stack. If LXI Security selected this can be done via Common Configuration, else manual interaction via LAN Reset/webpage or front panel required.		
	Ping the DUT for su	iccess		
		Ping the DUT via IPv4 which is expected to succeed		
	Call webpage via IP	v4 and expect success response		
		Call webpage via IPv4 and expect success response.		
21.1.11 IPv4	Enabled by Default			
Category	LXI IPv6			
Test Type	Kerberos Test, man	ual		
Rule	IPv4 Enabled by De	fault		
Explanation	IPv4 traffic shall be	enabled by default. LCI shall enable IPv4 if disabled.		
Pre Condition	Connect DUT			
		Connect the DUT to the test network		
	Get IP from mdns			
		Search via mdns for a single lxi service and retrieve its IP address		
Test Procedure	Disable IPv4 stack	Prompt the tester to disable the IPv4 stack on the DUT. Note: Some devices may not be able to disable the stack, but traffic can still be prevented via the firewall.		



	Ping the DUT for failure	2
	Р	ing the DUT via IPv4 which is expected to fail.
	Call webpage via IPv4 a	and expect failure response
	C	all webpage via IPv4 and expect failure response.
	Do LCI	
	Т	he tester is prompted to do a manual LAN reset on the DUT.
	Ping the DUT for succe	SS
	Р	ing the DUT via IPv4 which is expected to succeed
	Call webpage via IPv4 a	and expect success response
	C	all webpage via IPv4 and expect success response.
21.2.1 Cr	eate a Link-local address	
Category	LXI IPv6	
Test Type	Kerberos Test, automat	ed
Rule	Create a Link-local add	ress
Explanation	All LXI IPv6 compliant o described in RFC 4862 discovery messages, wl	devices shall create a unique Link-local address (FE80/64) first as - IPv6 Stateless Address Autoconfiguration using the Neighbor hich are part of ICMPv6.
Pre Condition	Connect DUT	
	C	connect the DUT to the test network
Test Procedure	Get Link-local IPv6 from	n mdns
	G	iet the IPv6 link-local address only via mDNS.
21.2.2 Su	pport Stateless Address Aut	oconfiguration (RA)
Category	LXI IPv6	
Test Type	Kerberos Test, automat	red
Rule	Support Stateless Addr	ress Autoconfiguration (RA)
Explanation	LXI devices shall suppo RFC 2462.	rt RFC 4862 - IPv6 Stateless Address Autoconfiguration that supersedes
Pre Condition	Enable IPv4 DHCP rout	er
	E	nable the dhcp router for IPv4
	Connect DUT	
	C	Connect the DUT to the test network
	Get IP from mdns	
	S	earch via mdns for a single lxi service and retrieve its IP address
	Enable IPv6 via Commo	on Configuration
	C	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 s supported)
	Enable IPv6 DHCPEnab	led attribute
	E	nable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnabled	attribute
	E	nable IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticAddr	ressEnabled
	C	Disable IPv6 staticAddressEnabled attribute via Common Configuration.



	En	able IPv6 RA router	
			Enable IPv6 RA address assignment on the router. Ensure the DUT has no DHCP address any more. Ensure the DUT has a RA address.
Test Procedu	ire Ge	et RA IPv6 from mdr	15
			Get the RA address only via mDNS.
21.2.3	Stop using	the router assigne	d IP Address if the valid lifetime lease not renewed
Category	LX	I IPv6	
Test Type	Ke	rberos Test, automa	ated
Rule	Sto	op using the router	assigned IP Address if the valid lifetime lease not renewed
Explanation	lf a su LA	If an LXI Device is unable to renew its router assigned valid lifetime lease, it shall stop using the supplied IP configuration that failed to be renewed, and signal an error to the user via the LXI LAN Status Indicator. Refer to Figure 21.1 for the definition of the valid lifetime lease.	
Pre Conditio	n En	able IPv4 DHCP rou	iter
			Enable the dhcp router for IPv4
	Co	onnect DUT	
			Connect the DUT to the test network
	Ge	et IP from mdns	
			Search via mdns for a single lxi service and retrieve its IP address
	En	able IPv6 via Comm	non Configuration
			Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	En	able IPv6 DHCPEna	bled attribute
			Enable IPv6 DHCPEnabled attribute via Common Configuration.
	En	able IPv6 RAEnable	d attribute
			Enable IPv6 RAEnabled attribute via Common Configuration.
	Dis	sable IPv6 staticAdc	dressEnabled
			Disable IPv6 staticAddressEnabled attribute via Common Configuration.
	En	able IPv6 RA router	
			Enable IPv6 RA address assignment on the router.
			Ensure the DUT has a RA address.
Test Procedu	ire Ge	et RA IPv6 from mdr	ns
			Get the RA address only via mDNS.
	Sto	op IPv6 RA router	
		•	Stop the IPv6 RA assignment on the router.
	Wa	ait for DUT to loose	RA IPv6
			Wait for the device-under-test (DUT) to stop using the RA address.
21.2.5	Support Sta	atic IP Address Ass	signment
Category	LX	I IPv6	
Test Type	Ke	rberos Test, manual	
Rule	Su	pport Static IP Add	ress Assignment



Explanation	Devices shall support Static IP addressing. Some TCP/IP networks require each device to be manually configured with an IP address, network prefix length, default gateway, and optionally DNS IP addresses. On these networks the network administrator provides the network configuration values to the device user. LXI devices shall provide a way to enter the following parameters into the device:
	IPv6 IP Address
	Network Prefix Length
	Default gateway DNS IP addresses
	Before using any static IP address, the device shall verify the address is not already in use. See NIST IPv6 Profile, Section 4.2, Basic Capabilities, for IPv6 Stateless Address Autoconfiguration (RA) and Duplicate Address Detection (DAD)
Test Procedure	Is there a way to enter the IPv6 address
	Prompt Tester: Is there a way to enter the IPv6 address
	Is there a way to enter the IPv6 Network Prefix Length
	Prompt Tester: Is there a way to enter the IPv6 Network Prefix Length
	Is there a way to enter the IPv6 default gateway
	Prompt Tester: Is there a way to enter the IPv6 default gateway
	Is there a way to enter the IPv6 DNS IP addresses
	Prompt Tester: Is there a way to enter the IPv6 DNS IP addresses
21.2.6 Supp	ort DHCPv6
Category	LXI IPv6
Test Type	Kerberos Test, automated
Rule	Support DHCPv6
Explanation	Devices shall support both Stateless and Stateful DHCPv6 addressing.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	21.2.7
	21.2.8
21.2.7 Stop	using the DHCP assigned IP Address if the valid lifetime lease not renewed
Category	LXI IPv6
Test Type	Kerberos Test, automated
Rule	Stop using the DHCP assigned IP Address if the valid lifetime lease not renewed
Explanation	If an LXI device implements DHCPv6 then it must abide by this rule.
Pre Condition	If an LXI Device is unable to renew its DHCPv6 valid lifetime lease, it shall stop using the supplied IP configuration that failed to be renewed, and signal an error to the user via the LXI LAN Status Indicator. Refer to Figure 21.1 for the definition of the valid lifetime lease.
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns

Search via mdns for a single lxi service and retrieve its IP address



	Enable IPv6 via Common Configuration
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCPEnabled attribute
	Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnabled attribute
	Enable IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticAddressEnabled
	Disable IPv6 staticAddressEnabled attribute via Common Configuration.
	Enable IPv6 DHCP router
	Enable IPv6 DHCP address assignment on the router.
	Ensure the DUT has no RA address any more.
	Ensure the DUT has a DHCP address.
	Disconnect DUT
	Disconnect the DUT from the test network
	Connect DUT
	Connect the DUT to the test network
Test Procedure	Get DHCP IPv6 from mdns
	Get the DHCP address only via mDNS.
	Stop IPv6 DHCP router
	Stop the IPv6 DHCP assignment on the router.
	Wait for DUT to loose DHCP IPv6
	Wait for the device-under-test (DUT) to stop using the DHCP address.
21.2.8 Hond	or New DHCP Options at Lease Renewal
Catagony	LXLIPv6
Category	
Test Type	Kerberos Test, automated
Test Type Rule	Kerberos Test, automated Honor New DHCP Options at Lease Renewal
Test Type Rule Explanation	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule.
Test Type Rule Explanation	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease.
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable the dhcp router for IPv4
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address Enable IPv6 via Common Configuration
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address Enable IPv6 via Common Configuration Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address Enable IPv6 via Common Configuration Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported) Enable IPv6 DHCPEnabled attribute
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address Enable IPv6 via Common Configuration Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported) Enable IPv6 DHCPEnabled attribute Enable IPv6 DHCPEnabled attribute via Common Configuration.
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address Enable IPv6 via Common Configuration Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported) Enable IPv6 DHCPEnabled attribute Enable IPv6 RAEnabled attribute
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address Enable IPv6 via Common Configuration Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported) Enable IPv6 DHCPEnabled attribute Enable IPv6 RAEnabled attribute Enable IPv6 RAEnabled attribute
Test Type Rule Explanation Pre Condition	Kerberos Test, automated Honor New DHCP Options at Lease Renewal If an LXI device implements DHCPv6, then it must abide by this rule. LXI Devices shall honor new DHCP options provided when renewing a lease. Enable IPv4 DHCP router Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address Enable IPv6 via Common Configuration Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported) Enable IPv6 DHCPEnabled attribute Enable IPv6 RAEnabled attribute Enable IPv6 RAEnabled attribute Enable IPv6 staticAddressEnabled



	Enable IPv6 DHCP ro	puter
		Enable IPv6 DHCP address assignment on the router.
		Ensure the DUT has no RA address any more.
		Ensure the DUT has a DHCP address.
	Disconnect DUT	
		Disconnect the DUT from the test network
	Connect DUT	
		Connect the DUT to the test network
Test Procedure	Get DHCP IPv6 from	mdns
		Get the DHCP address only via mDNS.
	Change IPv6 DHCP r	ange router
		Change the range of the IPv6 DHCP server.
	Wait for DUT to acce	ept new range
		Depending on the lease time (in general 5min), wait until the IP address has changed
	Get DHCP IPv6 from	mdns
		Get the DHCP address only via mDNS.
	Validate IP has new r	range
		Validate the IP address matches the expected DHCP range.
21.2.9 Select	ion of IP Configuratio	n Modes
Category	LXI IPv6	
Test Type	Kerberos Test, manu	al
Rule	Selection of IP Confi	guration Modes
Explanation	If an LXI device supp the different modes requirements). Either	orts DHCPv6 and/or Static IP, then there need to be options to configure via the LXI required Web pages (see Section 21.11 for LXI Web page of the following configurations is valid:
	- A single configurat o Automatic (implyir o Manual (Static IP a	ion setting which allows a selection of one of the following options: ng RA, DHCP) Iddress only).
	- Individual configur o RA o DHCP o Static	ation settings to enable or disable the following options :
	0 Static	
	If you only support of out of the possible of	one of these additional modes, then leave the one you did not implement configuration settings, shown above.
Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Get IPv6 from mdns	
		Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.



Test Procedure	Check IPv6 configuration options	
	Prompt the Tester to check IPv6 configuration options. Either a "Automatic" selection method must be found or a way to individually set RA/DHCP/Static must be available. It is also possible to have a "Static only" selection method.	
21.2.10 Abi	ility to Enable/Disable Privacy Setting	
Category	LXI IPv6	
Test Type	Kerberos Test, manual	
Rule	Ability to Enable/Disable Privacy Setting	
Explanation	Devices shall support enabling and disabling privacy settings. RFC 8981 describes an extension to IPv6 Stateless Address Autoconfiguration that causes hosts to generate temporary addresses with randomized interface identifiers (IID's) for each prefix advertised with autoconfiguration enabled. RFC 8981 obsoletes RFC 4941 which previously referred to this as privacy settings. LXI refers to this as privacy settings for backward compatibility reasons.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	Enable IPv6 via Common Configuration	
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)	
	Enable IPv6 DHCPEnabled attribute	
	Enable IPv6 DHCPEnabled attribute via Common Configuration.	
	Enable IPv6 RAEnabled attribute	
	Enable IPv6 RAEnabled attribute via Common Configuration.	
	Disable IPV6 staticAddressEnabled	
	Enable IPv6 RA router	
	Enable IPv6 RA address assignment on the router.	
	Ensure the DUT has no DHCP address any more.	
	Ensure the DUT has a RA address.	
	Get RA IPv6 from mdns	
TID	Get the RA address only via mDNS.	
lest Procedure	Disable Privacy Settings Prompt the tester to disable privacy masking on the device-under-test (DUT).	
	Get RA IPv6 from mdns	
	Get the RA address only via mDNS.	
	Validate IP address is not masked	
	Validate the IP address is not masked and the MAC address can be recognized within the IP address.	



	Enable Privacy Settings		
	Prompt the tester to enable privacy masking on the device-under-test (DUT).		
	Get RA IPv6 from mdns		
	Get the RA address only via mDNS.		
	Validate IP address is masked		
	Validate the IP addresshas been masked by the privacy setting.		
21.2.11	Privacy Setting Enabled by Default		
Category	LXI IPv6		
Test Type	Kerberos Test, manual		
Rule	Privacy Setting Enabled by Default		
Explanation	The privacy setting shall be enabled by LCI and be enabled by default.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
	Enable IPv6 via Common Configuration		
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)		
	Enable IPv6 DHCPEnabled attribute		
	Enable IPv6 DHCPEnabled attribute via Common Configuration.		
	Enable IPv6 RAEnabled attribute		
	Enable IPv6 RAEnabled attribute via Common Configuration.		
	Disable IPv6 staticAddressEnabled		
	Disable IPv6 staticAddressEnabled attribute via Common Configuration.		
	Enable IPv6 RA router		
	Enable IPv6 RA address assignment on the router.		
	Ensure the DUT has a RA address.		
	Get RA IPv6 from mdns		
	Get the RA address only via mDNS.		
Test Procedure	e Disable Privacy Settings		
	Prompt the tester to disable privacy masking on the device-under-test (DUT).		
	Get RA IPv6 from mdns		
	Get the RA address only via mDNS.		
	Validate IP address is not masked		
	Validate the IP address is not masked and the MAC address can be recognized within the IP address.		
	Do LCI		
	The tester is prompted to do a manual LAN reset on the DUT.		
	Get RA IPv6 from mdns		
	Get the RA address only via mDNS.		



	Verify Privacy Setting is enabled
	Verify the Privacy Setting is enabled by investigating the RA IPv6 addres
	Validate IP address is masked
	Validate the IP addresshas been masked by the privacy setting.
21.3.1 Dis	play Link-local Address
Category	LXI IPv6
Test Type	Kerberos Test, manual
Rule	Display Link-local Address
Explanation	All IPv6 devices will display the preferred link-local address on the front panel displays, if present, and the Welcome web page. An IPv6 link-local address will have a network prefix of: FE80::/64 equivalent to IPv4: 169.254.0.0/16 addresses.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get IPv6 from mdns
	Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Query Home Item TCP/IP Address
	Prompt tester to check availability of the 'TCP/IP Address' on the 'Welcome Web Page'
	Evaluate IPv6 addresses
	Evaluate the given IPv6 addresses for link-local, RA and/or DHCP address.
	Query front panel link-local address
	Prompt the tester to enter the front-panel link-local address.
Post Condition	Match Displayed with mDNS IPv6 addresses Match the displayed/entered mDNS IPv6 addresses with the addresses given by mDNS.
21.3.2 Dis	play a minimum of one other Preferred Address
Category	LXI IPv6
Test Type	Kerberos Test, manual
Rule	Display a minimum of one other Preferred Address
Explanation	If an LXI IPv6 compliant device creates a globally scoped, preferred address, then this should be displayed via the front panel of the device, if it has one, and on the LXI defined Welcome page (see section 21.11 for IPv6 Web pages requirements).
Pre Condition	Enable IPv6 RA router
	Enable IPv6 RA address assignment on the router. Ensure the DUT has no DHCP address any more. Ensure the DUT has a RA address.
	Connect DUT
	Connect the DUT to the test network
	Get IPv6 from mdns
	Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.



Test Procedure	Query Home Item TCP/I	P Address
	Pr 'W	ompt tester to check availability of the 'TCP/IP Address' on the /elcome Web Page'
	Evaluate IPv6 addresses	
	Ev	aluate the given IPv6 addresses for link-local, RA and/or DHCP ldress.
	Query front panel globa	l address
	Pr	ompt the tester to enter the front-panel global address.
Post Condition	Match Displayed with m M	DNS IPv6 addresses atch the displayed/entered mDNS IPv6 addresses with the addresses
	gi	ven by mDNS.
21.4.1 Supp	ort Multicast DNS	
Category	LXI IPv6	
Test Type	Kerberos Test, automate	d
Rule	Support Multicast DNS	
Explanation	LXI IPv6 capable devices section 10, for mDNS ar LXI specification for mo	must implement multicast DNS. All the rules and recommendations in d DNS-SD, apply to IPv6 devices. See sections 10.3-10.8 of the Core re on this.
Pre Condition	Connect DUT	
	Co	onnect the DUT to the test network
Test Procedure	Get IPv6 from mdns	
	Ge ha re	et all available IPv6 addresses via mDNS. It is possible for a device to ve several IPv6 addresses, at a minimum the link-local address will be turned.
21.4.2 Supp	ort mDNS on IPv6 only ne	tworks
Category	LXI IPv6	
Test Type	Kerberos Test, manual	
Rule	Support mDNS on IPv6	only networks
Explanation	mDNS must work on IPv local address scoping (F	/6 only networks. LXI only requires at a minimum that mDNS use link- F02/16) on IPv6 networks.
Pre Condition	Enable IPv4 DHCP route	r
	Er	able the dhcp router for IPv4
	Connect DUT	
	Co	onnect the DUT to the test network
	Get IP from mdns	
	Se	arch via mdns for a single lxi service and retrieve its IP address
	Enable IPv6 via Commo	n Configuration
	Co	onnect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 supported)
	Enable IPv6 DHCPEnable	ed attribute
	En	able IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnabled	attribute
	En	able IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticAddre	issEnabled
	Di	sable IPv6 staticAddressEnabled attribute via Common Configuration.



	Connect DUT	
		Connect the DUT to the test network
	Get IPv6 from mdns	
		Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Disable IPv4 stack	
		Prompt the tester to disable the IPv4 stack on the DUT. Note: Some devices may not be able to disable the stack, but traffic can still be prevented via the firewall.
	Disconnect DUT	
		Disconnect the DUT from the test network
	Start wireshark captu	ire: Filter "mdns && ipv6"
		start a wireshark capture filtering for mDNS and IPV6 protocol. Filter: "mdns && ipv6"
	Connect DUT	
		Connect the DUT to the test network
	Stop wireshark captu	ire
		Stop the wireshark from further package capturing
	Analyse wireshark ca	Analyse the given wireshark capture for AAAA records advertised by the
		201.
21.4.5 Provide	e Manual DNS IP Add	Iress Entry
Category	LXI IPv6	
Test Type	Kerberos Test, manu	al
Rule	Provide Manual DNS	S IP Address Entry
Explanation	LXI Devices shall allo The automatic IP cor specific DNS configu in network environm	w the user to enter DNS server(s) IP addresses. nfiguration with manual DNS configuration enables the user to select a ration in addition to the DHCPv6 configuration information. This is useful rents with a DNS server per department and a DHCPv6 server per site.
Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Get IPv6 from mdns	
		Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Is there a way to ent	er the IPv6 DNS IP addresses
		Prompt Tester: Is there a way to enter the IPv6 DNS IP addresses
21.4.7 Provide	e way to Disable mDN	NS and DNS-SD for IPv6
Category	LXI IPv6	
Test Type	Kerberos Test, manu	al
Rule	Provide way to Disat	ble mDNS and DNS-SD for IPv6
Explanation	Devices shall provide	e a way to enable and disable mDNS and DNS-SD for IPv6.
Pre Condition	Connect DUT	

Connect the DUT to the test network



	Get IPv6 from mdns	
		Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Disable mDNS	
		Prompt the tester to disable mDNS
	Wait for service name	e to disappear from mdns
		Wait until the service name has disappeared from mdns.
	Enable mDNS	
	Cat IDvC frame mading	Prompt the tester to enable mDNS
	Get IPv6 from mans	Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
21.4.9 mDNS and DNS-SD Enabled by LAN Configuration Initialize (LCI)		
Category	LXI IPv6	
Test Type	Kerberos Test, manua	al
Rule	mDNS and DNS-SD	Enabled by LAN Configuration Initialize (LCI)
Explanation	When the LCI reset mechanism is activated, it shall enable mDNS and DNS-SD for IPv4 and IPv6.	
Pre Condition	Connect DUT	
		Connect the DUT to the test network
	Get IPv6 from mdns	
		Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Disable mDNS	
		Prompt the tester to disable mDNS
	Wait for service name	e to disappear from mdns
		Wait until the service name has disappeared from mdns.
	Do LCI	
		The tester is prompted to do a manual LAN reset on the DUT.
	Get IPV6 from mans	Get all available IPv6 addresses via mDNS. It is possible for a device to
		have several IPv6 addresses, at a minimum the link-local address will be returned.
21.5.1 ICMPv6	Ping Reply	
Category	LXI IPv6	
Test Type	Kerberos Test, autom	nated
Rule	ICMPv6 Ping Reply	


Explanation	LXI Devices shall support ICMPv6 (Internet Control Message Protocol), used for a Ping Responder for diagnostics. (Relevant IETF RFC: 4443)
	The TCP/IP stack in the LXI device shall be able to reply to the ICMPv6 echo request message used by the ping command. The 'ping -6 ' or 'ping -6 ' command is the standard way to understand whether a user's connection to an Ethernet device is working.
	Note that both ping and ARP equivalents in IPv4 are done via ICMPv6, with ARP (IPv4) being replaced with neighbor discovery (IPv6). Echo request and Echo reply implement the 'ping' functionality.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get IPv6 from mdns
	Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Ping the DUT via IPv6 for success
	Ping the DUT via IPv6 for success using the global IPv6 address.
21.5.3 Prov	ide Way to Disable ICMPv6 Echo Reply Message
Category	LXI IPv6
Test Type	Kerberos Test, manual
Rule	Provide Way to Disable ICMPv6 Echo Reply Message
Explanation	LXI devices shall have a way to enable and disable the ICMP Echo Reply messages.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get IPv6 from mdns
	Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Disable ICMPv6 Ping Responder
	Prompt the tester to disable ICMP Ping Responder for IPv6
	Ping the DUT via IPv6 for failure
	Ping the DUT via IPv6 using the gloabal IPv6 address and expect it to fail.
	Enable ICMPv6 Ping Responder
	Prompt the tester to enable ICMP Ping Responder for IPv6
	Ping the DUT via IPv6 for success
	Ping the DUT via IPv6 for success using the global IPv6 address.
21.5.4 ICMF	Pv6 Echo Reply Enabled by Default
Category	LXI IPv6
Test Type	Kerberos Test, manual
Rule	ICMPv6 Echo Reply Enabled by Default
Explanation	ICMP Ping service ("Ping Responder") shall be enabled by default.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4



	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	Enable IPv6 via Cor	nmon Configuration
		Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCPE	nabled attribute
		Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnat	pled attribute
		Enable IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticA	ddressEnabled
		Disable IPv6 staticAddressEnabled attribute via Common Configuration.
	Enable IPv6 RA rou	ter
		Enable IPv6 RA address assignment on the router. Ensure the DUT has no DHCP address any more. Ensure the DUT has a RA address.
	Connect DUT	
		Connect the DUT to the test network
	Get RA IPv6 from m	ndns
		Get the RA address only via mDNS.
	Disable Ping Respo	nder
		Prompt the Tester to disable the ICMP Ping Responder
Test Procedure	Ping the DUT via IP	v6 for failure
		Ping the DUT via IPv6 using the gloabal IPv6 address and expect it to fail.
	Do LCI	
		The tester is prompted to do a manual LAN reset on the DUT.
	Ping the DUT via IP	v6 for success
		Ping the DUT via IPv6 for success using the global IPv6 address.
21.6 Dupl	icate IP Address Detec	tion
Category	LXI IPv6	
Test Type	Kerberos Test man	ual
Rule	Duplicate IP Addres	rs Detection
Explanation	If a duplicate or Addres	ss Detection
	fault condition.	iss is detected, the Device shall use the LAI LAIN status indicator to signal a
Pre Condition	Connect DUI	
		Connect the DUT to the test network
	Get IPv6 from mdn	S
		have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Cause duplicate IP	
		Cause the device to issue a duplicate IP warning by setting the device to the same address as the test hardware. This may be done via he webpage LAN configuration or via the devices frontpanel.



	Is LAN Status Indicator showing FAULT
	Prompt the Tester to check the LAN Status indicator for FAULT.
	Evaluate duplicate IPv6 correction
	When a duplicate IPv6 address detection occurs the device must not use the IPv6 address. It shall not be advertised by Mdns, nor shown elsewhere as active. The device wills till be reachable via other global mechanisms or via the link-local address. The LAN status indicator shall show as fault.
21.8 Pro	ovide an Error Indicator for LAN Configuration Faults
Category	LXI IPv6
Test Type	Kerberos Test, manual
Rule	Provide an Error Indicator for LAN Configuration Faults
Explanation	LXI Devices shall make use of the LXI LAN Status Indicator to inform the user of a LAN fault or error caused by:
	 Failure to acquire a valid IP address Detection of a duplicate IP address Failure to renew an already acquired auto-configured address (RA or DHCP) valid lifetime (lease). Failure to obtain an initial RA or DHCP lifetime is not a failure. LAN cable disconnected (as reported by Ethernet connection monitoring)
Pre Condition	Stop IPv6 DHCP router
	Stop the IPv6 DHCP assignment on the router.
	Stop IPv6 RA router
	Stop the IPv6 RA assignment on the router.
	Disconnect DUT
Tast Drasadura	Disconnect the DUT from the test network
lest Procedure	IS LAN Status Indicator showing FAULI Prompt the Tester to check the LAN Status indicator for FAULT.
	Connect DUT
	Connect the DUI to the test network
	Is LAN Status Indicator showing OK Prompt the Tester to check the LAN Status indicator for OK.
	Enable IPv6 RA router
	Enable IPv6 RA address assignment on the router. Ensure the DUT has no DHCP address any more. Ensure the DUT has a RA address.
	Get RA IPv6 from mdns
	Get the RA address only via mDNS.
	Is LAN Status Indicator showing OK Prompt the Tester to check the LAN Status indicator for OK.
	Stop IPv6 RA router
	Stop the IPv6 RA assignment on the router.
	Wait for DUT to loose RA IPv6
	Wait for the device-under-test (DUT) to stop using the RA address.
	Is LAN Status Indicator showing FAULT
	Prompt the Tester to check the LAN Status indicator for FAULT.



	Do LCI	
		The tester is prompted to do a manual LAN reset on the DUT.
	Is LAN Status Indica	ator showing OK
		Prompt the Tester to check the LAN Status indicator for OK.
	Enable IPv6 DHCP r	router
		Enable IPv6 DHCP address assignment on the router. Ensure the DUT has no RA address any more. Ensure the DUT has a DHCP address.
	Get DHCP IPv6 fror	n mdns
		Get the DHCP address only via mDNS.
	ls LAN Status Indica	ator showing OK
		Prompt the Tester to check the LAN Status indicator for OK.
	Stop IPv6 DHCP ro	uter
		Stop the IPv6 DHCP assignment on the router.
	Wait for DUT to loc	ose DHCP IPv6
		Wait for the device-under-test (DUT) to stop using the DHCP address.
	Is LAN Status Indica	ator showing FAULT
		Prompt the Tester to check the LAN Status indicator for FAULT.
	Do LCI	
		The tester is prompted to do a manual LAN reset on the DUT.
	Is LAN Status Indica	ator showing OK
		Prompt the Tester to check the LAN Status indicator for OK.
	Enable IPv6 RA rou	ter
		Enable IPv6 RA address assignment on the router. Ensure the DUT has no DHCP address any more. Ensure the DUT has a RA address.
	Open web page in	browser
		Prompt tester to open the devices web page
	Activate LAN ID ind	licator
		Prompt tester to activate the LAN ID indicator on web page
	Is LAN ID indicator	active
		Query tester if LAN ID indicator is showing on device
	Deactivate LAN ID i	indicator
		Prompt tester to deactivate the LAN ID indicator on web page
	Is LAN ID indicator	deactivated
		Query tester if LAN ID indicator is not showing on device
Combi	ned IPv4 and IPv6 L	AN Status Indicator
	LXI IPv6	
	Kerberos Test, auto	mated

Rule Combined IPv4 and IPv6 LAN Status Indicator

21.8.1

Category Test Type



licator, te diagram tion 8.10
tion 8.10
tion 21.8
tle more following ss created
l, then this
e other device to ne IPv4 will
n when thing has he user for et or
andom on each to a router
. On most erver or a d

LAN Status Indicator enabled by default for both $\ensuremath{\mathsf{IPv4}}$ and $\ensuremath{\mathsf{IPv6}}$

Rule



Explanation	If the LAN Status Indicator can be configured, the LAN Status indicator by default shall show both IPv4 and IPv6 errors.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mans
	Search via mdns for a single lxi service and retrieve its IP address
	Enable IDv6 via Common Configuration
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCPEnabled attribute
	Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnabled attribute
	Enable II vo to Enabled attribute via Common Configuration
	Disable IF vo staticAddressEnabled attribute via Common Configuration
	Enclus ID: C DA maritan
	Enable IPV6 KA router
	Enable IPV6 RA address assignment on the router. Ensure the DUT has no DHCP address any more.
Ta at Dua as duus	
lest Procedure	Disable LAN status Indicator
	Disable the LAN status indicator for IPv6 or IPv4 or both if possible.
	Stop IPv6 RA router
	Stop the IPv6 RA assignment on the router.
	Wait for DUT to loose RA IPv6
	Wait for the device-under-test (DUT) to stop using the RA address.
	Is LAN Status Indicator showing OK
	Prompt the Tester to check the LAN Status indicator for OK.
	Do LCI
	The tester is prompted to do a manual LAN reset on the DUT.
	Enable IPv6 RA router
	Enable IPv6 RA address assignment on the router.
	Ensure the DUT has no DHCP address any more.
	Ensure the DUT has a RA address.
	Get RA IPv6 from mdns
	Get the RA address only via mDNS.
	Stop IPv6 RA router
	Stop the IPv6 RA assignment on the router.
	Wait for DUT to loose RA IPv6
	Wait for the device-under-test (DUT) to stop using the RA address.
	Is LAN Status Indicator showing FAUIT
	Prompt the Tester to check the LAN Status indicator for FAULT.



21.9	LAN Configuration Initialize (LCI)
Category	LXI IPv6
Test Type	Kerberos Test, manual
Rule	LAN Configuration Initialize (LCI)
Explanation	LXI Devices shall provide an LCI reset mechanism, as defined in the core specification – section 2.4.5 that when activated places the LXI Device's network settings into a default state. These settings shall take effect when the LCI mechanism is activated, without requiring any further operator actions (e.g., if the LXI Device requires a reboot for the changes to take effect, the LXI Device shall reboot automatically). The LXI Device default state shall be fully documented and available in the manufacturer's supplied documentation.
	Table of items affected by LAN Configuration Initialize Mechanism
	Item Value Section IPv4 stack Enabled 21.11.7 IPv6 stack Enabled 21.11.7 IPv6 Address Configuration: 1. RA 2. DHCPv6 3. Static 1. Enabled 2. Enabled 3. Static 1. Enabled 2. Enabled if implemented 3. Disabled if implemented 21.2.9 Privacy Setting Disabled 21.2.11 LAN Status Indicator Enabled for both IPv4 and IPv6 21.8.5 ICMPv6 Echo Reply Message Enabled 21.5.4 Web Password for configuration Factory Default 9.8 mDNS and DNS-SD Enabled 10.3
	10.7.1
Due Courth	
Pre Conditio	Enable IPv4 DHCP router

Enable the dhcp router for IPv4



	Connect DUT		
		Connect the DUT to the test network	
	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	Enable IPv6 via Con	nmon Configuration	
		Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)	
	Enable IPv6 DHCPE	nabled attribute	
		Enable IPv6 DHCPEnabled attribute via Common Configuration.	
	Enable IPv6 RAEnat	oled attribute Enable IPv6 RAEnabled attribute via Common Configuration.	
	Disable IPv6 staticA	ddressEnabled	
		Disable IPv6 staticAddressEnabled attribute via Common Configuration.	
	Enable IPv6 RA rou	ter	
		Enable IPv6 RA address assignment on the router.	
		Ensure the DUT has no DHCP address any more.	
		Ensure the DUT has a RA address.	
	Connect DUT		
		Connect the DUT to the test network	
	Get RA IPv6 from m	ndns	
		Get the RA address only via mDNS.	
	Get identification fil	e	
		Get the identification file from the device under test	
Test Procedure	Disable Privacy Sett	ings	
		Prompt the tester to disable privacy masking on the device-under-test (DUT).	
	Change web password		
		Prompt the tester to change web password away from the default value. If LXI Security is configured, then this step is skipped as passwords are handled differently.	
	Disable mDNS		
		Prompt the tester to disable mDNS	
	Disable ICMPv6 Pin	g Responder	
		Prompt the tester to disable ICMP Ping Responder for IPv6	
	Disable LAN status	Indicator	
		Disable the LAN status indicator for IPv6 or IPv4 or both if possible.	
	Disable IPv6 stack		
		Prompt the tester to disable the IPv6 stack on the DUT. This may not be possible.	
		Note: Some devices may not be able to disable the stack, but traffic can still be prevented via the firewall.	
	Disable IPv4 stack		
		Prompt the tester to disable the IPv4 stack on the DUT. Note: Some devices may not be able to disable the stack, but traffic can still be prevented via the firewall.	
	Do LCI		
		The tester is prompted to do a manual LAN reset on the DUT.	



	Get RA IPv6 from mdns
	Get the RA address only via mDNS.
	Ping the DUT for success
	Ping the DUT via IPv4 which is expected to succeed
	Validate IP address is masked
	Validate the IP addresshas been masked by the privacy setting.
	Is web password reset
	Prompt the tester to get password is reset to default or not. If LXI Security is configured, then this step is skipped as passwords are handled differently.
21.11.1 Imp	lement all Rules in the Web Interface Section
Category	LXI IPv6
Test Type	Kerberos Test, automated
Rule	Implement all Rules in the Web Interface Section
Explanation	Implement all the Rules in Section 9 – Web Interface.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	Web Interface
21.11.2 Incl	ude 'LXI IPv6' in Welcome Web Page "LXI Extended Functions"
Category	LXI IPv6
Test Type	Kerberos Test, automated
Rule	Include 'LXI IPv6' in Welcome Web Page "LXI Extended Functions"
Explanation	Devices implementing the LXI IPv6 function shall include 'LXI IPv6' in the 'LXI Extended Functions' display item of the welcome web page.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	1.4.6
21.11.3 Sho	w LinkLocal and Preferred IPv6 Addresses on Welcome Web Page
Category	LXI IPv6
Test Type	Kerberos Test, automated
Rule	Show LinkLocal and Preferred IPv6 Addresses on Welcome Web Page
Explanation	Add the following information to the LXI Welcome Page - Rule 9.2: - IPv6 Link-Local Address
	 Show at least one preferred Global addresses obtained through RA, DHCPv6 or Static addressing. If none are available then just show the link-local address. Optionally show any other scoped and preferred addresses obtained through RA, DHCPv6 or Static addressing such as Unique-Local addresses.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	21.3.1 21.3.2



21.11.6	Show Static IPv6 Settings on LAN Configuration Web Page
Category	LXI IPv6
Test Type	Kerberos Test, manual
Rule	Show Static IPv6 Settings on LAN Configuration Web Page
Explanation	Section 9.5 describes the information that needs to be present to configure an IPv4 device. The hostname and description are common for both IPv4 and IPv6 so this only needs to be present once.
	If the device supports Static IP mode, on IPv6, then the following settings need to be on the IP Configuration Page and configurable by the user of the device:
	- IPv6 Configuration Mode1 - IPv6 address 2 - Prefix Length - Default Gateway3 - DNS Server(s)4
	The IPv6 Configuration Mode field controls how the IP address for the instrument is assigned. For the manual configuration mode, the static IP address, prefix length, and default gateway are used to configure the LAN. The automatic configuration mode uses Autoconfiguration addressing (RA and DHCPv6 ¡V if implemented), as described in section 21.2 to obtain the instrument IP address(es).
Pre Conditio	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single IXI service and retrieve its IP address
	Enable IPv6 via Common Configuration Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCPEnabled attribute
	Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnabled attribute
	Enable IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticAddressEnabled Disable IPv6 staticAddressEnabled attribute via Common Configuration.
	Enable IPv6 RA router
	Enable IPv6 RA address assignment on the router. Ensure the DUT has no DHCP address any more. Ensure the DUT has a RA address.
	Connect DUT
	Connect the DUT to the test network
	Get RA IPv6 from mdns
	Get the RA address only via mDNS.
Test Procedu	ure Open web page in browser
	Prompt tester to open the devices web page



	Open IPv6 LAN configuration web page
	Prompt the tester to open the IPv6 LAN configuration webpage of the device-under-test (DUT).
	Query IPv6 LAN Item IPv6 Configuration Mode
	Prompt tester to check availability to configure the 'IPv6 Configuration Mode' on the 'IPv6 LAN Configuration Web Page'
	Query IPv6 LAN Item IPv6 address
	Prompt tester to check availability to configure the 'IPv6 address' on the 'IPv6 LAN Configuration Web Page'
	Query IPv6 LAN Item Prefix Length
	Prompt tester to check availability to configure the 'Prefix Length' on the 'IPv6 LAN Configuration Web Page'
	Query IPv6 LAN Item Default Gateway
	Prompt tester to check availability to configure the 'Default Gateway' on the 'IPv6 LAN Configuration Web Page'
	Query IPv6 LAN Item DNS Server(s)
	Prompt tester to check availability to configure the 'DNS Server(s)' on the 'IPv6 LAN Configuration Web Page'
21.11.7	Add a Stack Disable Option to the Configuration Mode.
_	

Category LXI IPv6

category		
Test Type	Kerberos Test, automated	
Rule Add a Stack Disable Option to the Configuration Mode.		
Explanation Devices shall have independent options to disable IPv4 and IPv6.		
Test Procedure	Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	21.1.8 21.1.10	
21.11.8 Disp	lay of Status for Disabled IP Protocols	
Category	LXI IPv6	
Test Type	Kerberos Test, manual	
Rule	Display of Status for Disabled IP Protocols	
Explanation	The following rules shall be followed when displaying the status of disabled IP Protocols:	
	1) The configuration display of disabled IP protocols shall show the various configuration fields for IPv4 or IPv6.	
	2) The configuration display of disabled IP protocols shall show the IPv4 or IPv6 Configuration	

ion Mode, and show either the text "Disabled", the text "-", or a blank field in place of the IP address when the corresponding IP protocol is disabled.

Pre Condition Connect DUT

Connect the DUT to the test network

Get RA IPv6 from mdns

Get the RA address only via mDNS.



Test Procedure	Disable IPv6 stack	
	Prompt the tester to disable the IPv6 stack on the DUT. This may not b possible)e
	Note: Some devices may not be able to disable the stack, but traffic ca still be prevented via the firewall.	in
	Open web page in browser	
	Prompt tester to open the devices web page	
	Query Home Item Value TCP/IP Address	
	Prompt tester for the 'TCP/IP Address' on the 'Welcome Web Page'	
	Evaluate IP addresses	
	Evaluate the given addresses for IPv4 addresses (DHCP, Auto-IP) and IPv6 addresses (link-local, RA and/or DHCP address).	
	Disable IPv4 stack	
	Prompt the tester to disable the IPv4 stack on the DUT. Note: Some devices may not be able to disable the stack, but traffic ca still be prevented via the firewall.	яn
	Open web page in browser	
	Prompt tester to open the devices web page	
	Query Home Item Value TCP/IP Address	
	Prompt tester for the 'TCP/IP Address' on the 'Welcome Web Page'	
	Evaluate IP addresses	
	Evaluate the given addresses for IPv4 addresses (DHCP, Auto-IP) and IPv6 addresses (link-local, RA and/or DHCP address).	
21.12.2 Supp	ort IEEE-1588 via UDP over IPv6 for the Link-Local Scope	
Category	LXI IPv6	
Test Type	Kerberos Test, manual	
Rule	Support IEEE-1588 via UDP over IPv6 for the Link-Local Scope	
Explanation	The LXI IEEE-1588 Profile 1.0 recommends that UDP over IPv6 transport should be possible (Recommendation 2.6.2 – UDP over IPv6). If the device implements recommendation 21.12.7 then the device shall support IEEE-1588 via UDP over IPv6 for the link-local scope (FF02/16)	1
Pre Condition	Connect DUT	
	Connect the DUT to the test network	
	Get RA IPv6 from mdns	
	Get the RA address only via mDNS.	
	Open web page in browser	
	Prompt tester to open the devices web page	
	Open 1588 Sync configuration web page	
	Prompt tester to open the 1588 Sync configuration web page	
	Switch to 1588 IPv6	
	Prompt tester to switch the 1588 to use IPv6 instead of IPv4	
	Start management node	
	Start up the PTP management node	
	Start ordinary clock	
	Start up the PTP clock	
	Initialize all clocks	
	Send a management message INITIALIZE to all clocks.	



Test Procedure	Set DUT to Slave
	Set the local clock to master by setting a high priority value (e.g. 0) and ensuring the DUT is set to a lower priority value (e.g. 128)
	Ensure DUT is Slave
	Wait for the DUT to be slave and the local clock master.
	Wait for stable meanPathDelay of Slave
	Wait for the meanPathDelay to be stable. Retrieve the meanPathDelay via a CURRENT_DATA_SET management message to the Slave.
	Set DUT to Master
	Set DUT as target, get local port identity and DUT announce interval plus the calculated interval. Subsequently Switch local clock to slave. Give the DUT time and Ensure DUT is Master and stable mean path delay.
	Ensure DUT is Master
	Wait for the DUT to be master and the local clock slave.
	Wait for stable meanPathDelay of Slave
	Wait for the meanPathDelay to be stable. Retrieve the meanPathDelay via a CURRENT_DATA_SET management message to the Slave.
Post Condition	Reset local clock
	Reset all clock modifications done to the local clock during this test (e.g. priority, log announce interval, special stack modifications etc.)
	Shutdown ordinary clock
	Shutdown the PTP clock
	Shutdown management node
	Shutdown the PTP management node
	Switch to 1588 IPv4
	IPv4 and IPv6 shall be exclusivly enabled. This teststep shall switch the DUT to use 1588 with IPv4.
21.12.3 Supp	ort selecting IPv4 or IPv6 for IEEE-1588
Category	LXI IPv6
Test Type	Kerberos Test, manual
Rule	Support selecting IPv4 or IPv6 for IEEE-1588
Explanation	If you implement recommendation 21.12.1 then you shall abide by this rule.
	IEEE-1588 running on IPv6 is not compatible with IEEE-1588 running on IPv4 because you can't have 2 master clocks.
	LXI IPv6 compliant devices shall have the ability to select which IP protocol to run over: IPv4 or IPv6 and they shall never allow both to be enabled. This configuration option should be located on the LXI Sync Web page.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get RA IPv6 from mdns
	Get the RA address only via mDNS.
Test Procedure	Open web page in browser
	Prompt tester to open the devices web page



	Open 1588 Sync configuration web page
	Prompt tester to open the 1588 Sync configuration web page
	Query 1588 Sync Item Select IPv4/IPv6
	Prompt tester to check availability to configure the 'IPv4/IPv6 mode' on the '1588 Sync Configuration Web Page'
	Is Select IPv4/IPv6 mutually exclusive
	Prompt tester to check the 'IPv4/IPv6 mode' on the '1588 Sync Configuration Web Page' is mutually exclusive
21.12.4 Cha	nges to LXI Sync Web Page
Category	LXI IPv6
Test Type	Kerberos Test, manual
Rule	Changes to LXI Sync Web Page
Explanation	If you implement recommendation 21.12.1, then you shall abide by this rule.
	There are no changes needed to the LXI Sync Web page if the IEEE-1588 stack only supports IPv4. If it supports either then the device shall add the ability to select which protocol the IEEE-1588 stack is supposed to use.
	If the Current Grandmaster clock and Parent clock are identified by IP address then they shall show the IPv6 addresses if the IEEE-1588 stack was using IPv6. The normal nomenclature for these 2 parameters is to show the EUI-64 identifier.
Pre Condition	Connect DUT
	Connect the DUT to the test network
	Get RA IPv6 from mdns
	Get the RA address only via mDNS.
Test Procedure	Open web page in browser
	Prompt tester to open the devices web page
	Open 1588 Sync configuration web page
	Switch to 1588 IDv6
	Prompt tester to switch the 1588 to use IPv6 instead of IPv4
	Have all IP addresses converted to IPv6
	Prompt tester to check all IP addresses on the '1588 Sync Configuration Web Page' have converted to IPv6 addresses.
21.13.2 Use	IPv6 Multicast Address and Port Number
Category	LXI IPv6
Test Type	Kerberos Test, automated
Rule	Use IPv6 Multicast Address and Port Number
Explanation	If you implement recommendation 21.13.1, then you shall abide by this rule.
	LXI Devices shall use the IANA registered IPv6 multicast address of FF02::138 for LXI Event Message transmission using UDP multicast.
	The default IANA registered port number is 5044 for LXI Event Messages—user configuration may override this default.



Test Procedure	NOT SUPPORTED	
		This test is currently not implemented. If the configuration would expect this test to run, then it will fail. Otherwise it will pass with message 'not supported'.
21.14.1 Supp	ort IPv6 access to Ider	tification XML Document
Category	LXI IPv6	
Test Type	Kerberos Test, autor	nated
Rule	Support IPv6 access	to Identification XML Document
Explanation	The LXI XML Identifi	cation document shall be accessible via IPv6.
Pre Condition	Enable IPv4 DHCP r	outer
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	Soarch via mans for a single ly sonvice and retrieve its IP address
	Enable IPv6 via Com	Search via mutis for a single in service and retrievents in address
		Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCPEr	nabled attribute
		Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnab	led attribute
		Enable IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticA	ddressEnabled
		Disable IPv6 staticAddressEnabled attribute via Common Configuration.
	Enable IPv6 RA rout	er Enable IDvé RA address assignment on the router
		Ensure the DUT has a RA address.
	Connect DUT	
		Connect the DUT to the test network
	Get RA IPv6 from m	dns
		Get the RA address only via mDNS.
Test Procedure	Get identification file	e Get the identification file from the device under test
21.14.2 Includ	de LXI IPv6 Address in	<interface></interface>
Category	LXI IPv6	
Test Type	Kerberos Test, autor	nated
Rule	Include LXI IPv6 Add	dress in <interface></interface>
Explanation	If an IPv6 global add global address is av	dress is available devices shall include it in an XML element. If no IPv6 ailable, devices shall include the link-local IPv6 address in an XML element.
Pre Condition	Enable IPv4 DHCP r	outer Enable the dhcp router for IPv4
	Connect DUT	

Connect the DUT to the test network



	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	Enable IPv6 via Common Configuration
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCPEnabled attribute Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnabled attribute
	Enable IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticAddressEnabled
	Disable IPv6 staticAddressEnabled attribute via Common Configuration.
	Disable IPv6 router
	Disable the IPv6 router so that neither RA nor DHCPv6 addresses are being assigned.
	Disconnect DUT
	Disconnect the DUT from the test network
	Connect DUT
	Connect the DUT to the test network
	Get Link-local IPv6 from mdns
	Get the IPv6 link-local address only via mDNS.
	Get identification file
	Get the identification file from the device under test
Test Procedure	Get IPv6 <interface> tag</interface>
	Get the IPv6 tag from the lxi identification file.
	Evaluate IPv6 addresses
	Evaluate the given IPv6 addresses for link-local, RA and/or DHCP address.
	Enable IPv6 RA router
	Enable IPv6 RA address assignment on the router. Ensure the DUT has no DHCP address any more. Ensure the DUT has a RA address.
	Get identification file
	Get the identification file from the device under test
	Get IPv6 <interface> tag</interface>
	Get the IPv6 tag from the lxi identification file.
	Evaluate IPv6 addresses
	Evaluate the given IPv6 addresses for link-local, RA and/or DHCP address.
21.14.3 IP 1	Гуре is "IPv6"
Category	LXI IPv6
Test Type	Kerberos Test, automated
Rule	IP Type is "IPy6"

Explanation Devices shall use "IPv6" as the IP type for the IPv6 address element.

Pre Condition Enable IPv4 DHCP router

Enable the dhcp router for IPv4



	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	Enable IPv6 via Com	mon Configuration
		Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCPEn	abled attribute
		Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnable	ed attribute
		Enable IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticAd	dressEnabled
		Disable IPv6 staticAddressEnabled attribute via Common Configuration.
	Enable IPv6 RA route	r
		Enable IPv6 RA address assignment on the router. Ensure the DUT has no DHCP address any more. Ensure the DUT has a RA address.
	Connect DUT	
		Connect the DUT to the test network
	Get RA IPv6 from mo	Ins
		Get the RA address only via mDNS.
	Get identification file	
		Get the identification file from the device under test
Test Procedure	Get IPv6 <interface></interface>	tag
		Get the IPv6 tag from the lxi identification file.
	Evaluate Interface att	tribute 'Type'
		Evaluate the IPv6 interface tag attribute Type for the value: "IPv6"
21.14.5 Includ	le LXI IPv6 Address in	<gateway></gateway>
Category	LXI IPv6	
Test Type	Kerberos Test, autom	nated
Rule	Include LXI IPv6 Add	ress in <gateway></gateway>
Explanation	If an IPv6 address foi element.	r the gateway is available, devices shall include it in the element of the IPv6
Pre Condition	Enable IPv4 DHCP ro	uter
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	Enable IPv6 via Com	mon Configuration
		Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCPEn	abled attribute
		Enable IPv6 DHCPEnabled attribute via Common Configuration.



	Enable IPv6 RAEnabled attribute		
	Enable IPv6 RAEnabled attribute via Common Configuration.		
	Disable IPv6 staticAddressEnabled		
	Disable IPv6 staticAddressEnabled attribute via Common Configuration	٦.	
	Enable IPv6 RA router		
	Enable IPv6 RA address assignment on the router.		
	Ensure the DUT has no DHCP address any more.		
	Ensure the DUT has a RA address.		
	Connect DUI		
	Get KA IPV6 from mans		
	Cat identification file		
	Get Identification file		
Test Drocedure			
lest Procedure	Get IPV6 <interface> tag</interface>		
	Evaluate < Galeway > element Evaluate the IPv6 interface element tag is available		
	Evaluate the involute clement tag is available.		
21.14.6 Show	w LXI Prefix length in <subnetmask></subnetmask>		
Category	LXI IPv6		
Test Type	Kerberos Test, automated		
Rule	Show LXI Prefix length in <subnetmask></subnetmask>		
Explanation	Devices shall show the prefix length in the element of the IPv6 element.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
	Enable IPv6 via Common Configuration		
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IP is supported)	v6	
	Enable IPv6 DHCPEnabled attribute		
	Enable IPv6 DHCPEnabled attribute via Common Configuration.		
	Enable IPv6 RAEnabled attribute		
	Enable IPv6 RAEnabled attribute via Common Configuration.		
	Disable IPv6 staticAddressEnabled		
	Disable IPv6 staticAddressEnabled attribute via Common Configuration	٦.	
	Enable IPv6 RA router		
	Enable IPv6 RA address assignment on the router.		
	Ensure the DUT has no DHCP address any more.		
	Connect DUT		
	Connect the DUT to the test network		



	Get RA IPv6 from mdns	
	Get the RA address only via mDNS.	
	Get identification file	
	Get the identification file from the device under test	
Test Procedure	Get IPv6 <interface> tag</interface>	
	Get the IPv6 tag from the lxi identification file.	
	Evaluate <subnetmask> element</subnetmask>	
	Evaluate the IPv6 interface element tag is available.	
21.14.7 Inclu	ude the LXI IPv6 Function in the <lxiextendedfunctions> element</lxiextendedfunctions>	
Category	LXI IPv6	
Test Type	Kerberos Test, automated	
Rule	Include the LXI IPv6 Function in the <lxiextendedfunctions> element</lxiextendedfunctions>	
Explanation	LXI devices implementing IPv6 shall include a element in the XML element with the FunctionName attribute of "LXI IPv6" and a Version attribute containing the version number of this document.	
	Example:	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	Enable IPv6 via Common Configuration	
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)	
	Enable IPv6 DHCPEnabled attribute	
	Enable IPv6 DHCPEnabled attribute via Common Configuration.	
	Enable IPv6 RAEnabled attribute	
	Enable IPv6 RAEnabled attribute via Common Configuration.	
	Disable IPv6 staticAddressEnabled	
	Disable IPv6 staticAddressEnabled attribute via Common Configuration.	
	Enable IPv6 RA router	
	Enable IPv6 RA address assignment on the router.	
	Ensure the DUT has a RA address.	
	Connect DUT	
	Connect the DUT to the test network	
	Get RA IPv6 from mdns	
	Get the RA address only via mDNS.	
	Get identification file	
	Get the identification file from the device under test	
Test Procedure	Get 'ExtendedFunctions'	
	Get all Extended Functions given by the LXI identification file.	



Evaluate IPv6 extended function

Evaluate the IPv6 extended function tag from the XML identification file. Ensure a version is given along with the function name.



22.0 LXI Security Extended Function

Categories	LXI Security	
22.8 LXI	Security Web Interface	
Category	LXI Security	
Test Type	Kerberos Test, automated	
Rule	LXI Security Web Interface	
Explanation	Devices implementing the LXI Security Extended Function shall include 'LXI Security' in the 'LXI Extended Functions' display item of the welcome web page.	
Test Procedure	Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	1.4.6	
22.8.1 LXI	Security Web Page unsecure Mode Indication	
Category	LXI Security	
Test Type	Kerberos Test, manual	
Rule	LXI Security Web Page unsecure Mode Indication	
Explanation	LXI Secure devices shall provide an indication on the LXI welcome web page if they are currently operating in the unsecure Mode.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
TURNEL	Search via mons for a single lxi service and retrieve its IP address	
lest Procedure	GET the Common Configuration	
	succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Set the DUT to Non-Unsecure Mode	
	Set all the Interface attributes value to Non-unsecure, which has impact on unsecure mode.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Query unsecure mode indicator	
	Open the LXI welcome page and visually check the welcome page that the DUT has an unsecure mode indicator.	



Loop next 6 Steps for unsecure mode indication Loop over the next 6 Steps for unsecure mode indication of several attributes. Currently following list is taken into account, but may be extended in the furture: Http::operation IPv6::privacyModeEnabled Hislip::mustStartEncrypted Hislip::encryptionMandatory Telnet::tlsRequired VXI11::enabled ScpiRaw::enabled. Set unsecure Mode for specific Interface attribute Enable each attribute, which has impact on unsecure mode. **PUT Common Configuration** PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used Query unsecure mode indicator Open the LXI welcome page and visually check the welcome page that the DUT has an unsecure mode indicator. Set Non-unsecure Mode for specific Interface attribute Set back the Interface attribute value to Non-unsecure. **PUT Common Configuration** PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used. Query unsecure mode indicator Open the LXI welcome page and visually check the welcome page that the DUT has an unsecure mode indicator. **LXI Security XML Identification Document** Category LXI Security

- Test TypeKerberos Test, automatedRuleLXI Security XML Identification DocumentExplanationLXI devices implementing LXI Security extended function shall include Function elements for
the LXI Security Extended Function. The Function element are contained in the XML Device
element. With the FunctionName attribute of "LXI Security" and a Version attribute containing
the version number of this document.Test ProcedureComputed by other tests
This test is computed by the result of other tests.
- Dependencies 10.2.5

22.9

22.10.1 unsecure Mode

Category	LXI Security
Test Type	Kerberos Test, automated
Rule	unsecure Mode



Explanation	An LXI Secure device is considered unsecure if its configuration enables protocols or behaviours that are known to be unsecure. If any part of a device configuration is known to explicitly enable unsecure operation, the device operates in unsecure mode.		
Test Procedure	Computed by other test	ts	
	Th	nis test is computed by the result of other tests.	
Dependencies	23.10.8		
	23.10.9		
	23.10.10		
	23.10.11		
	23.10.12		
	23.10.13		
	23.10.14		
	23.10.15		
	23.10.10		
	23.10.18		
	a l 11 11 1		
22.10.1.1 Vendo	ors Shall Indicate unsecure	e for non-LXI device Settings	
Category	LXI Security		
Test Type	Kerberos Test, automate	ed	
Rule	Vendors Shall Indicate unsecure for non-LXI device Settings		
Explanation	Devices shall also indicate they are operating in an unsecure Mode if settings beyond the scope of LXI Security are considered by the device manufacturer to be unsecure.		
Pre Condition	Enable IPv4 DHCP router		
	Er	nable the dhcp router for IPv4	
	Connect DUT		
	Co	onnect the DUT to the test network	
	Get IP from mdns		
	Se	earch via mdns for a single lxi service and retrieve its IP address	
	GET Common Configura	ation	
	GI su de	ET the Common Configuration from the device. Expect the call to acceed. Authentication is given, the correct URL is being used and the evice is setup correctly.	
	Set the DUT to Non-Un	secure Mode	
	Sectine 201 to Holl on	at all the Interface attributes value to Non-unsecure, which has impact	
	or	n unsecure mode.	
	PUT Common Configura	ation	
	PL A	JT Common Configuration and expect a valid response from the DUT. valid port is used, authorization is given and the correct URL is being	
	GET Common Configura	ation	
	GI GI Su de	ET the Common Configuration from the device. Expect the call to acceed. Authentication is given, the correct URL is being used and the evice is setup correctly.	



	Check unsecure indicator state
	Verify the unsecure indicator state through Common Configuration. It can be true/false as per expected result. If the MustStartEncrypted is set to true and EncryptionMandatory is set to false, the unsecure flag should be true and vice versa. In the case both attributes are true,the unsecure flag should be false
Test Procedure	Verify each vendor specific protocol that have impact on unsecure Mode
	Find out and verify all the additional Interface elements that impact unsecure Mode.
	Set unsecure Mode for specific Interface attribute
	Enable each attribute, which has impact on unsecure mode.
	Check unsecure mode for interface is true
	Check the unsecure mode of the interface is set to true in the Common Configuration.
	Set Non-unsecure Mode for specific Interface attribute
	Set back the Interface attribute value to Non-unsecure.
	Check unsecure mode for interface is false
	Check the unsecure mode of the interface is set to false in the Common Configuration.
22.10.2 Mult	iple LAN Interfaces supporting LXI Security
Category	LXI Security
Test Type	Kerberos Test, automated
Rule	Multiple LAN Interfaces supporting LXI Security
Explanation	If multiple LAN network interface cards (NICs) are present in an LXI Secure device, those that are LXI compliant shall support the LXI Security Extended Function.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	7.7
22.11.1 Supp	ort IPv4 Secure Configuration
Category	LXI Security
Test Type	Vendor Declaration
Rule	Support IPv4 Secure Configuration
Explanation	All LXI Devices implement IPv4. LXI Secure devices shall implement the secure requirements for

IPv4 in this section and the LXI API Extended Function specification.

22.11.2	Support IPv6 Secure Configuration
Category	LXI Security
Test Type	Vendor Declaration
Rule	Support IPv6 Secure Configuration
Explanation	Devices that implement IPv6 capability and LXI Security shall implement the secure requirements for IPv6 in this section and the LXI API Extended Function specification. This requirement shall be followed regardless of if a device complies with the LXI IPv6 extended function.



22.11.3	Ignore mDNS Unicast Queries From Outside the Local Link
Category	LXI Security
Test Type	Vendor Declaration
Rule	Ignore mDNS Unicast Queries From Outside the Local Link
Explanation	Since it is possible for an mDNS unicast query to be received from a machine outside the local link, LXI Secure devices shall check that the source address in the mDNS query packet matches the local subnet for that link (or, in the case of IPv6, the source address has an on-link prefix) and silently ignore the packet if not. This behaviour is as recommended in RFC6762
22.12.1	IEEE 802.1AR Compliance
Category	LXI Security
Test Type	Vendor Declaration
Rule	IEEE 802.1AR Compliance
Explanation	 LXI Security compliant devices shall comply with the device requirements stated in IEEE 802.1AR with the following caveats: 1. IEEE 802.1AR has a detailed description of the DevID module. In general, LXI Secure device software has no such module externally visible, thus those requirements do not directly bear on an LXI device although the device implementation is expected to substantially follow those requirements. This may be ideally accomplished through either a physical or firmware HSM in conjunction with the LXI Security API. LXI Security does require an API that includes several certificate management features similar to the DevID Module requirements, see the LXI API Extended Function. 2. IEEE 802.1AR 6.4 implies that DevID certificates can be validated using a CA root certificate as the trust anchor. Although not clearly in conflict with IEEE 802.1AR, LXI Security explicitly permits devices to use self-signed certificates in their DevID, thus making the self-signed certificate itself the trust anchor. 3. IEEE 802.1AR section 5.5, Supplier Requirements, places several requirements on the supplier which are beyond the scope of LXI and are not placed on the device vendor by LXI.
22.12.2	Use the Most Recently Provisioned DevID
Category	LXI Security
Test Type	Kerberos Test, automated
Rule	Use the Most Recently Provisioned DevID
Explanation	If any LDevID has been provisioned to the device, the IDevID shall not be used, regardless of the cryptographic suite of the LDevID. Unless explicitly configured otherwise, devices shall use the most recently provisioned valid certificate for each cryptographic suite that the device supports to authenticate itself regardless of the protocol being used.
Pre Conditio	n Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	Remove all Certificates
	Delete all certificates on the dut via the delete-certificate API.
	Get the IDevId Certificate Get the IDevId Certificate from the DUT by requesting a list of certificates via the API.
Test Procedu	Ire Verify device is using IDevID Get the IDevId certificate and check its the used one.



Create self-signed certificate with unsupported signature algorithm
Use create-certificate api to send an api request with an unsupported signature algorithm. Expect a Bad Request as response, with a list of all supported ones.
Read LxiProblemDetails for supported signature algorithms
Read out the list of supported signature algorithms from the LxiProblemDetails
Create self-signed certificate for each supported signature algorithm
Create a self-signed certificate for each signature algorithm via the create-certificate API
Check latest certificate is used
Check that the latest certificate is always used when creating a new certificate.
Get each new certificate via API
Get each of the new certificates via the API and the GUID.
Verify certificate has correct crypto hash
Check that every certificate was created with the correct crypto hash.

22.12.3.1 Distinguished Name

Category	LXI Security
Test Type	Kerberos Test, automated
Rule	Distinguished Name
Explanation	Subject Distinguished Name (DN) – field shall have the attributes as explained in the documentation
Pre Condition	Get certificates
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS
Test Procedure	Get IDevID Certificate from the device
	Get the IDevID Certificate from the device via API. Use the identified GUID from the certificate list to receive the correct certificate.
	Check certificate for attributes
	Check whether the certificate attributes CommonName, Organization, OrganizationUnit and SerialNumber have been set.
	Create self-signed certificate with attributes
	Create a self-signed certificate via API, with the CommonName, Organization, OrganizationUnit, and SerialNumber attributes set.
	GET Certificate for GUID
	GET certificate via the API /lxi/certificates/ <guid> using the appropriate GUID.</guid>
	Check certificate for attributes
	Check whether the certificate attributes CommonName, Organization, OrganizationUnit and SerialNumber have been set.
2 12 2 2 Subia	h Altowate News

22.12.3.2 Subject Alternate Name

Category	LXI Security
Test Type	Kerberos Test, automated
Rule	Subject Alternate Name



Explanation	Devices that have a hardware or firmware HSM shall have a SAN field, see documentation
Pre Conditio	Vendor declared HSM availability
	Check if a HSM is available by checking the test configuation.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check HSM value
	Check the vendor declaration whether a Hardware Security Module (HSM) is required.
	Get certificates
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS
Test Procedu	Get IDevID Certificate from the device
	Get the IDevID Certificate from the device via API. Use the identified GUID from the certificate list to receive the correct certificate.
	Get 'HW Module Name' from certificate
	Retrieve the Certificate Subject Alternative Names and look for the value 'HW Module Name', if the vendor declaration is set to require a Hardware Module name.
	Create self-signed certificate with attributes
	Create a self-signed certificate via API, with the CommonName, Organization, OrganizationUnit, and SerialNumber attributes set.
	GET Certificate for GUID
	GET certificate via the API /lxi/certificates/ <guid> using the appropriate GUID.</guid>
	Get 'HW Module Name' from certificate
	Retrieve the Certificate Subject Alternative Names and look for the value 'HW Module Name', if the vendor declaration is set to require a Hardware Module name.
22.13.1	Secure Command-and-Control Interface
Category	LXI Security
Test Type	Vendor Declaration
Rule	Secure Command-and-Control Interface
Explanation	LXI Secure devices shall provide at least one secure Command-and-Control interface. That is, a protocol that provides encryption and server authentication (e.g., IVI HiSLIP rev2.0, HTTPS, etc.).
22.13.2	Client Authentication Configuration
Category	LXI Security
Test Type	Vendor Declaration
Rule	Client Authentication Configuration
Explanation	At least one Command-and-Control protocol shall provide a configuration that requires client authentication.



22.13.3	unsecure Command-and-Control Interfaces
Category	LXI Security
Test Type	Vendor Declaration
Rule	unsecure Command-and-Control Interfaces
Explanation	LXI Secure devices implementing unsecure Command-and-Control interfaces shall provide settings to control which of these protocols are enabled.
22.13.4	HiSLIP Devices Supported SASL Mechanisms
Category	LXI Security
Test Type	Kerberos Test, automated
Rule	HiSLIP Devices Supported SASL Mechanisms
Explanation	LXI Secure devices that implement the HiSLIP extended function shall support client authentication using the SASL mechanisms of ANONYMOUS, PLAIN, and SCRAM.
Test Procedu	re Computed by other tests
	This test is computed by the result of other tests.
Dependencie	23.12.13.1-1 23.12.13.1-2 23.12.13.1-5 23.12.13.1-7
22.13.5	Devices Shall Support IVI 6.5, SASL Mechanism Specification
Category	LXI Security
Test Type	Kerberos Test, automated
Rule	Devices Shall Support IVI 6.5, SASL Mechanism Specification
Explanation	LXI Secure devices that implement the HiSLIP extended function shall support client authentication using the SASL mechanisms of ANONYMOUS, PLAIN, and SCRAM.
Test Procedu	re Computed by other tests
	This test is computed by the result of other tests.
Dependencie	23.12.13.1-6 23.12.17.1-2
22.14	LXI API Security Methods
Category	LXI Security
Test Type	Kerberos Test, automated
Rule	LXI API Security Methods
Explanation	Devices shall provide the APIs defined in the LXI API Extended Function.
Test Procedu	re Computed by other tests
	This test is computed by the result of other tests.
Dependencie	IS LXI API



23.0 LXI API Extended Function

Categories	LXI Api
23.5.1	Devices Comply with Current Schemas
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Devices Comply with Current Schemas
Explanation	The LXI schema's may be updated from time to time. The LXI Conformance Policy indicates the minimum versions devices are required to conform to as part of conformance to a device specification version. Devices shall support schemas that are current at the time of their development, which may be minor revisions more recent than the minimum requirement of the conformance policy. Devices shall clearly indicate versions of the schema they support. Devices may also support older schema versions.
Test Procedur	re Computed by other tests
	This test is computed by the result of other tests.
Dependencie	s 23.10.8 23.10.9 23.10.10 23.10.11 23.10.12 23.10.13 23.10.14 23.10.15 23.10.16 23.10.16 23.10.17 23.10.18
23.6	Include 'LXI API' in the Welcome Web Page "LXI Extended Functions"
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Include 'LXI API'' in the Welcome Web Page "LXI Extended Functions"
Explanation	Devices implementing the LXI API Extended Function shall include 'LXI API' in the 'LXI Extended Functions' display item of the welcome web page.
Test Procedur	re Computed by other tests
Dependencie	This test is computed by the result of other tests.
Dependencie	5 1.4.6
23.7	Include the LXI API Function in the LXI Identification
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Include the LXI API Function in the LXI Identification
Explanation	Devices implementing LXI API Extended Function shall include a element in the XML element with the FunctionName attribute of "LXI API" and a Version attribute containing the version number of this document.
Pre Conditior	Enable IPv4 DHCP router Enable the dhcp router for IPv4



		Connect DUT	
			Connect the DUT to the test network
		Get IP from mdns	
			Search via mdns for a single lxi service and retrieve its IP address
		Get identification file	Cat the identification file for a the device under test
Tast Dragodu	150	Cat / Extanded Exmatic	Get the identification file from the device under test
iest Procedu	lie	Get ExtendedFunctio	Get all Extended Functions given by the LXL identification file
		Evaluate API Extende	ed Function
			Evaluate the API extended function tag from the XML identification file.
23.10.1	API Clie	nt Authentication ar	nd Authorization
Category		ΙΧΙΑΡΙ	
Tost Tupo		Korboros Tost autom	aatad
Rule		API Client Authentic	nation and Authorization
Evolution		API clients shall be a	high to authorizate themselves by providing an HTTP request header that
		supplies an authentic the device working in generated by the clie be included with the the customer to acqu provide the API key of	cation key. The authentication key may be generated by the device, or by in concert with external applications. The authentication key is not ent. When using API key authentication, the HTTP header X-API-Key shall HTTP request to provide the API key to the device. The procedure used by uire the API key is beyond the scope of LXI. However, devices shall not over Ethernet using an unsecure connection.
Test Procedu	ure	Send an api request	for each Lxi-Api without an authorization tag
			For each Lxi-Api (Common Configuration, Device Specific Configuration, all-certificates, specific-certificate, create-certificate, enable-certificate and csr-certificate) send a API request without authorization tag. Expect a '401 Unauthorized client' response, because its not allowed to get access to the Lxi-Api without authentication and authorization.
		Expect '401 Unautho	rized client' response
			Expect a '401 Unauthorized client' response, because its not allowed to get access to the Lxi-Api without authentication and authorization.
		Send API request for	each Lxi-Api without '/api/'
			For each Lxi-Api (Common Configuration, Device Specific Configuration and identification) send an API request without /api/ in the URL and no authorization tag. Expect a '200 OK' response, because none Lxi-Api's doesn't need an authorization tag
		Expect '200 OK' resp	onse
			Expect a '200 OK' response, because the request was valid.
23.10.1.1	API Key	Authentication	
Category		LXI API	
Test Type		Kerberos Test, autor	nated

Rule API Key Authentication



Explanation	API clients shall be able to authenticate themselves by providing an HTTP request header that supplies an authentication key. The authentication key may be generated by the device, or by the device working in concert with external applications. The authentication key is not generated by the client. When using API key authentication, the HTTP header X-API-Key shall be included with the HTTP request to provide the API key to the device. The procedure used by the customer to acquire the API key is beyond the scope of LXI. However, devices shall not provide the API key over Ethernet using an unsecure connection.	
Test Procedure	Send API request for each Lxi-Api with an authorization tag	
	For each Lxi-Api (Common Configuration, Device Specific Configuration, all-certificates, specific-certificate, create-certificate, enable-certificate and csr-certificate) send a API request with authorization tag. Expect Other response than 401 Unauthorized client response	
	Expect other response than '401 Unauthorized client response'	
	Expect other response than 401 Unauthorized client response, because the authentication is valid.	
23.10.1.2 H	ITTPS Basic and Digest Authentication	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	HTTPS Basic and Digest Authentication	
Explanation	API clients shall be able to authenticate themselves by providing HTTP Basic or Digest authentication per RFC7616/RFC7617 or whatever successors are current when the device is designed. The realm for the LXI API shall be "LXI-API". Per section 23.10.1.3, RULE – API Requires Authorization, authenticated users must also be authorized to use the full API. The users list in the ClientCredential element permits users to be designated as authorized.	

Pre Condition	Configure Username and password on the device
	PUT the Common Configuration with a username and password pair with api access to the device.
Test Procedure	Send api request for each api with basic authentication
	For each Lxi-Api (Common Configuration, Device Specific Configuration, all-certificates, specific-certificate, create-certificate, enable-certificate and csr-certificate), send a api request with basic authentication. Expect valid responses, unless otherwise stated in the next test step.

23.10.1.3 API Requires Authorization

Category	LXI API
Test Type	Kerberos Test, automated
Rule	API Requires Authorization
Explanation	The authority of authenticated users shall be verified before they are permitted to change the LXI Security Settings via any Ethernet protocol or interface. This specification requires two mechanisms by which users may be authorized: Authorized users may be specified to the device using the API defined in section 17, RULE – LXI Common Configuration PUT API. The user list in the ClientCredential element can be used to designated users as authorized using the APIAccess attribute. Thus, users presenting the name and password indicated in the ClientCredential are permitted to perform privileged operations. Users presenting a valid API Key are authorized. Other authorization determinations beyond the scope of LXI may be used as well. Such mechanisms must be used to initially authorize a user to use the API.



Pre Condition	Configure Username and password on the device without API access
	PUT the Common Configuration with a username and password pair with no api access to the device.
Test Procedure	Send api request for each api with basic authentication
	For each Lxi-Api (Common Configuration, Device Specific Configuration, all-certificates, specific-certificate, create-certificate, enable-certificate and csr-certificate), send a api request with basic authentication. Expect valid responses, unless otherwise stated in the next test step.
	Expect '401 Unauthorized client' response
	Expect a '401 Unauthorized client' response, because its not allowed to get access to the Lxi-Api without authentication and authorization.
	Send API request with incorrect API key
	Send an API request (e.g. Common Configuration) with an invalid API- Key and expect an 401 Unauthorized client response.
	Expect '401 Unauthorized client' response
	Expect a '401 Unauthorized client' response, because its not allowed to get access to the Lxi-Api without authentication and authorization.
23.10.2 Additio	onal Means of Authorization
Category	LXI API
Test Type	Vendor Declaration
Rule	Additional Means of Authorization
Explanation	LXI devices are permitted to implement additional means beyond the scope of this specification to authorize the API, however such means shall ensure that clients are fully authenticated and authorized.
23.10.3 LXI Cer	tificate and CSR GUIDs
Category	LXI API
Test Type	Kerberos Test, automated
Rule	LXI Certificate and CSR GUIDs
Explanation	Several of the LXI APIs reference either certificates, certificate chains or CSRs using a GUID. The GUID is created and managed by the device and shall be made up of an arbitrary string of alpha-numerics and hyphens. CSRs may be deleted by the user or, from time-to-time, expire on the device. See section 23.10.16.1, RULE – Minimum CSR Retention, for LXI requirements. The device shall ensure that GUIDs do not replicate under foreseeable circumstances including malicious client actions. When a certificate is posted to the device it shall receive a new GUID, and the GUID for the corresponding CSR shall not be used again.
Test Procedure	Create self-signed certificate with attributes
	Create a self-signed certificate via API, with the CommonName, Organization, OrganizationUnit, and SerialNumber attributes set.
	Get CSR
	Get CSK certificate via the /ixi/api/get-csr API.
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS
	Check GUIDs are alpha-numeric strings
	Check the GUID only contains alpha-numeric characters.



Check GUIDS are unique

Check the given GUIDS are unique within a certificates list receiied from the DUT.

23.10.4.1	XML Payloads Comply with LXI Schemas
Category	LXI API
Test Type	Kerberos Test, automated
Rule	XML Payloads Comply with LXI Schemas
Explanation	LXI provides XSD schemas for each of the LXI APIs that uses an XML payload. Devices shall produce schema-valid XML and accept and properly act on any schema-valid XML. Numerous requirements regarding the use and interpretation of the schema are included in the following sections regarding the schemas and shall be followed by devices.
Test Proced	ure Computed by other tests
	This test is computed by the result of other tests.
Dependenci	es 23.10.8 23.10.9 23.10.10 23.10.11 23.10.12 23.10.13 23.10.14 23.10.15 23.10.15 23.10.16 23.10.17 23.10.18
23.10.4.2	Response and Request headers
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Response and Request headers
Explanation	Devices shall return the specified response headers. Devices shall observe the request headers and ensure that a client presenting request payloads based on the LXI-specified payloads and syntaxes are accepted.
Test Proced	ure Computed by other tests
	This test is computed by the result of other tests.
Dependenci	es 23.10.8 23.10.9 23.10.10 23.10.11 23.10.12 23.10.13 23.10.13 23.10.14 23.10.15 23.10.15 23.10.16 23.10.17 23.10.18



23.10.4.3	HTTP Return Codes
Category	LXI API
Test Type	Kerberos Test, automated
Rule	HTTP Return Codes
Explanation	If an operation fails, the device shall return the appropriate HTTP status code.
Test Procedu	ure Computed by other tests
	This test is computed by the result of other tests.
Dependenci	es 23.10.8
	23.10.9
	23.10.10
	23.10.11
	23.10.12
	23.10.13
	23.10.15
	23.10.16
	23.10.17
	23.10.18
23.10.4.4	LXI Problem Details
Category	LXI API
Test Type	Kerberos Test, automated
Rule	LXI Problem Details
Explanation	When returning errors, devices shall return information regarding the failure using the LXIProblemDetails XML. The HTTP Response Header returned with LXI Problem Details shall be 'Content-Type:application/xml'.
Test Procedu	Ire Send a bad request
	Send a api request with an error like a syntax error to the device, using the API-Key.
	Check response for Problem Details xml
	Check the response from the previous API call for a Problems Details xml.
	Check xml against xsd
	Validate the xml against the corresponding xsd schema.
23.10.4.5	Operation Pending Response Handling
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Operation Pending Response Handling
Explanation	If an LXI API returns status 202, that is request pending, it shall return the LXIPendingDetails XML. The pending details permits the client to determine details about pending actions and determine when they are complete. Devices shall include a response header of: Content-Type: application/xml The LXIPendingDetails XML includes a URL at which the client can perform an HTTP GET to determine the status of the pending operation. The response from that URL shall either be status 200, OK, or a status of 202, accepted with a new LXIPendingDetails XML.
Test Procedu	Jre Send vendor given API
	Send the API given by tet configuration.

Report bases on file: LxiConformanceTestSuite_1.6.json



	Call URL given by Pending details
	Call the URL given by the Pending details API response.
	Evaluate if user action needed and time to wait
	Evaluate if user action is requried and/or time to wait is set.
23.10.4.5.1	Operations That Require User Action Return Operation Pending
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Operations That Require User Action Return Operation Pending
Explanation	If an LXI API requires user action, it shall return a status of 202, with the LXIPendingDetails XML without waiting for user intervention.
Test Procedu	ure Send vendor given API
	Send the API given by tet configuration.
	Call URL given by Pending details
	Call the URL given by the Pending details API response.
	Evaluate if user action needed and time to wait
	Evaluate if user action is requried and/or time to wait is set.
23.10.4.5.2	Accepted Response URL Expiration

Category	LXI API
Test Type	Kerberos Test, automated
Rule	Accepted Response URL Expiration
Explanation	As long as the operation remains pending each response shall return a status of 202 and an LXIPendingDetails XML. The subsequent responses are permitted to use a different URL, therefore the client must base subsequent GETs on the updated URL. The client performs a GET on the URL (which may return a fresh LXIPending response) or, The client executes another HTTP method that returns a pending status or, 1 hour has elapsed or, The device is rebooted. If the pending operation requires a reboot to complete, the URL may be invalid after the reboot, however, the device should attempt to provide a URL that will remain valid.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.10.4.5
22 10 6 2 Saba	Location on the device
23.10.0.3 SCHE	ווום וטכמנוטוו טוו נווב עבעונב

Category	LXI API
Test Type	Kerberos Test, automated
Rule	Schema location on the device
Explanation	Devices shall provide schemas for each payload produced or consumed by the device. The schemas, on a device, shall be located at the device URL from the HTTP(S) server ports that serve the specific API, in the directory lxi. Thus, the URL for the 1.0 release of the LXI Common Configuration schema shall be:http(s)://lxi/schemas/LXICommonConfiguration/1.0The schemas are also available on the LXI website in the directory schemas. Thus, the URL for the 1.0 release of the LXI Common Configuration Schema is: http(s)://lxi/schemas/LXICommonConfiguration/1.0The Schemas are also available on the LXI website in the directory schemas. Thus, the URL for the 1.0 release of the LXI Common Configuration Schema is: http(s)://lxistandard.org/lxi/schemas/LXICommonConfiguration/1.0
Test Procedure	Validate schema location for GET APIs
	Validate schema location for every GET API Url.

Report bases on file: LxiConformanceTestSuite_1.6.json



Validate schema location for APIs with Xml payload

Validate schema location for every API Url, except GET, which has an Xml as payload.

23.10.8 L	XI Common Configuration GET API
Category	LXI API
Test Type	Kerberos Test, automated
Rule	LXI Common Configuration GET API
Explanation	The LXI Common Configuration GET API returns the overall device LXI configuration. The configuration returned in the XML payload may meaningfully be applied to all devices in a system.
Test Procedure	GET Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check response header content-type for xml Check the previous API calls response header content-type for xml.
	Validate Xml against local schema Validate the response Xml against the appropriate local schema.
	Validate Xml against the schema on the device Validate the response Xml against the appropriate schema on the device.
23.10.8.1 T	he lxi/common-configuration Endpoint Elides User Lists
Category	LXI API
Test Type	Kerberos Test, automated
Rule	The lxi/common-configuration Endpoint Elides User Lists
Explanation	The lxi/common-configuration endpoint does not require client authentication, therefore, this response shall elide the user lists used for client authentication and authorization.
Test Procedure	Computed by other tests This test is computed by the result of other tests.
Dependencies	23.12.1.2-4
23.10.9 L	XI Common Configuration PUT API
Category	LXI API
Test Type	Kerberos Test, automated
Rule	LXI Common Configuration PUT API
Explanation	The LXI Common Configuration PUT API configures the common device LXI configuration. The configuration represented by the XML payload may meaningfully be applied to all devices in a system.
Pre Condition	GET Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	PUT Common Configuration PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.


	PUT Common Configuration without authorization PUT the Common Configuration with the URL /lxi/api/common- configuration without any authorization. Expect it to fail because of missing authorization. The failure should be '404 Unauthorized client'.
	PUT Common Configuration missing '/api/' in URL PUT Common Configuration using the URL /lxi/common-configuration. Expect failure as the endpoint does not exist.
23.10.9.1 Ignore	e Read-Only Attributes On Write
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Ignore Read-Only Attributes On Write
Explanation	There are several attributes in the LXI Common Configuration Schema that are read-only, that is, they are returned by the device as part of a GET, but they are not intended for use during a PUT. If a device receives Read-only attributes on a PUT it shall ignore them, and not treat them as an error.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.12.1.1-2 23.12.2.1-3 23.12.2.1-6
23.10.10 LXI De	evice Specific Configuration GET API
Category	LXI API
Test Type	Kerberos Test, automated
Rule	LXI Device Specific Configuration GET API
Explanation	The LXI Device Specific Configuration GET API returns device-specific configuration and capabilities as specified in the LXI Device Specific Configuration schema. The settings returned by this API are either potentially unique to a particular device or automatically configured. The two endpoints return the same response.
Test Procedure	GET Device Specific Configuration GET the Device Specific Configuration from device via API /lxi/api/device- specific-configuration using API-Key.
	Check response header content-type for xml Check the previous API calls response header content-type for xml.
	Validate Xml against local schema Validate the response Xml against the appropriate local schema.
	Validate Xml against the schema on the device
	Validate the response Xml against the appropriate schema on the device.
23.10.11 LXI De	evice Specific Configuration PUT API
Category	LXI API
Test Type	Kerberos Test, automated
Rule	LXI Device Specific Configuration PUT API



Explanation	The LXI Device Specific Configuration PUT API configures network settings that are device- specific or potentially automatically configured. Devices retain the LXI Device Specific configuration and only utilize it when automatic configuration is disabled. Thus, writing the LXI Device Specific configuration while automatic configuration is active then subsequently disabling automatic configuration will result in the device using the configuration specified in the LXI Device Specific configuration.	
Pre Condition	GET Device Specific Configuration	
	GET the Device Specific Configuration from device via API /lxi/api/device-specific-configuration using API-Key.	
Test Procedure	PUT Device Specific Configuration	
	PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.	
	PUT Device Specific Configuration without authorization tag	
	PUT the valid Device Specific Configuration to the device via device- specific-configuration API without an authorization tag. Expect an Error because of the missing authorization.	
	PUT Device Specific Configuration missing '/api/' in URL	
	PUT the Device Specific Configuration to the device via the API leaving away the '/api/' in the URL. Expect it to fail due to invalid endpoint.	
23.10.12 LXI	Certificates GET API	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	LXI Certificates GET API	
Explanation	The LXI Certificates GET API returns a listing of certificates, certificate chains, and outstanding CSRs on the device. This listing includes information specified in the LXICertificateList schema including GUIDs that identify each entity. These GUIDs may be used, for instance, to designate the LXI Certificate to the DEL method. CSRs may be deleted by the user or, from time-to-time, expire on the device. See section 23.10.16.1, RULE – Minimum CSR Retention, for LXI requirements.	
Test Procedure	Get certificates	
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS	
	Check response header content-type for xml	
	Check the previous API calls response header content-type for xml.	
	Validate Xml against local schema Validate the response Xml against the appropriate local schema.	
	Get certificates via API /lxi/certificates	
	Try to GET the certificates list via API /lxi/certificates, expect error due to invalid endpoint.	
23.10.13 LXI	Certificates POST API	
Category	LXI API	
Test Type	Kerberos Test, automated	

- Rule LXI Certificates POST API
- Explanation The LXI Certificates POST API provisions a certificate or certificate chain to the device to be used by the device to identify itself



Pre Condition	Get certificates			
		Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS		
Test Procedure	Get CSR			
		Get CSR certificate via the /lxi/api/get-csr API.		
	Get certificates			
		Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS		
	Create certificate fr	rom CSR		
		Create a self-signed certificate out of the Certificate Signing Request.		
	POST certificate			
		POST the certificate to the device via /lxi/api/certificates using the API- Key.		
	Check response he	ader content-type for xml		
		Check the previous API calls response header content-type for xml.		
	Validate Xml again	st local schema		
		Validate the response Xml against the appropriate local schema.		
	GET Certificate for	GUID		
		GET certificate via the API /lxi/certificates/ <guid> using the appropriate GUID.</guid>		
	Match returned cer	Match returned certificate to created certificate		
		Compare the values from the certificate with the values in the created one for a match.		
	Get certificates, check for CSR GUID			
		Get the certificates list from device and check for CSR GUID within the list.		
	POST certificate, expect failure missing CSR			
		Repost the certificate to the device and expect a failure as the CSR has been deleted inbetween.		
	Get CSR			
		Get CSR certificate via the /lxi/api/get-csr API.		
	Create certificate fr	om CSR		
		Create a self-signed certificate out of the Certificate Signing Request.		
	POST certificate, ex	pect failure		
		POST certificate via /lxi/certificate and expect an error due to endpoint not available.		
	Get certificates, expect new GUID in list			
		Get the certificates list from the device and expect the new GUID to be returned in the list additionally to the original list retrieved previously.		
	POST certificate created without CSR from the device			
		POST a self-signed certificate to the device which was not created from a CSR retrieved from the device. Expect this POST to fail, as a posted certificate shall match a CSR on the device.		

23.10.14 LXI Certificate GET API

Category	LXI API
Test Type	Kerberos Test, automated



Rule	LXI Certificate GET API		
Explanation	The LXI Certificates/ <guid> GET API returns the certificate, certificate chain, or CSR identified by the <guid> incorporated into the URL. Note that the type of the response is dependent on the GUID.</guid></guid>		
Pre Condition	Get certificates		
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS		
	Ensure at least two LDevID's are available		
	Ensure at least two LDevIDs are available in the certificate list. If not create self-signed certificates on the device via the create-certificate API.		
	Ensure at least two CSR's are available		
	Ensure at least two CSR's are available in the certificate list. If not create them on the device via the get-csr API.		
	Get certificates		
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS		
Test Procedure	For each GUID in the GUID list:		
	GET Certificate for GUID		
	GET certificate via the API /lxi/certificates/ <guid> using the appropriate GUID.</guid>		
	Check response header content-type		
	Check the response header content-type. If the response is a certificate, then the content-type shall be pkcs10.		
	Check response header transfer-encoding for base64		
	If the response is a pkcs10, check the header transfer-encoding for base64.		
	GET Certificate for GUID		
	GET certificate via the API /lxi/certificates/ <guid> using the appropriate GUID.</guid>		
23.10.15 LXI C	Certificate DELETE API		
Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	LXI Certificate DELETE API		
Explanation	The LXI Certificates/ <guid> DELETE API deletes the certificate, certificate chain, or CSR identified by the <guid> incorporated into the URL.</guid></guid>		
Pre Condition	Get certificates		
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS		
	Ensure at least two LDevID's are available		
	Ensure at least two LDevIDs are available in the certificate list. If not create self-signed certificates on the device via the create-certificate API.		
	Ensure at least two CSR's are available		

Ensure at least two CSR's are available in the certificate list. If not create them on the device via the get-csr API.



	Get certificates		
		Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS	
Test Procedure	DELETE certificate via	the GUID	
		DELETE certificate via /lxi/api/certificates/ <guid> using API-Key.</guid>	
	Expect Error		
		Expect Error. This can have several reasons. For an API this may be an invalid endpoint, wrong data (such as invalid GUID). Check previous test step for indication of expected error.	
	Check no GUID was r	emoved	
		Get certificates from device and ensure no GUID was removed.	
	For each certificate w	hich is not an IDevID:	
		For each certificate which is not an IDevID, do the next steps.	
	Delete certificate, exp	ect failure	
		Delete the certificate using the API /lxi/certificate/ <guid> and expect an error due to endpoint not available.</guid>	
	DELETE certificate via	the GUID	
		DELETE certificate via /lxi/api/certificates/ <guid> using API-Key.</guid>	
	Get certificates and check guid was deleted		
		Get certificates from device and ensure the GUID is no more listed.	
	GET certificate for GU	IID, expect failure	
		GET certificate for a specific GUID and expect an error as the GUID is not available.	
	For each CSR:		
		Do the next steps for each CSR	
	DELETE CSR via the G	JUID	
		DELETE CSR via /lxi/api/certificates/ <guid> using API-Key.</guid>	
	Get CSR, expect failu	re	
		Get CSR via /lxi/api/certificates/ <guid> using API-Key and expect an error. No CSR with the given GUID available.</guid>	
23.10.16 LXI CSF	R GET API		

Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	LXI CSR GET API	
Explanation	The LXI CSR GET API acquires a PKCS#10 CSR from the device. The CSR is created based on the data in the LXICertificateRequest XML which includes the subject and other fields the client specifies for the CSR.	
Pre Condition	Create certificate request	
	Create a certificate request XML with values to use for an API call.	
Test Procedure	Get CSR	
	Get CSR certificate via the /lxi/api/get-csr API.	
	Check response header content-type for pkcs10	
	Check response header content-type for pkcs10. Pkcs10 is the format of a CSR.	
	Check response header transfer encoding for Base64	
	Check the response header transfer encoding is Base64.	



	Verify PEM file response	
	Check the format of the certificate signing request.	
	Ensure request parameters are within the PEM file	
	Check the parameters from the Certificate Request xml are within the retrieved certificate signing request.	
	Get CSR missing '/api/' in URL	
	Get CSR certificate via the /lxi/get-csr API and expect an error due to invalid endpoint.	
23.10.16.1 Min	nimum CSR Retention	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Minimum CSR Retention	
Explanation	Devices shall at least retain the most recently generated CSR for any given cryptography suite at least until a power cycle. Devices should retain CSRs longer than this to support other customer use models, especially those that require operator intervention.	
Pre Condition	Get certificates	
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS	
	Get CSR	
	Get CSR certificate via the /lxi/api/get-csr API.	
	Get certificates	
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS	
Test Procedure	Validate CSR lifetime	
	Identify the CSR GUID in the GUID list every 10 seconds. Ensure it stays available for a while.	
23.10.17 LXI	Create Certificate API	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	LXI Create Certificate API	
Explanation	In response to this call, the device shall create a new certificate (that is, an LDevID) to use to authenticate itself. This self-signed certificate shall be managed and presented to clients consistent with the requirements in the LXI Security Extended Function. If the device is unable to respect any of the fields specified in the LXICertificateRequest, the device shall return an error.	
Pre Condition	Create simple certificate request and values	
	Create simple certificate request and values to send to the DUT.	
Test Procedure	Create certificate	
	Create a certificate via PUT /lxi/api/create-certificate using API-Key.	
	Check response header content-type for xml	
	Check the previous API calls response header content-type for xml.	
	Validate Xml against local schema	

Validate the response Xml against the appropriate local schema.



	GET Certificate for GUID	
	GET certificate via the API /lxi/certificates/ <guid> using the appropriate GUID.</guid>	
	Check fields in certificate	
	Validate all fields from the certificate request are used for the certificate.	
	Create certificate with an invalid xml	
	Try to create a certificate with a faulty certificate request xml. Expect an error due to invalid certificate request xml.	
	Create certificate via PUT /lxi/create-certificate	
	Try to create a certificate via the endpoint /lxi/create-certificate. Expect an Error as endpoint shall not be available.	
23.10.18 LXI C	Certificate ENABLED API	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule		
Explanation	The LXI Certificates/ <guid>/enabled PUT API enables or disables the designated certificate or certificate chain identified by the <guid> incorporated into the URL.</guid></guid>	
Pre Condition	Get certificates	
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS	
	Ensure at least two certificates are available	
	Ensure at least two certificates are available, if not create them.	
Test Procedure	Identify currently used certificate	
	Identify currently used certificate. This can be done via HTTPS or HiSLIP.	
	Disable currently used certificate Disable currently used certificate via /lxi/api/certificates/ <guid>/enabled using API-Key</guid>	
	Verify device has stopped using the certificate	
	Verify the device has stopped using the certificate.	
	Get certificate enabled value	
	Read back value via /lxi/api/certificates/ <guid>/enabled using API-Key and check for enabled value.</guid>	
	Enable certificate	
	Enable the certificate via the API /lxi/api/certificates/ <guid>/enabled and the apropriate GUID and the boolean value true.</guid>	
	Verify the device is using the certificate	
	Verify the device is using the certificate again. This can be verified via HiSLIP or HTTPS webpages.	
	Get certificate enabled value	
	Read back value via /lxi/api/certificates/ <guid>/enabled using API-Key and check for enabled value.</guid>	
	Disable certificate missing '/api/' in URL	
	Disable the certificate via the URL /lxi/certificates/ <guid>/enabled using the apropriate GUID.</guid>	



23.10.18.1	LXILiterals Parameter to Enabled is Boolean
Category	LXI API
Test Type	Kerberos Test, automated
Rule	LXILiterals Parameter to Enabled is Boolean
Explanation	The LXILiterals schema permits arbitrarily typed attributes. The request LXILiterals parameter to enabled shall be an attribute of name value and of type xs:boolean. The value of the Boolean attribute indicates if the certificate or certificate chain identified by the <guid> is enabled.</guid>
Test Proced	lure Computed by other tests
	This test is computed by the result of other tests.
Dependenc	cies 23.10.18
23.10.18.2	LXILiterals Response to Enabled is Boolean
Category	LXI API
Test Type	Kerberos Test, automated
Rule	LXILiterals Response to Enabled is Boolean
Explanation	The LXILiterals schema permits arbitrarily typed attributes. The response LXILiterals parameter to enabled shall be an attribute of name value and of type xs:boolean. The value of the Boolean attribute indicates if the certificate or certificate chain identified by the <guid> is enabled.</guid>
Test Proced	lure Computed by other tests
	This test is computed by the result of other tests.
Dependenc	cies 23.10.18
23.12-1	LXICommonConfigurationSchema HTTP PUT
Category	LXI API
Test Type	Kerberos Test, automated
Rule	LXICommonConfigurationSchema HTTP PUT
Explanation	On an HTTP PUT the device shall go to the state specified in the XML.
Test Proced	lure Computed by other tests
	This test is computed by the result of other tests.
Dependenc	ies 23.12.6-1 23.12.6-2 23.12.6.1-1 23.12.6.1-2 23.12.6.1-3 23.12.6.2-1
23.12.1.1-1	Attribute LXICommonConfiguration Strict Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute LXICommonConfiguration Strict Required
Explanation	Attribute strict shall be implemented. Attribute strict indicates that designated portions of this



Pre Conditio	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Proced	e Ensure Common Configuration does not return strict attribute	
	Ensure Common Configuration does not return strict attribute.It is a write only attribute.	
	Enable Strict Mode	
	Activate the Strict Mode in the LXI Common Configuration XML.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Verify all interface elements and create missing elements	
	Verify all of the interface elements and create each missing element as per LXI Common Configuration.	
	PUT Common Configuration, expect failure, depending on strict handling	
	Expect failure notice due to strict handling. If device implements all elements, then strict mode does not change the behaviour of the device and gets success response	
	Disable Strict Mode	
	Deactivate the Strict Mode in the LXI Common Configuration XML.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
23.12.1.1-2	Attribute LXICommonConfiguration HSMPresent	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Attribute LXICommonConfiguration HSMPresent	
Explanation	HSMPresent is a read-only attribute that is true if and only if the device uses a HSM to protect the private keys used for LXL communication.	

Pre Condition Enable IPv4 DHCP router

Enable the dhcp router for IPv4

Connect DUT

Connect the DUT to the test network

Get IP from mdns

Search via mdns for a single lxi service and retrieve its IP address



	GET Common Configuration			
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
Test Procedure	Ensure availability o	Ensure availability of HSMPresent attribute		
		Read the HSMPresent value from the LXI CommonConfiguration.		
	Compare the HSMI	Compare the HSMPresent value against test configuration		
		Compare the HSMPresent value against the test configuration value.		
	Modify the HSMPre	Modify the HSMPresent value		
		Modify the HSMPresent value via the Common Configuration.		
	PUT Common Cont	PUT Common Configuration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	GET Common Configuration			
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Read the HSMPrese	ent Value and ensure modified value was ignored Read the HSMPresent Value from the LXI Common Configuration XML and ensure the modified value was ignored.		

23.12.1.1-3 Attribute LXICommonConfiguration HSMPresent Required

Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute LXICommonConfiguration HSMPresent Required
Explanation	Attribute HSMPresent shall be implemented. HSMPresent indicates if the device has a hardware security module.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Ensure availability of HSMPresent attribute
	Read the HSMPresent value from the LXI CommonConfiguration.

23.12.1.2-1 LXICommonConfiguration Interface Configuration

Category	LXI API
Test Type	Kerberos Test, automated
Rule	LXICommonConfiguration Interface Configuration
Explanation	Devices shall accept configuration based on an Interface element for any LXI conformant interface.



Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Modify interface element
	Modify the interface element value.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23.12.1.2-2 Retu	Irn of Interfaces by Devices
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Return of Interfaces by Devices
Explanation	Devices shall return an Interface element for each interface.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Compare number of interface elements against test configuration
	The total number of interfaces in the LXI Common Configuration should match the number specified in the test configuration.
	Compare amount of LXI compliant interfaces against test configuration
	The total number of LXI compliant interfaces in the LXI Common Configuration should match the number specified in the test configuration.
23.12.1.2-3 Clier	ntAuthentication PUT
Category	LXI API
Test Type	Kerberos Test, automated



	Connec	ct DUT
		Connect the DUT to the test network
	Get IP 1	from mdns
		Search via mdns for a single lxi service and retrieve its IP address
	GET Co	ommon Configuration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Proced	lure Check a	availability of ClientAuthentication element
		Check the availability of ClientAuthentication element in the Common Configuration XML retrieved from the DUT.
	PUT Co	ommon Configuration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Co	mmon Configuration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Verify C	Common Configuration is unchanged
		Ensure that the LXI Common Configuratiuon has no change and ClientAuthentication element is in the Common Configuration.
	Remov	e ClientAuthentication element
		Remove the ClientAuthentication element from the Common Configuration.
	PUT Co	ommon Configuration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Co	ommon Configuration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Verify C	Common Configuration is unchanged
		Ensure that the LXI Common Configuratiuon has no change and ClientAuthentication element is in the Common Configuration.
23.12.1.2-4	ClientAuthentic	ation Attributes
Category	LXI API	

ClientAuthentication without the @passwords or @APIAccess attributes shall be returned for

GET over secure connections and elided for unsecure connections.

Enable the dhcp router for IPv4

Connect the DUT to the test network

Kerberos Test, automated

Enable IPv4 DHCP router

Connect DUT

ClientAuthentication Attributes

Test Type

Explanation

Pre Condition

Rule



	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Availability of HTTP
	Ensure that the HTTP element is available in the Common Configuration.
	Enable HTTP operation attribute
	Enable the HTTP operation attribute via Common Configuration
	Enable HTTP API-LXISecurity service
	Enable the HTTP API-LXISecurity service via Common Configuration.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Test Procedu	re GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Validate availability of ClientAuthentication
	Verify that the ClientAuthentication element is in the Common Configuration but without passwords and APIAccess attributes.
	GET Common Configuration missing '/api/' in URL
	GET Common Configuration over secure connection (HTTPS) via /lxi/api/ common-configuration and expect success response.
	Validate the absence of ClientAuthentication
	Verify that the ClientAuthentication element is absence in the Common Configuration.
	GET Common Configuration via HTTP
	GET Common Configuration over unsecure connection (HTTP) and expect failure response.
	GET Common Configuration missing '/api/' in URL via HTTP
	GET Common Configuration over unsecure connection (HTTP) and expect success response.
	Validate the absence of ClientAuthentication
	Verify that the ClientAuthentication element is absence in the Common Configuration.
23.12-2	LXICommonConfigurationSchema GET Response
Category	LXI API
Test Type	Kerberos Test automated

lest lype	Kerberos lest, automated
Rule	LXICommonConfigurationSchema GET Response
Explanation	The device GET response shall indicate the current state and capabilities of the device.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.



Dependencies	23.12-1 23.10.6.3
23.12.2-1 Int	erface Disable
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Interface Disable
Explanation	Non-LXI interfaces can be disabled using the Interface/@enabled attribute
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mans for a single ixi service and retrieve its IP address
	GET Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Get Interface elements which are not LXI compliant
	Get the Non-LXI compliant interface elements from the Common Configuration.
	Check for enabled attribute for all Non-LXI compliant interfaces Validate the Non-LXI compliant interfaces should have enabled attribute.
23.12.2.1-1 Int	erface Default Name
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Interface Default Name
Explanation	Devices with a single interface shall treat the Interface element with the name LXI (the default name) to configure the single interface. Devices with multiple interfaces shall assign one of them the name LXI (the default name).
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mans for a single ixi service and retrieve its IP address
	GET the Common Configuration from the device. Expect the call to
	succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Modify Network parameters
	Modify the Network parameters of the Common Configuration.
	Rename interface to 'LXI'
	If there is a single interface, rename the interface to 'LXI'.



	PUT Common Config	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Common Config	guration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Verify settings	
		Verify that the network parameters and interface name are same as set before.
	Ensure single interfac	ce named 'LXI'
		If multiple interfaces are available, remove all of the interface elements except the interface named 'LXI'.
	Modify Network para	ameters
		Modify the Network parameters of the Common Configuration.
	PUT Common Config	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Common Config	guration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Verify 'LXI' interface h	has assigned values
		Verify that the single enabled interface is named LXI and the assigned values are same as set before in the interface.
	Remove interface na	me attribute named LXI
		Remove the name attribute in the interface, which is named LXI from the Common Confgiuration.
	Modify Network para	ameters
		Modify the Network parameters of the Common Configuration.
	PUT Common Config	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Common Config	guration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Ensure default interfa	ace name is named LXI
		Ensure the device shall have the default interface name set to LXI.
Attribut	e Interface Name Re	equired
	LXI API	

Test Type Kerberos Test, automated

23.12.2.1-2

Category

Rule Attribute Interface Name Required



Explanation	Attribute name shall be implemented. name identifies this physical network interface within the device. It differentiates the interfaces in devices that have multiple interfaces.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check for 'name' attribute for each interface
	For each interface check for the 'name' attribute in the Common Configuratrion.
	Check for single interface named LXI
	Go through each interface in the Common Configuration and ensure only one is named LXI.
	Modify the Interface name
	Modify the Interface name attribute and set a value other than LXI. This shall cause a Common Configuration PUT action to fail.
	PUT Common Configuration, expect failure
	PUT the Common Configuration to the device and expect failure response. Check previous step for better understanding. This may be due to incorrect data, no authentication or any other reason for the API call to fail.
23.12.2.1-3 Attri	oute Interface LXIConformant Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute Interface LXIConformant Required
Explanation	Attribute LXIConformant shall be implemented. LXIConformant is a read-only attribute that
	indicates the LXI specifications this device complies with. If this interface does not comply with the LXI Device specification, an empty string is used.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns

Search via mdns for a single lxi service and retrieve its IP address

GET Common Configuration

GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.

Get identification file

Get the identification file from the device under test



Test Procedure	Check all interface elements for LXIConformant attribute
	Check all of the interface elements for LXIConformant attribute
	Match test interface values against Identification file values
	Match the test interface LXIConformant values against Identification file values
	Modify LXIConformant attribute's value
	Modify the LXIConformant attribute's value in the Common Configuration
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Verify that the LXI-Conformant read only attribute ignored the modified value Verify that the LXI-Conformant read only attribute ignored the modified value
	Match test interface values against Identification file values Match the test interface LXIConformant values against Identification file values
23.12.2.1-4 LXI co	onformant Interfaces Enabled
Category	LXI API
Test Type	Kerberos Test, manual
Rule	I XI conformant Interfaces Enabled
Explanation	IXI conformant interfaces shall be enabled others may be enabled
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Disable all LXI Conformant interfaces
	Disable all of the LXI Conformant interfaces in the Common Configuration.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.



	Get Common Configuration, expect failure GET Common Configuration via API and expect failure response due to disabled interface
	Do I CI
	The tester is prompted to do a manual LAN reset on the DUT.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Ensure interfaces are enabled
	Go through each interface in the Common Configuration and ensure the LXIConformant interfaces are enabled.
23.12.2.1-5	Attribute Interface Enabled Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute Interface Enabled Required
Explanation	Attribute enabled shall be implemented. enabled indicates if this physical network interface is enabled.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Proced	re Check availability of Enabled attribute on all interfaces Check the availability of Enabled attribute on all interfaces in the Common Configuration
23.12.2.1-6	Attribute Interface unsecureMode Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute Interface unsecureMode Required
Explanation	Attribute unsecureMode shall be implemented. unsecureMode is a read-only attribute that indicates that one or more configurations in this XML do not meet the LXI minimum requirements for secure device operation.
Test Proced	re Computed by other tests
	This test is computed by the result of other tests.
Dependenc	s 23.12.2-3
23.12.2.1-7	Interface LXI Secure Devices Protocol
Category	LXI API
Test Type	Vendor Declaration



Rule	Interface LXI Secure Devices Protocol	
Explanation	LXI Secure devices shall document the protocols that are controlled by this attribute.	
23.12.2.1-8	Interface unsecure Protocols	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Interface unsecure Protocols	
Explanation	If the device does not implement any other unsecure protocols, then on a GET, otherUnsecureProtocolsEnabled shall return false. However, if written true, such a device shall either fail the PUT or indicate unsecure mode is True.	
Pre Conditior	n Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single IXI service and retrieve its IP address	
	GET Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedu	re Check otherUnsecureProtocolsEnabled value for each interface	
	Check the otherUnsecureProtocolsEnabled value for each interface. If the value is true, the test passes, otherwise it continues to the further steps.	
	Enable otherUnsecureProtocolsEnabled attribute	
	Modify the value of otherUnsecureProtocolsEnabled to true for each interface.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Check otherUnsecureProtocolsEnabled for true	
	Read otherUnsecureProtocolsEnabled of the interface and expect value to be true.	
	Check unsecure mode for unsecure	
	Check the unsecure mode state is usnecure, therefore expect the value to be true.	
23.12.2.1-9	Attribute Interface otherUnsecureProtocolsEnabled Required	
Category	I XI API	

Category	
Test Type	Kerberos Test, automated
Rule	Attribute Interface otherUnsecureProtocolsEnabled Required



Explanation	Attribute otherUnsecureProtocolsEnabled shall be implemented. otherUnsecureProtocolsEnabled represents the state of various device-specific protocols that are beyond the scope of LXI	
Test Procedur	e Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	23.12.2-3	
23.12.2.1-10	Interface Ethernet communication	
Category	LXI API	
Test Type	Vendor Declaration	
Rule	Interface Ethernet communication	
Explanation	Those settings are necessary to re-establish Ethernet communication with the instrument shall be enabled.	
23.12.2.1-11	Interface Indicate unsecure Mode	
Category	LXI API	
Test Type	Vendor Declaration	
Rule	Interface Indicate unsecure Mode	
Explanation	The impact of these configurations on the device secure mode are determined by the device vendor. However, if unsecure protocols are enabled, the device shall indicate it is in unsecure mode.	
23.12.2-2	Non Lxi Conformant Interfaces	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule Non Lxi Conformant Interfaces		
Explanation	Device network interfaces (including those added dynamically) over which the LXI device may be controlled that are not LXI Conformant shall at least support this element with the enabled attribute so that network interfaces that are not LXI Security capable can be disabled.	
Test Procedur	e Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	5 23.12.2-1	
23.12.2.2-1	Interface Network Required	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Interface Network Required	
Explanation	Network is required. Interfaces that are not LXI Conformant are required to implement this element, however, they are only required to implement the Network/@Enabled attribute.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mans for a single IXI service and retrieve its IP address	



	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check availability of Network element on all interfaces Check availability of Network element on all interfaces in the Common Configuration
23.12.2.2-2 Ir	terface HTTP Element
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Interface HTTP Element
Explanation	HTTP is optional, however devices that implement HTTP are require to fully implement this element.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check availability of HTTP element on all LXI Conformant interfaces
	Check the availability of HTTP element on all LXI Conformant interfaces ir the Common Configuration.
	Add HTTP element
	If HTTP element is not present, create a HTTP element as disabled in the Common Configuration
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23.12.2.2-3 Ir	terface Multiple HTTP Elements
Category	LXI API
	Kerberos Test, automated
Rule	Interface Multiple HTTP Elements
Explanation	If multiple HTTP elements are present, each shall have a different port. Additional instances of
Explanation	this element may be used to provide independent control of multiple servers (although each

Pre Condition Enable IPv4 DHCP router

Enable the dhcp router for IPv4

Connect DUT

the API and the human interface

Connect the DUT to the test network

must be on a different port). This may be useful, for instance, if separate servers are setup for



	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	GET Common Conf	iguration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check for multiple I	HTTP elements
		Check for multiple HTTP elements. If single HTTP element is found in the interface, test is pass.
	Ensure the HTTP po	orts are all different
		Ensure all of the HTTP ports of various HTTP elements are different.
23.12.2.2-4 Inter	face HTTPS Required	
Category	LXI API	
Test Type	Kerberos Test, auto	mated
Rule	Interface HTTPS Red	quired
Explanation	HTTPS is required.	
Pre Condition	Enable IPv4 DHCP r	outer
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	GET Common Conf	iguration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check availability o	f HTTPS element on all LXI Conformant interfaces
		Check the availability of HTTPS element on all interfaces in the Common Configuration.
	Add HTTPS elemen	t
		If HTTPS element is not present, create a HTTPS element as disabled in the Common Configuration.
	PUT Common Conf	iguration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23.12.2.2-5 Mult	iple HTTPS Elements	
Category	LXI API	

category		
Test Type	Kerberos Test, automated	
Rule	Multiple HTTPS Elements	
Explanation	If multiple HTTPS elements are present, each shall have a different port. Additional instances of this element may be used to provide independent control of multiple servers (although each must be on a different port). This may be useful, for instance, if separate servers are setup for the API and the human interface.	



Pre Condition	Enable IPv4 DHCP	router	
		Enable the dhcp router for IPv4	
	Connect DUT		
		Connect the DUT to the test network	
	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Cont	figuration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Check for multiple	HTTPS elements	
		Check for multiple HTTPS elements. If single HTTPS element is found in the interface, test is pass.	
	Ensure the HTTPS p	ports are all different	
		Ensure all of the HTTPS ports of various HTTPS elements are different.	
23.12.2.2-6 Inte	rface SCPIRaw Elemen	t	
Category	LXI API		
Test Type	Kerberos Test, auto	omated	
Rule	Interface SCPIRaw	Element	
Explanation At least one instance of SCPIRaw shall be accepted by devices that Command and Control connection. A separate instance of SCPIRay		ce of SCPIRaw shall be accepted by devices that implement a SCPIRaw	
	which a SCPIRaw se	erver is running.	
Pre Condition	Enable IPv4 DHCP router		
		Enable the dhcp router for IPv4	
	Connect DUT		
		Connect the DUT to the test network	
	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Cont	figuration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Check availability o	f SCPIRaw	
		Check the availability of SCPIRaw element on tested interface as per test configuration. If present, disable it otherwise create the SCPIRaw element as disabled.	
	Disable Strict Mode	2	
		Deactivate the Strict Mode in the LXI Common Configuration XML.	
	PUT Common Con	figuration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Enable Strict Mode		
		Activate the Strict Mode in the LXI Common Configuration XML.	



	PUT Common Configuration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Enable Strict Mode		
		Activate the Strict Mode in the LXI Common Configuration XML.	
	Enable SCPIRaw		
		Enable SCPIRaw on the device by setting the Enabled attribute of the SCPIRaw element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and SCPIRaw not supported.	
	PUT Common Config	guration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Disable Strict Mode		
		Deactivate the Strict Mode in the LXI Common Configuration XML.	
	Enable SCPIRaw		
		Enable SCPIRaw on the device by setting the Enabled attribute of the SCPIRaw element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and SCPIRaw not supported.	
	PUT Common Configuration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
Interfac	e Telnet Element		
	LXI API		

Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Interface Telnet Element	
Explanation	At least one instance of Telnet shall be accepted by devices that implement the Telnet Command and Control connection. A separate instance of Telnet is used for each port at which a Telnet server is running.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Check availability of Telnet	
	Check the availability of Telnet element on tested interface as per test configuration. If present, disable it otherwise create the Telnet element as disabled.	

23.12.2.2-7



	Disable Strict Mode		
		Deactivate the Strict Mode in the LXI Common Configuration XML.	
	PUT Common Configuration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Enable Strict Mode		
		Activate the Strict Mode in the LXI Common Configuration XML.	
	PUT Common Config	guration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Enable Strict Mode		
		Activate the Strict Mode in the LXI Common Configuration XML.	
	Enable Telnet		
		Enable Telnet via Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and Telnet not supported.	
	PUT Common Config	guration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Disable Strict Mode		
		Deactivate the Strict Mode in the LXI Common Configuration XML.	
	Enable Telnet		
		Enable Telnet via Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and Telnet not supported.	
	PUT Common Config	guration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
terfac	e SCPITLS Element		

23.12.2.2-8 Interface SCPITLS Element

Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Interface SCPITLS Element	
Explanation	At least one instance of SCPITLS shall be accepted by devices that implement a SCPITLS Command and Control connection. A separate instance of SCPITLS is provided for each port at which a SCPITLS server is running.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	



	GET Common Confi	guration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Proced	lure Check availability of	SCPITLS
		Check the availability of SCPITLS element on tested interface as per test configuration. If present, disable it otherwise create the SCPITLS element as disabled.
	Disable Strict Mode	
		Deactivate the Strict Mode in the LXI Common Configuration XML.
	PUT Common Confi	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Enable Strict Mode	
		Activate the Strict Mode in the LXI Common Configuration XML.
	PUT Common Confi	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Enable Strict Mode	
		Activate the Strict Mode in the LXI Common Configuration XML.
	Enable SCPITLS	
		Enable SCPITLS on the device by setting the Enabled attribute of the SCPITLS element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and SCPITLS not supported.
	PUT Common Confi	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Disable Strict Mode	
		Deactivate the Strict Mode in the LXI Common Configuration XML.
	Enable SCPITLS	
		Enable SCPITLS on the device by setting the Enabled attribute of the SCPITLS element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and SCPITLS not supported.
	PUT Common Confi	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23.12.2.2-9	Interface HiSLIP Element	

Category	LXI API
Test Type	Kerberos Test, automated
Rule	Interface HiSLIP Element



Explanation	HiSLIP shall be accepted by devices that implement the LXI HiSLIP extended function. Only a single instance of HiSLIP is permitted because a single instance of the protocol supports an arbitrary number of instances of servers at an arbitrary number of sub addresses.		
Pre Condition	Enable IPv4 DHCP router		
		Enable the dhcp router for IPv4	
	Connect DUIT		
	Connect Dor	Connect the DUT to the test network	
		connect the bor to the test network	
	Get IP from mans	Construction of the state of the local state of the local dataset	
		Search via mons for a single ixi service and retrieve its iP address	
	GEI Common Config	guration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Check availability of	HiSLIP	
		Check the availability of HiSLIP element on tested interface as per test configuration. If present, disable it otherwise create the HiSLIP element as disabled.	
	Disable Strict Mode		
		Deactivate the Strict Mode in the LXI Common Configuration XML.	
	PUT Common Confid	guration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Enable Strict Mode		
		Activate the Strict Mode in the LXI Common Configuration XML	
	PLIT Common Confi		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Enable Strict Mode		
		Activate the Strict Mode in the LXI Common Configuration XML.	
	Enable HiSLIP		
		Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIP element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.	
	PUT Common Configuration		
	PUT Common Configuration and expect a valid		
		A valid port is used, authorization is given and the correct URL is being used.	
	Disable Strict Mode		
		Deactivate the Strict Mode in the LXI Common Configuration XML.	
	Enable HiSLIP		
		Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIP element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.	



PUT Common Configuration

PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.

23.12.2.2-10 Inte	rface VXI11 Element	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Interface VXI11 Element	
Explanation	VXI11 shall be accepted by devices that implement a VXI-11 Command and Control connection. Only a single instance of the VXI-11 protocol can be created on an interface.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	;
Test Procedure	Check availability of VXI-11	
	Check the availability of VXI11 element on tested interface as per test configuration. If present, disable it otherwise create the VXI-11 element as disabled.	t
	Disable Strict Mode	
	Deactivate the Strict Mode in the LXI Common Configuration XML.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT A valid port is used, authorization is given and the correct URL is being used.	Г. I
	Enable Strict Mode	
	Activate the Strict Mode in the LXI Common Configuration XML.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT A valid port is used, authorization is given and the correct URL is being used.	Γ. Ι
	Enable Strict Mode	
	Activate the Strict Mode in the LXI Common Configuration XML.	
	Enable VXI-11	
	Set VXI11 'enabled' attribute to true via Common Configuration.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT A valid port is used, authorization is given and the correct URL is being used.	Γ. Ι
	Disable Strict Mode	
	Deactivate the Strict Mode in the LXI Common Configuration XML.	



Fnable VXI-11 Set VXI11 'enabled' attribute to true via Common Configuration. PUT Common Configuration PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used. 23.12.2.2-11 **Interface Unrecognized Extensions** Category LXI API Kerberos Test, automated Test Type Rule Interface Unrecognized Extensions Explanation If a device receives a well-formed extension element it does not recognize, it shall ignore it. **Pre Condition** Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address **GET** Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly. **Test Procedure** Add unknown extension element Create an unknown and well formed element in the interface, which is unknown by device. **PUT Common Configuration** PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used. 23.12.2.2-12 **Interface Get Configuration** LXI API Category Kerberos Test, automated Test Type Rule Interface Get Configuration Explanation On a GET, devices are permitted to express arbitrary configuration with extension elements, however such a device shall accept configuration using those elements. **Pre Condition** Enable IPv4 DHCP router

Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address GET Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.



Test Procedure	Check for Any Elen	nent
		Check for Any Element for all interfaces. If none found, test passes, otherwise it continues to the further steps.
	PUT Common Con	figuration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23.12.2.2-13 Inter	face unsecure Mode A	Attribute unsecureEnabled
Category	LXI API	
Test Type	Kerberos Test, man	iual
Rule	Interface unsecure	Mode Attribute unsecureEnabled
Explanation	Any element that controls a protocol that impacts the unsecure mode shall include an unsecureEnabled attribute. Setting this false shall disable the protocol or disable the unsecure behaviour. The device shall report unsecureMode true, when any protocol has unsecureEnabled true.	
Pre Condition	Enable IPv4 DHCP	router
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single IXI service and retrieve its IP address
	GEI Common Con	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Set the DUT to No	n-Unsecure Mode
		Set all the Interface attributes value to Non-unsecure, which has impact on unsecure mode.
Test Procedure	Check all any elem	ents for unsecureEnabled flag
		Check all any elements of the interface element for unsecureEnabled flag.
	Enable unsecureEn	abled attribute
		Set the unsecureEnabled attribute of the interface element value to true, if available.
	PUT Common Con	figuration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Query unsecure mo	ode indicator
		Open the LXI welcome page and visually check the welcome page that the DUT has an unsecure mode indicator.
	Disable unsecureEr	nabled attribute
		Set the unsecureEnabled attribute of the interface element value to false, if available.
	PUT Common Con	figuration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.



Query unsecure mode indicator

Open the LXI welcome page and visually check the welcome page that the DUT has an unsecure mode indicator.

23.12.2-3	unsecure Interface			
Category	LXI API			
Test Type	Kerberos Test, man	ual		
Rule	unsecure Interface			
Explanation	If any unsecure inte	If any unsecure interface is enabled, then the device shall report that it is unsecure mode.		
Pre Conditio	on Enable IPv4 DHCP	Enable IPv4 DHCP router		
		Enable the dhcp router for IPv4		
	Connect DUT			
		Connect the DUT to the test network		
	Get IP from mdns			
		Search via mdns for a single lxi service and retrieve its IP address		
	GET Common Conf	figuration		
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
Test Proced	ure Set the DUT to Nor	n-Unsecure Mode		
		Set all the Interface attributes value to Non-unsecure, which has impact on unsecure mode.		
	Check otherUnsecu	reProtocolsEnabled for false		
		Check the otherUnsecureProtocolsEnabled flag in the Common Configuration is set to false.		
	PUT Common Cont	figuration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	GET Common Conf	figuration		
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Check unsecure inc	licator for false		
		Check the unsecure indicator state through the Common Configuration and expect it to be false.		
	Query unsecure mo	ode indicator		
		Open the LXI welcome page and visually check the welcome page that the DUT has an unsecure mode indicator.		
	Check protocols an	d enable unsecure ones		
		For each interface, check protocols and enable unsecure protocols.		
	Check otherUnsecu	reProtocolsEnabled for true		
		Read otherUnsecureProtocolsEnabled of the interface and expect value to be true.		



	PUT Common Config	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Common Config	guration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check the unsecure i	indicator state, expect true
		Check the unsecure indicator state and expect the value to be true. This means the device is in an unsecure state.
	Query unsecure mod	le indicator
		Open the LXI welcome page and visually check the welcome page that the DUT has an unsecure mode indicator.
	Disable interface	
		Disable each interface in the Common Configuration.
	PUT Common Config	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Query unsecure mod	le indicator
	- ,	Open the LXI welcome page and visually check the welcome page that the DUT has an unsecure mode indicator.
	Do LCI	
		The tester is prompted to do a manual LAN reset on the DUT.
	Enable interface	
		Enable each interface in the Common Configuration.
	Set the DUT to Non-	Unsecure Mode
		Set all the Interface attributes value to Non-unsecure, which has impact on unsecure mode.
	PUT Common Config	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Query unsecure mod	le indicator
		Open the LXI welcome page and visually check the welcome page that the DUT has an unsecure mode indicator.
erfac	e Optional Elements	4

23.12.2-4 Interface Optional Elements

Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Interface Optional Elements	
Explanation	Absence of optional elements disables them	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	

Connect DUT

Connect the DUT to the test network



	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Get interface elements from the Common Configuration		
	Get all of the interface elements from the Common Configuration. This includes non LXI interfaces.		
	Enable each available ELEMENT		
	Enable each available element, which has enabled attribute. Depending on the iteration this may be either SCPIRaw, SCPITLS, Telnet, HiSLIP, VXI-11 or even an AnyElement.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
Test Procedure	Remove each element from the Common Configuration		
	Remove each available element from the Common Configuration. Depending on the iteration this may be either SCPIRaw, SCPITLS, Telnet, HiSLIP, VXI-11 or even an AnyElement.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Check each element is disabled		
	Check that each elements enabled attribute is false. This may be either SCPIRaw, SCPITLS, Telnet, HiSLIP, VXI-11 or even an AnyElement.		
23.12.2-5 Inter	face Optional Elements Response		
Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	Interface Optional Elements Response		
Explanation	If a device does not implement a capability configured by an XML element within Interface, it shall omit that optional XML element from its response. If the device does implement the capability, it shall include the element in the response and indicate the current configuration. See the details regarding the implementation of LXICommonConfiguration/@strict attribute regarding how certain protocol configurations are handled.		

Enable the dhcp router for IPv4

Connect the DUT to the test network

Search via mdns for a single lxi service and retrieve its IP address

Report bases on file: LxiConformanceTestSuite_1.6.json

Enable IPv4 DHCP router

Connect DUT

Get IP from mdns

Pre Condition



	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Get interface elements from the Common Configuration	
	Get all of the interface elements from the Common Configuration. This includes non LXI interfaces.	
Test Procedure	Ensure correct number of elements	
	Ensure the correct number of elements are present in the Common Configuration as per test configuration. Depending on the iteration this may be either SCPIRaw, SCPITLS, Telnet, HiSLIP, VXI-11 or even an AnyElement.	
	Compare capability attribute value to test configuration Compare the capability attribute value with test configuration value.	
	These must match.	
23.12-3 LXIC	ommonConfigurationSchema Capability Attributes	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	LXICommonConfigurationSchema Capability Attributes	
Explanation	Devices shall indicate capabilities not apparent from the queried settings using the capability attribute.	
Test Procedure	Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	23.12.9-1	
	23.12.9.1-1	
	23.12.9.1-2	
	23.12.10-1	
	23.12.10-2	
	23.12.10-3	
	23.12.10.1-1	
	23.12.10.1-2 23.12.10.1-3	
	23.12.11.1-3	
	23.12.11.1-6	
	23.12.11.1-7	
23.12.3.1-1 Netv	vork Element Ipv4 Required	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Network Element Ipv4 Required	
Explanation	IPv4 is required.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	



	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check for IPv4 Element in each LXI conformant interface element Check the availability of IPv4 Element in each LXI conformant interface element.
23.12.3.1-2 Netw	vork Element Ipv6 Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Network Element Ipv6 Required
Explanation	IPv6 is required by devices that implement the IPv6 Extended Function.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mans for a single ixi service and retrieve its iP address
	GET Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check IPv6 Element for each LXI Conformant interface
	Check the IPv6 Element for each LXI Conformant interface is available.
	Check for 'LXI IPv6' in the LXIConformant attribute
	Check that 'LXI IPv6' extended function is available in the LXIConformant attribute.
23.12.4.1-1 Attril	bute IPv4 Enabled Required
Category	LXI API
Test Type	Kerberos Test, manual
Rule	Attribute IPv4 Enabled Required
Explanation	Attribute enabled shall be implemented. Enabled generally enables or disables IPv4 operation.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to

GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.



	Enable IPv6 via Common C	onfiguration	
	Conr is su	ect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 ported)	
	Enable IPv6 DHCPEnabled	attribute	
	Enab	le IPv6 DHCPEnabled attribute via Common Configuration.	
	Enable IPv6 RAEnabled att	ibute	
	Enab	le IPv6 RAEnabled attribute via Common Configuration.	
	Disable IPv6 staticAddress	nabled	
	Disat	ble IPv6 staticAddressEnabled attribute via Common Configuration.	
	Enable IPv4 and IPv6 'Ping	Enabled' attribute	
	Set If Conf	Pv4 and IPv6 'PingEnabled' attribute to true via Common guration.	
	PUT Common Configuration	- n	
	PUT o A val used	Common Configuration and expect a valid response from the DUT. id port is used, authorization is given and the correct URL is being	
Test Procedure	Check availability of enable	d attribute in all IPv4 elements	
	Chec Com	k the availability of enabled attribute in all IPv4 elements in the mon Configuration.	
	Disable IPv4 'enabled' attri	bute	
	Set I	Pv4 'enabled' attribute to false.	
	Enable IPv4 and IPv6 'Ping	Enabled' attribute	
	Set If Conf	Pv4 and IPv6 'PingEnabled' attribute to true via Common guration.	
	PUT Common Configuration		
	PUT (A val used	Common Configuration and expect a valid response from the DUT. id port is used, authorization is given and the correct URL is being	
	Ping the DUT for failure		
	Ping	the DUT via IPv4 which is expected to fail.	
	Get Common Configuratio	n via IPv4. expect failure	
	GET (Common Configuration via IPv4 and expect the call to fail.	
	Get DHCP IPv6 from mdns		
	Get t	he DHCP address only via mDNS	
	Enable IPv/Lvia Common (onfiguration	
		pe IPv4 enabled attribute to true via the Common Configuration	
	DUT Common Configuratio		
		Common Configuration and expect a valid response from the DUT	
	A val	id port is used, authorization is given and the correct URL is being	
	Do LCI		
	The t	ester is prompted to do a manual LAN reset on the DUT.	
	Ping the DUT for success		
	Ping	the DUT via IPv4 which is expected to succeed	


Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	IPv4 State Without AutoIPEnabled		
Explanation	If omitted, and DHC	CPEnabled is present, the device uses the same state as DHCPEnabled.	
Pre Condition	Enable IPv4 DHCP r	outer	
		Enable the dhcp router for IPv4	
	Connect DUT		
		Connect the DUT to the test network	
	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Conf	iguration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	GET Device Specific	Configuration	
	·	GET the Device Specific Configuration from device via API /lxi/api/device-specific-configuration using API-Key.	
	Set static IP		
		Set the static IP in the Device Specific Configuration xml.	
	PUT Device Specific	Configuration	
		PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.	
Test Procedure	Remove AutolPEnal	bled attribute	
		Remove the AutoIPEnabled attribute from the IPv4 element.	
	Enable IPv4 DHCPE	nabled	
		Set DHCPEnabled to true in the IPv4 element.	
	PUT Common Conf	iguration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	GET Common Conf	iguration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Check AutoIPEnable	ed is true	
		Check AutoIPEnabled attribute value is true.	
	Remove AutolPEnal	bled attribute	
		Remove the AutoIPEnabled attribute from the IPv4 element.	
	Disable IPv4 DHCPEnabled		
		Set DHCPEnabled to false in the IPv4 element.	
	PUT Common Conf	iguration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	

23.12.4.1-2 IPv4 State Without AutoIPEnabled



		Get IP from mdns	
			Search via mdns for a single lxi service and retrieve its IP address
		Validate IP address	
			Validate IP address and confirm that device is using the static IP address.
		GET Common Config	guration
			GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
		Check DHCPEnablec	l is false
			Check DHCPEnabled attribute value is false.
		Check AutoIPEnable	d is false
			Check AutoIPEnabled attribute value is false.
23.12.4.1-3	Attribut	te IPv4 AutoIPEnable	ed Required
Category		LXI API	
Test Type		Kerberos Test, auton	nated
Rule		Attribute IPv4 Autol	PEnabled Required
Explanation		Attribute autoIPEnal Local Addressing ca Link Local Address. I Specific Configuratio	oled shall be implemented. AutoIPEnabled represents the state of the Link pability in the device. If enabled, the device may acquire an address using Link Local addresses supersede static values configured in the LXI Device on.
Pre Conditic	n	Enable IPv4 DHCP ro	puter
			Enable the dhcp router for IPv4
		Connect DUT	
			Connect the DUT to the test network
		Get IP from mdns	
			Search via mdns for a single lxi service and retrieve its IP address
		GET Common Config	guration
			GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
		GET Device Specific	Configuration
			GET the Device Specific Configuration from device via API /lxi/api/device-specific-configuration using API-Key.
		Set static IP	
			Set the static IP in the Device Specific Configuration xml.
		PUT Device Specific	Configuration
			PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.
Test Procedu	ure	Check the availability	y of AutoIPEnabled attribute
			Check the availability of AutoIPEnabled attribute in the IPv4 elements of the Common Configuration.
		Disable AutolPEnabl	ed and DHCPEnabled attributes
			Disable the AutoIPEnabled and DHCPEnabled attributes of the IPv4 element of the Common Configuration.



PUT Common Confi	guration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Disconnect DUT	
	Disconnect the DUT from the test network
Connect DUT	
	Connect the DUT to the test network
Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address
Check DUT has stati	c IP address
	Check the device has the previously configured static IP address.
GET Common Confi	guration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Enable AutoIPEnable	ed attribute
	Enable the AutolPEnabled attribute of the IPv4 element of the Common Configuration.
PUT Common Confi	guration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Wait for DUT to sett	le
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
GET Common Confi	guration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Enable AutoIPEnable	ed attribute
	Enable the AutoIPEnabled attribute of the IPv4 element of the Common Configuration.
Enable DHCPEnable	d attribute
	Enable the DHCPEnabled attribute of the IPv4 element in the Common Configuration.
PUT Common Confi	guration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Stop IPv4 DHCP rou	iter
	Stop the IPv4 DHCP router, so that no IPv4 DHCP addresses given for lease
Disconnect DUT	
	Disconnect the DUT from the test network
Connect DUT	
	Connect the DUT to the test network



	Wait for DUT to sett	le
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	Enable DHCPEnable	d attribute
		Enable the DHCPEnabled attribute of the IPv4 element in the Common Configuration.
	PUT Common Confi	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Enable IPv4 DHCP ro	outer
		Enable the dhcp router for IPv4
	Disconnect DUT	
		Disconnect the DUT from the test network
	Connect DUT	
		Connect the DUT to the test network
	Wait for DUT to sett	le
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
IPv4 Sta	ate With DhcpEnable	ed
	LXI API	
	Kerberos Test, autor	nated
	IPv4 State With Dhc	pEnabled

If omitted, and autoIPEnabled is present, the device uses the same state as autoIPEnabled.

23.12.4.1-4

Category Test Type Rule

Explanation

Pre Condition

Connect DUT

Connect the DUT to the test network

Enable the dhcp router for IPv4

Get IP from mdns

Search via mdns for a single lxi service and retrieve its IP address

GET Common Configuration

Enable IPv4 DHCP router

GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.

GET Device Specific Configuration

GET the Device Specific Configuration from device via API /lxi/api/device-specific-configuration using API-Key.

Set static IP

Set the static IP in the Device Specific Configuration xml.

PUT Device Specific Configuration

PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.



Test Procedure	Remove DHCPEnabled attribute			
	Remove the DHCPEnabled attribute from the IPv4 element.			
	Enable AutoIPEnabled attribute			
	Enable the AutoIPEnabled attribute of the IPv4 element of the Common Configuration.			
	PUT Common Configuration			
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.			
	GET Common Configuration			
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.			
	Check DHCPEnabled is enabled			
	Check DHCPEnabled attribute value is set to true which means DHCP is enabled.			
	Remove DHCPEnabled attribute			
	Remove the DHCPEnabled attribute from the IPv4 element.			
	Disable AutoIPEnabled attribute			
	Set AutoIPEnabled attribute to false in the IPv4 element.			
	PUT Common Configuration			
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.			
	Get IP from mdns			
	Search via mdns for a single lxi service and retrieve its IP address			
	Validate IP address			
	Validate IP address and confirm that device is using the static IP address.			
	GET Common Configuration			
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.			
	Check DHCPEnabled is false			
	Check DHCPEnabled attribute value is false.			
23.12.4.1-5 Attribu	te IPv4 DHCPEnabled Required			
Category	LXI API			
Test Type	Kerberos Test, automated			
Rule	Attribute IPv4 DHCPEnabled Required			
Explanation	Attribute DHCPEnabled shall be implemented. DHCPEnabled represents the state of the device DHCP protocol.			
Test Procedure	Computed by other tests			

This test is computed by the result of other tests.

Dependencies 23.12.4.1-3



Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	Attribute IPv4 mDNSEnabled Required		
Explanation	Attribute mDNSEnabled shall be implemented. mDNSEnabled represents the state of the multicast DNS responder in the device.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Enable IPv6 via Common Configuration		
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)		
	Enable IPv6 DHCPEnabled attribute		
	Enable IPv6 DHCPEnabled attribute via Common Configuration.		
	Enable IPv6 RAEnabled attribute		
	Enable IPv6 RAEnabled attribute via Common Configuration.		
	Disable IPv6 staticAddressEnabled		
	Disable IPv6 staticAddressEnabled attribute via Common Configuration.		
lest Procedure	Check the availability of mDNSEnabled attribute		
	check the availability of mDNSEnabled attribute in IPv4 and/or IPv6 element of the Common Configuration.		
	Loop next 5 Steps for mDNSEnabled value		
	Loop over the next 5 Steps to set all combinations of the mDNSEnabled value for IPv4 and IPv6.		
	IPv4: false; IPv6: true		
	IPv4: true; IPv6: false		
	IPv4: false; IPv6: false		
	Set IPv4 mDNSEnabled attribute		
	Set the IPv4 mDNSEnabled attribute to true/false via the Common Configuration.		
	Set IPv6 mDNSEnabled attribute		
	If IPv6 is supported, set the IPv6 mDNSEnabled attribute to true/false via the Common Configuration.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		

23.12.4.1-6 Attribute IPv4 mDNSEnabled Required



	Verify mDNS behaviour IPv4			
	Verify the mDNS behaviour for IPv4 as per mD If mDNSEnabled attribute value is true then de the mdns otherwise not.	NSEnabled attribute value. vice can get the IP from		
	Verify mDNS behaviour IPv6			
	Verify the mDNS behaviour for IPv6 as per mD If mDNSEnabled attribute value is true then de the mdns otherwise not. If Ipv6 is not supporte	NSEnabled attribute value. vice can get the IP from ed, this step is skipped.		
23.12.4.1-7 IPv	v4 Dynamic DNS			
Category	LXI API			
Test Type	Kerberos Test, automated			
Rule	IPv4 Dynamic DNS			
Explanation	Dynamic DNS is optional for LXI devices. Therefore, if not implement this attribute on a PUT.	ted, the device shall ignore		
Pre Condition	Enable IPv4 DHCP router			
	Enable the dhcp router for IPv4			
	Connect DUT			
	Connect the DUT to the test network			
	Get IP from mdns			
	Search via mdns for a single lxi service and ret	rieve its IP address		
	GET Common Configuration			
	GET the Common Configuration from the devi succeed. Authentication is given, the correct U device is setup correctly.	ce. Expect the call to RL is being used and the		
Test Procedure	Check the availability of dynamicDNSEnabled attribute			
	Check the availability of dynamicDNSEnabled a available and configured, test passes. Otherwis available and not configured, test continues to	attribute. If attribute is se,if attribute is not o further steps.		
	Enable IPv4 dynamicDNSEnabled attribute			
	Enable IPv4 dynamicDNSEnabled attribute by dynamicDNSEnabled attribute with value true available.	setting or adding in IPv4 element, if not		
	PUT Common Configuration			
	PUT Common Configuration and expect a valion A valid port is used, authorization is given and used.	d response from the DUT. the correct URL is being		
	Disable IPv4 dynamicDNSEnabled attribute			
	Disable IPv4 dynamicDNSEnabled attribute by dynamicDNSEnabled attribute with value false available.	setting or adding in IPv4 element, if not		
	PUT Common Configuration			
	PUT Common Configuration and expect a valion A valid port is used, authorization is given and used.	d response from the DUT. the correct URL is being		



23.12.4.1-8	IPv4 Devices Without dynamic DNS
Category	LXI API
Test Type	Kerberos Test, automated
Rule	IPv4 Devices Without dynamic DNS
Explanation	Devices that do not implement dynamic DNS shall omit this attribute on a GET.
Test Proced	lure Computed by other tests
	This test is computed by the result of other tests.
Dependenc	ies 23.12.4.1-7
23.12.4.1-9	IPv4 dynamicDNSEnabled With IPv6 dynamic DNS
Category	LXI API
Test Type	Kerberos Test, automated
Rule	IPv4 dynamicDNSEnabled With IPv6 dynamic DNS
Explanation	The dynamicDNSEnabled attribute shall be implemented irrespective of if IPv6 dynamic DNS is implemented.
Test Proced	lure Computed by other tests
	This test is computed by the result of other tests.
Dependenc	ies 23.12.4.1-7
23.12.4.1-10	Attribute IPv4 dynamicDNSEnabled Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute IPv4 dynamicDNSEnabled Required
Explanation	Attribute dynamicDNSEnabled shall be implemented. DynamicDNSEnabled represents the state of the dynamic DNS capability. Dynamic DNS is used to publish the hostname of the device to DNS.
Pre Conditi	on Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	CET Common Configuration
	GET Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Proced	lure Check the availability of dynamicDNSEnabled attribute
	Check the availability of dynamicDNSEnabled attribute. If attribute is available and configured, test passes. Otherwise, if attribute is not available and not configured, test continues to further steps.
	Enable dynamicDNSEnabled for IPv4
	Set dynamicDNSEnabled attribute of the Common Configuration to true for IPv4



Enable dynamicDN	VSEnabled for IPv6
	Set dynamicDNSEnabled attribute of the Common Configuration to true for IPv6, if this feature is supported.
PUT Common Cor	nfiguration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Verify DynamicDN Packets	S behaviour for IPv4 through capture and analysis of Dynamic Update
	Verify the behaviour of Dynamic DNS for IPv4 by capturing the network packets and analysing them for Dynamic Update Packets.
Disable dynamicD	NSEnabled for IPv4
	Set dynamicDNSEnabled attribute of the Common Configuration to false for IPv4
Disable dynamicD	NSEnabled for IPv6
-	Set dynamicDNSEnabled attribute of the Common Configuration to false for IPv6, if this feature is supported.
PUT Common Cor	nfiguration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Verify DynamicDN Packets	S behaviour for IPv4 through capture and analysis of Dynamic Update
	Verify the behaviour of Dynamic DNS for IPv4 by capturing the network packets and analysing them for Dynamic Update Packets.
Disable dynamicD	NSEnabled for IPv4 and enable for IPv6
	If IPv6 is supported, set the dynamicDNSEnabled attribute to false for IPv4 and true for IPv6.
PUT Common Cor	nfiguration, expect failure
	PUT the Common Configuration to the device and expect failure response. Check previous step for better understanding. This may be due to incorrect data, no authentication or any other reason for the API call to fail.
Verify DynamicDN Packets	S behaviour for IPv4 through capture and analysis of Dynamic Update
	Verify the behaviour of Dynamic DNS for IPv4 by capturing the network packets and analysing them for Dynamic Update Packets.
Enable dynamicDN	VSEnabled for IPv4 and disable for IPv6
	If IPv6 is supported, set the dynamicDNSEnabled attribute of the Common Confgiuration to true for IPv4 and false for IPv6.
PUT Common Cor	nfiguration, expect failure
	PUT the Common Configuration to the device and expect failure response. Check previous step for better understanding. This may be due to incorrect data, no authentication or any other reason for the API call to fail.
Verify DynamicDN Packets	S behaviour for IPv4 through capture and analysis of Dynamic Update
	Verify the behaviour of Dynamic DNS for IPv4 by capturing the network packets and analysing them for Dynamic Update Packets.



Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Attribute IPv4 pingEnabled Required	
Explanation	Attribute pingEnabled shall be implemented. Attribute pingEnabled represents the state of the IPv4 ICMP ping responder. shall be implemented.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Enable IPv6 via Common Configuration	
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)	
	Enable IPv6 DHCPEnabled attribute	
	Enable IPv6 DHCPEnabled attribute via Common Configuration.	
	Enable IPv6 RAEnabled attribute	
	Enable IPv6 RAEnabled attribute via Common Configuration.	
	Disable IPv6 staticAddressEnabled	
	Disable IPv6 staticAddressEnabled attribute via Common Configuration.	
Test Procedure	Check the availability of pingEnabled attribute	
	Check the availability of pingEnabled attribute in the Common Configuration.	
	Loop next 5 Steps for pingEnabled value	
	Loop over the next 5 Steps to set all combinations of the pingEnabled value for IPv4 and IPv6. IPv4: true; IPv6: true IPv4: false; IPv6: true	
	IPv4: true; IPv6: false	
	IPv4: false; IPv6: false	
	Set IPv4 pingEnabled to true/false	
	Set IDv6 pingEnabled to true/false	
	Set IPv6 pingenabled to true/false via Common Configuration if	
	supported.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Ping the DUT for success	
	Ping the DUT via IPv4 which is expected to succeed	

23.12.4.1-11 Attribute IPv4 pingEnabled Required



Ping the DUT via IPv6 for success

Ping the DUT via IPv6 for success using the global IPv6 address.

23.12.4.1-12 IPv4	Unrecognized Extensions
Category	LXI API
Test Type	Kerberos Test, automated
Rule	IPv4 Unrecognized Extensions
Explanation	LXI devices shall ignore extension attributes they do not recognize.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Add additional attribute to IPv4 element
	Add an additional attribute to IPv4 element.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23.12.5-1 IPv6	Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	IPv6 Required
Explanation	Since IPv6 is required in devices that implement the LXI IP Version 6 Extended Function, the required attributes are only required in implementations that implement IPv6.
Pre Condition	Enable IPv6 RA router
	Enable IPv6 RA address assignment on the router.
	Ensure the DUT has no DHCP address any more.
	Ensure the DUT has a KA address.
	Connect DUI
	Cot PA IBv6 from mdns
	Get the RA address only via mDNS
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check test configuration for LXI IPv6
	Check test configuration for LXI IPv6. If configured, test results depending on attribute testing. If IPv6 not supported, it is an automatic pass.



Dependencies	23.12.5.1-1	
	23.12.5.1-2	
	23.12.5.1-3	
	23.12.5.1-4	
	23.12.5.1-5	
	23.12.5.1-6	
	23.12.5.1-7	
	23.12.5.1-8	
	23.12.5.1-9	
	23.12.5.1-10	
	23.12.3.1-11	
23.12.5.1-1 IPv6	Attribute Enabled Re	equired
Category	LXI API	
Test Type	Kerberos Test, aut	omated
Rule	IPv6 Attribute Ena	abled Required
Explanation	Attribute enabled	shall be implemented. Enabled generally enables or disables IPv6 capability.
Pre Condition	Enable IPv4 DHCF	P router
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	Enable IPv6 via Co	ommon Configuration
		Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCF	PEnabled attribute
		Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEn	abled attribute
		Enable IPv6 RAEnabled attribute via Common Configuration
	Disable IPv6 static	
		Disable IPv6 staticAddrossEnabled attribute via Common Configuration
	Enable IDve DUCE	
		Finable IDue DUCD address assignment on the router
		Enable IF VO DHCF address assignment on the router. Ensure the DIIT has no BA address any more
		Ensure the DUT has a DHCP address
	Cot DUCD IDv6 fr	
	Get Drice involit	Get the DHCP address only via mDNS
	GET Common Co	of the price address only via mpros.
	GET COMMON CO	GET the Common Configuration from the device. Expect the call to
		succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Enable IPv6 'Pingl	Enabled' attribute
	5	Set IPv6 'PingEnabled' attribute value to true.
	PUT Common Co	nfiguration
		PUT Common Configuration and expect a valid response from the DUT
		A valid port is used, authorization is given and the correct URL is being used.



Test Procedure	Check availability of enabled attribute in all IPv6 elements		
	Check the availability of enabled attribute in all IPv6 elements in the		
	Common Configuration.		
	Disable IPv6 'enabled' attribute		
	Set IPv6 'enabled' attribute value to false.		
	Enable IPv6 'PingEnabled' attribute		
	Set IPv6 'PingEnabled' attribute value to true.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Ping the DUT via IPv6 for failure		
	Ping the DUT via IPv6 using the gloabal IPv6 address and expect it to fail.		
	Enable IPv6 via Common Configuration		
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Ping the DUT via IPv6 for success		
	Ping the DUT via IPv6 for success using the global IPv6 address.		
23.12.5.1-2 IPv6	Attribute DHCPEnabled Required		
Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	IPv6 Attribute DHCPEnabled Required		
Explanation	Attribute DHCPEnabled shall be implemented. DHCPEnabled represents the state of the device IPv6 DHCP protocol. If True, configuration is accepted via the DHCP protocol.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
	Enable IPv6 via Common Configuration		
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)		
	Enable IPv6 DHCPEnabled attribute		
	Enable IPv6 DHCPEnabled attribute via Common Configuration.		
	Enable IPv6 RAEnabled attribute		
	Enable IPv6 RAEnabled attribute via Common Configuration.		
	Disable IPv6 staticAddressEnabled		
	Disable IPv6 staticAddressEnabled attribute via Common Configuration		



	Enable IPv6 DHCP router
	Enable IPv6 DHCP address assignment on the router. Ensure the DUT has no RA address any more. Ensure the DUT has a DHCP address.
	Get DHCP IPv6 from mdns
	Get the DHCP address only via mDNS.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check availability of DHCPEnabled in all IPv6 elements
	Check the availability of DHCPEnabled attribute in all IPv6 elements.
	Disable IPv6 DHCPEnabled attribute
	Disable IPv6 DHCPEnabled attribute via Common Configuration.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Check mdns advertisement of DHCPv6 address has stopped
	Check mdns advertisement of DHCPv6 address has stopped.
	Ping IPv6 DHCP address for failure
	Ping the device via DHCPv6 address for failure.
	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	Enable IPv6 DHCPEnabled attribute
	Enable IPv6 DHCPEnabled attribute via Common Configuration.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Get DHCP IPv6 from mdns
	Get the DHCP address only via mDNS.
	Ping IPv6 RA address for success
	Ping the IPv6 RA address for success.
23.12.5.1-3 IPv6	6 Attribute RAEnabled Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	IPv6 Attribute RAEnabled Required
Explanation	Attribute RAEnabled shall be implemented. RAEnabled represents the state of address
Explanation	generation based on the router advertisement.

Pre Condition Enable IPv4 DHCP router

Enable the dhcp router for IPv4



	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	Enable IPv6 via Cor	nmon Configuration
		Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCPE	nabled attribute
		Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnat	pled attribute
		Enable IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticA	ddressEnabled
		Disable IPv6 staticAddressEnabled attribute via Common Configuration.
	Enable IPv6 RA rou	ter
		Enable IPv6 RA address assignment on the router.
		Ensure the DUT has no DHCP address any more. Ensure the DUT has a RA address.
	Connect DUT	
		Connect the DUT to the test network
	Get RA IPv6 from m	ndns
		Get the RA address only via mDNS.
	GET Common Conf	iguration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Enable IPv6 Privacy	ModeEnabled attribute for RA
		Enable IPv6 PrivacyModeEnabled attribute for RA via Common Configuration.
	PUT Common Conf	iguration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Test Procedure	Check availability o	f RAEnabled in IPv6 element
		Check the availability of RAEnabled attribute in IPv6 elements.
	Disable IPv6 RAEna	bled attribute
		Disable IPv6 RAEnabled attribute via Common Configuration.
	PUT Common Conf	iguration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Check the mdns ad	vertisement of RA address has stopped
		Check the mdns advertisement of RA address has stopped
	Ping IPv6 RA addre	ss for failure
		Ping device via RA address for failure
	Enable IPv6 RAEnat	- Ded attribute
		Enable IPv6 RAEnabled attribute via Common Configuration.



	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT A valid port is used, authorization is given and the correct URL is being used.	
	Get RA IPv6 from mdns	
	Get the RA address only via mDNS.	
	Ping IPv6 RA address for success	
	Ping the IPv6 RA address for success.	
23.12.5.1-4 IPv6	5 Attribute staticAddressEnabled Required	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	IPv6 Attribute staticAddressEnabled Required	
Explanation	Attribute static AddressEnabled shall be implemented. staticAddressEnabled indicates if the device uses the static address configured with LXIDeviceSpecificConfiguration/IPv6/ StaticAddress.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	Enable IPv6 via Common Configuration	
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv is supported)	v6
	Enable IPv6 DHCPEnabled attribute	
	Enable IPv6 DHCPEnabled attribute via Common Configuration.	
	Enable IPv6 RAEnabled attribute	
	Enable IPv6 RAEnabled attribute via Common Configuration.	
	Disable IPv6 staticAddressEnabled	
	Disable IPv6 staticAddressEnabled attribute via Common Configuration	1.
	Enable IPv6 DHCP router	
	Enable IPv6 DHCP address assignment on the router. Ensure the DUT has no RA address any more. Ensure the DUT has a DHCP address.	
	Disconnect DUT	
	Disconnect the DUT from the test network	
	Connect DUT	
	Connect the DUT to the test network	
	Get DHCP IPv6 from mdns	
	Get the DHCP address only via mDNS.	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	l
	Get identification file	
	Get the identification file from the device under test	



	GET Device Specifi	c Configuration	
		GET the Device Specific Configuration from device via API /lxi/api/device- specific-configuration using API-Key.	
	Set static IP		
		Set the static IP in the Device Specific Configuration xml.	
	PUT Device Specifi	c Configuration	
		PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.	
	Enable IPv6 staticA	ddressEnabled attribute via Common Configuration	
		Use the Common Configuration from the DUT and set the IPv6 attribute staticAddressEnabled to enabled.	
	Disable IPv6 DHCP	Enabled and RAEnabled attributes via Common Configuration	
		Use the Common Configuration from the DUT and disable the IPv6 attributes DHCPEnabled and RAEnabled.	
	PUT Common Con	figuration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
Disable IPv6 RA and DHCP routers		d DHCP routers	
		Disable IPv6 RA and IPv6 DHCP on the networks router. This forces the device to loses its IPv6 RA and DHCPv6 address once the lease time has expired.	
	Disconnect DUT		
		Disconnect the DUT from the test network	
	Connect DUT		
		Connect the DUT to the test network	
	Get IPv6 static add	lress from mdns	
		Get IPv6 static address from mdns. Look for single _lxitcp service via mdns, get the IPv6 addresses from the service and filter for IPv6 static IP address.	
Test Procedure	Check the availabil	ity of staticAddressEnabled attribute in IPv6 element Check the availability of staticAddressEnabled attribute in IPv6 element.	
	Disable IPv6 staticAddressEnabled		
		Disable IPv6 staticAddressEnabled attribute via Common Configuration.	
	PUT Common Con	figuration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Check advertisement of IPv6 static address via mDNS stopped		
		Check the advertisement of the IPv6 static address via mDNS has stopped.	
	Ping IPv6 static ad	dress for failure	
		Ping the DUT via IPv6 static address and expect it to fail.	
	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	Enable IPv6 staticAddressEnabled attribute via Common Configuration		
		Use the Common Configuration from the DUT and set the IPv6 attribute staticAddressEnabled to enabled.	



		Disable IPv6 DHCPE	nabled and RAEnabled attributes via Common Configuration
			Use the Common Configuration from the DUT and disable the IPv6 attributes DHCPEnabled and RAEnabled.
		PUT Common Config	guration
			PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
		Check advertisement	t of IPv6 static address via mDNS
			Ensure the IPv6 static address is being advertised via mDNS. Look for single lxi service, get the IPv6 address from the service and ensure it is the expected static IPv6 address.
		Ping IPv6 static addr	ress for success
			Ping the DUT's IPv6 static address and expect a successful ping.
23.12.5.1-5	IPv6 Att	ribute privacyMode	Enabled Required
Category		LXI API	
Test Type		Kerberos Test, auton	nated
Rule		IPv6 Attribute privac	yModeEnabled Required
Explanation		Attribute privacyModeEnabled shall be implemented. When privacyModeEnabled is enabled, neither the link local address, unique local address nor the RA-generated addresses include the device MAC address.	
Pre Conditior	n	Enable IPv4 DHCP ro	puter
			Enable the dhcp router for IPv4
		Connect DUT	
			Connect the DUT to the test network
		Get IP from mdns	
			Search via mdns for a single lxi service and retrieve its IP address
		Enable IPv6 via Com	mon Configuration Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
		Enable IPv6 DHCPEn	abled attribute
			Enable IPv6 DHCPEnabled attribute via Common Configuration.
		Enable IPv6 RAEnabl	ed attribute
			Enable IPv6 RAEnabled attribute via Common Configuration.
		Disable IPv6 staticAc	ldressEnabled
			Disable IPv6 staticAddressEnabled attribute via Common Configuration.
		Enable IPv6 RA route	er
			Enable IPv6 RA address assignment on the router. Ensure the DUT has no DHCP address any more. Ensure the DUT has a RA address.
		Get RA IPv6 from mo	dns
			Get the RA address only via mDNS.
		GET Common Config	guration
			GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.



	Get identification file		
	Get the identification file from the device under test		
Test Procedure	Check availability of PrivacyModeEnabled in IPv6 elements		
	Check the availability of PrivacyModeEnabled attribute in IPv6 elements.		
	Disable PrivacyModeEnabled attribute		
	Disable the PrivacyModeEnabled attribute in the Common Configuration.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Wait for DUT to settle		
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.		
	Get MACAddress from Identification file		
	Get the MACAddress from the XML Identification file for further usage.		
	Get RA IPv6 from mdns		
	Get the RA address only via mDNS.		
	Verify Privacy Setting is disabled		
	Verify Privacy Setting is disabled by investigating the RA IPv6 address.		
	Enable PrivacyModeEnabled attribute		
	Enable the PrivacyModeEnabled attribute in the Common Configuration.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Get RA IPv6 from mdns		
	Get the RA address only via mDNS.		
	Verify Privacy Setting is enabled		
	Verify the Privacy Setting is enabled by investigating the RA IPv6 address.		

23.12.5.1-6 IPv6 Attribute mDNSEnabled Required

Category	LXI API
Test Type	Kerberos Test, automated
Rule	IPv6 Attribute mDNSEnabled Required
Explanation	Attribute mDNSEnabled shall be implemented. mDNSEnabled represents the state of the IPv6 multicast DNS responder in the device.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.12.4.1-6

23.12.5.1-7 IPv6 Optional Dynamic DNS

Category	LXI API
Test Type	Kerberos Test, automated
Rule	IPv6 Optional Dynamic DNS
Explanation	Dynamic DNS is optional for LXI devices. Therefore, if not implemented, the device shall ignore this attribute on a PUT.



Pre Conditi	tion Enable IPv6 RA router	
	Enable IPv6	RA address assignment on the router.
	Ensure the	DUT has no DHCP address any more.
	Ensure the	DUT has a RA address.
	Connect DUT	
	Connect th	e DUT to the test network
	Get RA IPv6 from mdns	
	Get the RA	address only via mDNS.
	GET Common Configuration	
	GET the Co succeed. Au device is se	mmon Configuration from the device. Expect the call to thentication is given, the correct URL is being used and the tup correctly.
Test Proced	dure Check the availability of dynamic	DNSEnabled attribute
	Check the a available ar available ar	vailability of dynamicDNSEnabled attribute. If attribute is d configured, test passes. Otherwise,if attribute is not d not configured, test continues to further steps.
	Enable IPv6 dynamicDNSEnabled	attribute
	Enable IPv6	dynamicDNSEnabled attribute by setting or adding
	dynamicDN	SEnabled attribute with value true in IPv6 element, if not
	available.	
	PUT Common Configuration	on Configuration and expect a valid response from the DUT
	A valid por used	is used, authorization is given and the correct URL is being
	Disable IPv6 dynamicDNSEnable	lattribute
	Disable IPv dynamicDN available.	5 dynamicDNSEnabled attribute by setting or adding SEnabled attribute with value false in IPv6 element, if not
	PUT Common Configuration	
	PUT Comm A valid por used.	on Configuration and expect a valid response from the DUT. is used, authorization is given and the correct URL is being
23.12.5.1-8	IPv6 Devices Without Dynamic DNS	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	IPv6 Devices Without Dynamic D	NS
Explanation	n Devices that do not implement d	ynamicDNS shall omit this attribute on a GET.
Test Proced	dure Computed by other tests	
	This test is	computed by the result of other tests.
Dependenc	cies 23.12.5.1-7	
23.12.5.1-9	Attribute IPv6 IPv6DynamicDNS Requir	ed

Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute IPv6 IPv6DynamicDNS Required



Explanation	Attribute IPv6DynamicDNS shall be implemented irrespective of if IPv4DynamicDNS is implemented.	
Test Procedure	Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	23.12.4.1-10	
23.12.5.1-10 Attri	bute IPv6 pingEnabled Required	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Attribute IPv6 pingEnabled Required	
Explanation	Attribute pingEnabled shall be implemented. PingEnabled represents the state of the IPv6 ICMP ping function.	
Test Procedure	Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	23.12.4.1-11	
23.12.5.1-11 IPv6	Unrecognized Extensions	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	IPv6 Unrecognized Extensions	
Explanation	LXI devices shall ignore extension attributes they do not recognize.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	Enable IPv6 via Common Configuration	
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)	
	Enable IPv6 DHCPEnabled attribute	
	Enable IPv6 DHCPEnabled attribute via Common Configuration.	
	Enable IPv6 RAEnabled attribute	
	Enable IPv6 RAEnabled attribute via Common Configuration.	
	Disable IPv6 staticAddressEnabled	
	Disable IPv6 staticAddressEnabled attribute via Common Configuration.	
	Enable IPV6 DHCP router	
	Ensure the DUT has no RA address any more.	
	Ensure the DUT has a DHCP address.	
	Connect DUT	
	Connect the DUT to the test network	
	Get DHCP IPv6 from mdns	
	Get the DHCP address only via mDNS.	



	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Add an additional attribute to IPv6 element	
	Add an additional attribute to IPv6 element, which is unknown to the device.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
23.12.5-2 Devi	ces Without IPv6 Implementation	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Devices Without IPv6 Implementation	
Explanation	Devices shall implement IPv6/@enabled. If the device does not implement IPv6 it shall always return false. If LXICommonConfiguration/@strict attribute is false such a device ignores the IPv6 element on a PUT.	
Test Procedure	Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	23.12.5.1-1	
23.12.6-1 HTTI	P Port Enabled	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	HTTP Port Enabled	
Explanation	If no services are specified the server at this port is disabled.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Check the availability of HTTP	
	Check the availability of HTTP element in the Common Configuration.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
Test Procedure	Remove all of the HTTP services	
	Remove all of the HTTP services from the Common Configuration.	

PUT Common Configuration



PUT Common Configuration and expect a valid response from the DUT.

	A valid port is used, authorization is given and the correct URL is being used.
	Ensure HTTP port is not active
	Ensure HTTP port is not active. Do a port scan.
23.12.6.1-1 F	equirements HTTP
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Requirements HTTP
Explanation	Devices that implement the unsecure HTTP protocol shall implement at least the disable and redirectAll settings of @operation. Operation controls if the HTTP server is enabled, disabled, or if it forwards all requests to HTTPS.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Enable HTTP API-LXISecurity and Human-Interface services
	Enable HTTP API-LXISecurity and Human-Interface services via Common Configuration.
Test Procedure	Check availability of HTTP operation attribute on all interfaces
	Check the availability of HTTP operation attribute on all interfaces.
	Set HTTP operation attribute value
	Set the HTTP operation attribute value to enable/disable/redirectAll.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.

23.12.6.1-2 HTTP Port Number

Category	LXI API
Test Type	Kerberos Test, manual
Rule	HTTP Port Number
Explanation	The LCI HTTP port for the LXI Web interface and the LXI API services shall be 80.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4

Report bases on file: LxiConformanceTestSuite_1.6.json



	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedu	Check interfaces API-LXISecurity and Human-Interface services
	Check interfaces for HTTP API-LXISecurity and Human-Interface services
	Modify HTTP port
	Modify HTTP port for API-LXISecurity and Human-Interface (e.g. from port 80 to port 90).
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Get root webpage via HTTP port, expect failure response
	Get root webpage via HTTP port (e.g. default port 80) and expect failure response. Port has been modified.
	Get Common Configuration via modified HTTP port, expect success response
	Fetch the Common Configuration from the device via the modified HTTP port (e.g. port 90) and expect success response.
	Get Common Configuration via HTTP port, expect failure response
	Fetch the Common Configuration from the device via HTTP port (e.g. default port 80) and expect failure response. Port has moved away from default port.
	Do LCI
	The tester is prompted to do a manual LAN reset on the DUT.
	Get Common Configuration via HTTP port, expect success response
	Fetch the Common Configuration from the device via HTTP port (e.g. default port 80) and expect success response.
	Get root webpage via HTTP port, expect success response Get root webpage via HTTP port (e.g. default port 80) and expect success response.
23.12.6.1-3	ttribute HTTP Port Required
Category	LXI API
Test Type	Kerberos Test automated
Тезстуре	

RuleAttribute HTTP Port RequiredExplanationAttribute port shall be implemented. TCP port of the HTTP server.Test ProcedureComputed by other tests
This test is computed by the result of other tests.Dependencies23.12.6.1-2

HTTP unsecure Mode

23.12.6-2



Category	LXI API
Test Type	Kerberos Test, automated
Rule	HTTP unsecure Mode
Explanation	If any service is enabled that permits changing the device configuration over an unencrypted connection the device is in unsecure mode.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check the availability of HTTP unsecure service
	Check the availability of HTTP unsecure service.
	Set the DUT to Non-Unsecure Mode
	Set all the Interface attributes value to Non-unsecure, which has impact on unsecure mode.
	Turn of all unsecure services
	Turn of all unsecure services. Go through the Common Configuration and disable all unsecure services.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Wait for DUT to settle
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check unsecure mode for interface is false
	Check the unsecure mode of the interface is set to false in the Common Configuration.
	Enable each HTTP unsecure service
	Enable each HTTP unsecure service.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.



	Wait for DUT to settle
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check unsecure mode for interface is true
	Check the unsecure mode of the interface is set to true in the Common Configuration.
	Disable each HTTP unsecure service
	Disable each HTTP unsecure service.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Wait for DUT to settle
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check unsecure mode for interface is false
	Check the unsecure mode of the interface is set to false in the Common Configuration.
23.12.6.2-1	HTTP Device Queried
Category	LXI API
Test Type	Kerberos Test, automated
Rule	HTTP Device Queried
Explanation	When the device is queried, it shall provide a Service element for each service provided by the device, with the Service/@enable attribute indicating those that are currently enabled.

Pre Condition Enable IPv4 DHCP router

Enable the dhcp router for IPv4

Connect DUT

Connect the DUT to the test network

Get IP from mdns

Search via mdns for a single lxi service and retrieve its IP address

GET Common Configuration

GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.

Availability of HTTP

Ensure that the HTTP element is available in the Common Configuration.

Enable HTTP operation attribute

Enable the HTTP operation attribute via Common Configuration



	PUT Common Configu	uration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
Test Procedure	Disable HTTP Human-	Interface service		
		Disable the HTTP Human-Interface service via Common Configuration.		
	PUT Common Configuration			
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Wait for DUT to settle			
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.		
	Get root webpage via	HTTP, expect failure		
		Get root web Page via HTTP and expect failure response.		
	Enable HTTP Human-l	Interface service		
		Enable the HTTP Human-Interface service via Common Configuration.		
	PUT Common Configu	uration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Wait for DUT to settle	Wait for DUT to settle		
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.		
	Get root webpage via	НТТР		
		Get root webpage via HTTP and expect success response.		
	Disable HTTP API-LXIS	Security service		
		Disable the HTTP API-LXISecurity service via Common-Configuration.		
	PUT Common Configu	uration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Wait for DUT to settle			
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.		
	Get Common Configu	ration via HTTP port, expect failure response		
		Fetch the Common Configuration from the device via HTTP port (e.g. default port 80) and expect failure response. Port has moved away from default port.		
	Enable HTTP API-LXIS	ecurity service		
		Enable the HTTP API-LXISecurity service via Common Configuration.		
	PUT Common Configu	uration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Wait for DUT to settle			
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.		



GET Common Configuration

GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.

23.12.7-1 HT	TPS Human Interface Content	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	HTTPS Human Interface Content	
Explanation	The HTTPS web human interface content served by LXI Secure devices shall be a superset of the content available via HTTP. That is, a device is not permitted to only offer a subset of the HTTP human interface over the secure HTTPS connection.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Enable HTTP protocol with Basic authentication	
	Enable HTTP protocol with Basic authentication via Common Configuration.	
	Enable HTTPS protocol with Basic authentication	
	Enable HTTPS protocol with Basic authentication via Common Configuration.	
	Setup User/Password with API-Access	
	Setup User/Password with API-Access via Common Configuration.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
Test Procedure	Check the available Webpages in the test configuration	
	Check the available Webpages in the test configuration.	
	Call webpage via HTTP and expect success response	
	Call webpage via HTTP and expect success response. It may also be possible to get a failure response as a call to a protected webpage over insecure connection(HTTP) is not allowed.	
	Call webpage via HTTPS and expect success response	
	Call webpage via HTTPS and expect success response.	
Post Condition	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	



	Remove User/Password
	Remove previously created Usernames and Passwords from the Commor Configuration.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23.12.7.1-1 HT	TPS Default Port
Category	LXI API
Test Type	Kerberos Test, manual
Rule	HTTPS Default Port
Explanation	The default HTTPS port shall be 443 for the Human Interface and the LXI API Service.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Modify HTTPS port for Service 'Human-Interface' and 'API-LXISecurity'
	Modify HTTPS port away from default port. (e.g. from 443 to 446)
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Get root webpage via HTTPS, expect failure
	Get root web Page via HTTPS port (e.g. default,443) and expect failure response. Either the wrong port is given or Human-Interface is disabled.
	Get Common Configuration via HTTPS port and expect failure response
	Get the Common Configuration via HTTPS port (e.g. default,443) from the device and expect failure response. Either the port is wrong, API- LXISecurity is not enabled or no authentication is given.
	Get Common Configuration via modified HTTPS port and expect success
	GET Common Configuration via the modified HTTPS port (e.g. 446) and expect a success response from the device.
	Do LCI
	The tester is prompted to do a manual LAN reset on the DUT.
	Get Common Configuration via HTTPS port and expect success response
	GET Common Configuration via HTTPS port (e.g. default,443) and expect success response. The HTTPS port is enabled, API-LXISecurity is enabled, API-Key is given.



	Get Common Configuration via modified HTTPS port and expect failure GET Common Configuration via the modified HTTPS port (e.g. 446) and	
	expect a failure response from the device.	
	Ensure HTTPS port for 'Human-Interface' and 'API-LXISecurity' have reverted Ensure HTTPS port for 'Human-Interface' and 'API-LXISecurity' have reverted to the default value(e.g. 443).	
	Get root webpage via HTTPS, expect success	
	Get root webpage via HTTPS port (e.g. default, 443) and expect success response. The HTTPS port is enabled, the Human-Interface is enabled and no authentication is required.	
23.12.7.1-2 Elen	nent HTTPS Port Required	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Element HTTPS Port Required	
Explanation	Element Port shall be implemented. TCP port of the HTTPS server.	
Test Procedure	Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	23.12.7.1-1	
23.12.7.1-3 Elen	nent HTTPS ClientAuthenticationRequired Required	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Element HTTPS ClientAuthenticationRequired Required	
Explanation	Element clientAuthenticationRequired shall be implemented. The clientAuthenticationRequired indicates if clients are required to authenticate as configured in this element.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Setup User/Password with API-Access	
	Setup User/Password with API-Access via Common Configuration.	
	Enable Human-Interface and API-LXISecurity with basic authentication	
	Enable the HTTPS services Human-Interface and API-LXISecurity with basic authentication via the Common COnfiguration	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT A valid port is used, authorization is given and the correct URL is being used.	



Test Procedure	Ensure clientAuthenticationRequired is available on all HTTPS elements
	Ensure clientAuthenticationRequired attribute is available on all HTTPS elements.
	Disable clientAuthenticationRequired
	Set the clientAuthenticationRequired attribute value to false.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Common Configuration without authentication
	GET the CommonConfiguration from the device without authentication. Expect the call to fail as no authentication was given. '404 Unauthorized' error expected.
	Get root webpage via HTTPS without authentication, expect success
	Get root webpage via HTTPS without authentication and expect success response as client authentication is not required.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Get root webpage via HTTPS with authentication and expect success response
	Get the devices root webpage via HTTPS with authentication and expect success response. The HTTPS port is enabled, the Human-Interface is enabled and the correct authentication data has been given.
	Enable clientAuthenticationRequired
	Set the clientAuthenticationRequired attribute value to true.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Common Configuration without authentication
	GET the CommonConfiguration from the device without authentication. Expect the call to fail as no authentication was given. '404 Unauthorized' error expected.
	Get root webpage via HTTPS without authentication and expect failure response
	Get the devices root webpage via HTTPS without authentication and expect failure response as authentication should be required.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Get root webpage via HTTPS with authentication and expect success response
	Get the devices root webpage via HTTPS with authentication and expect success response. The HTTPS port is enabled, the Human-Interface is enabled and the correct authentication data has been given.
Post Condition	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.



	Remove User/Password		
		Remove previously created Usernames and Passwords from the Common Configuration.	
	PUT Common Confi	guration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
23.12.7-2 HTTI	PS Without Service		
Category	LXI API		
Test Type	Kerberos Test, auton	nated	
Rule	HTTPS Without Serv	HTTPS Without Service	
Explanation	If no services are enabled, then the HTTPS server is disabled. In addition to the LXI-required HTTP client authentication, LXI devices should provide application-level authentication		
Pre Condition	Enable IPv4 DHCP ro	puter	
		Enable the dhcp router for IPv4	
	Connect DUT		
		Connect the DUT to the test network	
	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Config	guration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Disable all HTTPS se	rvices	
		Disable all HTTPS services.	
	PUT Common Confi	guration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Wait for DUT to settle		
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	
	Get root webpage v	ia HTTPS, expect failure	
		Get root web Page via HTTPS port (e.g. default,443) and expect failure response. Either the wrong port is given or Human-Interface is disabled.	
	Ensure HTTPS port is	s not active	
		Ensure HTTPS port is not active. Do a port scan on the device.	
Post Condition	Enable all HTTPS ser	vices	
		Enable all HTTPS services. If HTTP supported, this can automated by enabling HTTPS via the Comon Coonfiguration on HTTP, otherwise a user interaction may be required to ensure the next tests can continue.	

23.12.7.2-1 HTTPS Device Queried

Category	LXI API
Test Type	Kerberos Test, manual
Rule	HTTPS Device Queried



Explanation	When the device is queried, it shall provide a Service element for each service provided by the device, with the Service/@enable attribute indicating those that are currently enabled		
Pre Condition	Enable IPv4 DHCP router		
		Enable the dhcp router for IPv4	
	Connect DUT		
		Connect the DUT to the test network	
	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Confi	guration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Disable HTTPS Hum	an-Interface service	
		Disable the HTTPS Human-Interface service via Common Configuration.	
	PUT Common Confi	guration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Wait for DUT to settle		
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	
	Get root webpage via HTTPS, expect failure		
		Get root web Page via HTTPS port (e.g. default,443) and expect failure response. Either the wrong port is given or Human-Interface is disabled.	
	Enable HTTPS Human-Interface service		
		Enable the HTTPS service Human-Interface via the Common Configuration	
	PUT Common Confi	guration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Wait for DUT to sett	le	
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	
	Get root webpage via HTTPS, expect success		
		Get root webpage via HTTPS port (e.g. default, 443) and expect success response. The HTTPS port is enabled, the Human-Interface is enabled and no authentication is required.	
	Disable HTTPS API-I	LXISecurity service	
		Disable the HTTPS API-LXISecurity service via Common Confgiuration.	
	PUT Common Confi	guration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Wait for DUT to settle		
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	



		Get Common Configuration via HTTPS port and expect failure response	
			Get the Common Configuration via HTTPS port (e.g. default,443) from the device and expect failure response. Either the port is wrong, API- LXISecurity is not enabled or no authentication is given.
		Do LCI	
			The tester is prompted to do a manual LAN reset on the DUT.
		Wait for DUT to settl	e
			Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
		GET Common Config	juration
			GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
23.12.7-3	HTTPS /	Application-level Clie	ent Authentication
Category		LXI API	
Test Type		Vendor Declaration	
Rule		HTTPS Application-le	evel Client Authentication
Explanation		If the device is using indicating HTTP clien	application-level client authentication, none of the sub elements t authentication need to be enabled in the HTTPS element.
23.12.7-4	HTTPS I	LXI Common Configu	Iration With Scheme
Category		LXI API	
Test Type		Kerberos Test, autom	ated
Rule		HTTPS LXI Common	Configuration With Scheme
Explanation		When returning the l representing that sch available on the devi	XI Common Configuration, if a scheme is implemented, then the element neme shall be present. This permits clients to determine what schemes are ce.
Pre Conditio	on	Enable IPv4 DHCP ro	uter
			Enable the dhcp router for IPv4
		Connect DUT	
			Connect the DUT to the test network
		Get IP from mdns	
			Search via mdns for a single lxi service and retrieve its IP address
		GET Common Config	juration
			GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedu	ure	Check the availability	of declared SCHEME in the Common Configuration
			Check each declared SCHEME is given in the Common Configuration. A SCHEME is a declared authentication scheme such as Basic, Digest etc., these must be declared in the Test configuration.
			Note: As Basic is the only LXI required scheme, any configured scheme will be verified to be available in the Common Configuration, however only Basic will be tested functionally.



Category	LXI API		
Test Type	Kerberos Test, manual		
Rule	HTTPS I CL Security Scheme		
Explanation	After an ICI, the security scheme is not changed		
Pre Condition	Enable IDv/ DHCP router		
	Enable in v4 Drice Touter Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to		
	succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Setup User/Password with API-Access		
	Setup User/Password with API-Access via Common Configuration.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT.		
	A valid port is used, authorization is given and the correct URL is being used.		
Test Procedure	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Modify the security scheme to require Basic		
	Modify the security scheme to require Basic		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Wait for DUT to settle		
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.		
	Call webpage via HTTPS using Basic authentication and expect success response		
	response.		
	Do LCI		
	The tester is prompted to do a manual LAN reset on the DUT.		
	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Ensure Basic scheme configuration is unchanged		
	Ensure the Basic scheme configuration is unchanged in the Common Configuration.		

23.12.7-5 HTTPS LCI Security Scheme



	Call webpage via H	TTPS using Basic authentication and expect success response Call webpage via HTTPS using Basic authentication and expect success response.	
Post Condition	GET Common Conf	iguration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Remove User/Password		
		Remove previously created Usernames and Passwords from the Common Configuration.	
	PUT Common Conf	iguration PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
23.12.7-6 HTTP	S LXI API services Ena	abled	
Category	LXI API		
Test Type	Kerberos Test, manı	ual	
Rule	HTTPS LXI API servi	HTTPS I XI API services Enabled	
Explanation	On LCI the LXI Web	On ICI the IXI Web interface and the IXI API services shall be enabled	
Pre Condition	Enable IPv4 DHCP r	router	
		Enable the dhcp router for IPv4	
	Connect DUT		
		Connect the DUT to the test network	
	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Conf	iguration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Disable HTTPS API-	LXISecurity service	
		Disable the HTTPS API-LXISecurity service via Common Confgiuration.	
	Disable HTTPS Hum	nan-Interface service	
		Disable the HTTPS Human-Interface service via Common Configuration.	
	PUT Common Conf	iguration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Wait for DUT to set	tle	
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	
	Get Common Confi	guration via HTTPS port and expect failure response	
		Get the Common Configuration via HTTPS port (e.g. default,443) from the device and expect failure response. Either the port is wrong, API- LXISecurity is not enabled or no authentication is given.	


Get root webpage via HTTPS, expect failure	
	Get root web Page via HTTPS port (e.g. default,443) and expect failure response. Either the wrong port is given or Human-Interface is disabled.
Do LCI	
	The tester is prompted to do a manual LAN reset on the DUT.
GET Common Config	guration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Get root webpage via HTTPS, expect success	
	Get root webpage via HTTPS port (e.g. default, 443) and expect success response. The HTTPS port is enabled, the Human-Interface is enabled and no authentication is required.
Verify HTTPS API-LXISecurity and Human-Interface are active	
	Verify that the HTTPS API-LXISecurity and Human-Interface services are active.

23.12.8.1-1 Service Name Rules

Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Service Name Rules	
Explanation	LXI Service names are case sensitive. LXI Security specifies the following services: Human- Interface, API-LXISecurity, API-Device and other	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Check for availability of Service with name Human-Interface	
	Check the service with name Human-Interface is available.	
	Check for availability of Service with name API-LXISecurity	
	Check the service with name API-LXISecurity is available.	
	Check for availability of Service with name API-Device	
	Check the service with name API-LXISecurity is available.	
23.12.8.1-2 Attrik	oute Service Name Required	

Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute Service Name Required
Explanation	The name attribute shall be implemented. The name indicates the name of the service.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4



	Connect DUT	
	(Connect the DUT to the test network
	Get IP from mdns	
	S	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configu	ration
	(5 0	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check for 'name' attrib	oute for each HTTPS service
	E	Ensure each HTPS service has a 'name' attribute.
23.12.8.1-3 Attrik	oute Service Enabled Req	uired
Category	LXI API	
Test Type	Kerberos Test, automa	ted
Rule	Attribute Service Enab	led Required
Explanation	The enabled attribute	shall be implemented. Note this attribute is syntactically required.
Test Procedure	Computed by other te	sts
	1	This test is computed by the result of other tests.
Dependencies	23.12.7.2-1	
23.12.8.1-4 Servi	ce Devices Without addit	tional Attributes
Category	LXI API	
Test Type	Kerberos Test, automa	ted
Rule	Service Devices Withou	ut additional Attributes
Explanation	Devices that do not ur	nderstand additional attributes shall ignore them.
Pre Condition	Enable IPv4 DHCP rou	ter
	E	nable the dhcp router for IPv4
	Connect DUT	
	(Connect the DUT to the test network
	Get IP from mdns	
	S	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configu	ration
	(5 0	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Add additional unknow	wn attributes
	/ t	Add additional unknown attributes to a service. These shall be ignored by he device if unknown.
	PUT Common Configu	ration
	F /	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23.12.8.2-1 Servi	ce Element Basic	
Category	LXI API	

Kerberos Test, automated

Test Type



Rule	Service Element Basic	
Explanation	Devices shall implement Basic. When Basic is configured, devices may not be in unsecure mo	
Test Procedure	Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	23.12.7.1-3	
23.12.8.2-2 Servi	ice Element Digest	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Service Element Digest	
Explanation	Devices may implement Digest. When Digest is configured, devices may not be in unsecure mode.	
Test Procedure	Computed by other tests	
	This test is computed by the result of other tests.	
Dependencies	23.12.7.1-3	
23.12.8.2-3 Servi	ice Default Value Enabled Attribute	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Service Default Value Enabled Attribute	
Explanation	The default value of the enabled attribute of extension elements shall be True so that the presence of the element without a value indicates the mechanism is enabled. The element name should match the authentication scheme in the IANA HTTP Authentication Schemes Registry.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mons for a single ixi service and retrieve its iP address	
	GET Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Disable all additional Extension elements	
	Disable all additional Extension elements, which means all except 'Basic' and 'Digest' authentication	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Remove schemes enabled attribute from HTTPS Human-Interface service	
	The HTTPS Human-Interface service has Authentication Mechanisms. Each of these have an enabled attribute. In this teststep the enabled attribute of these Authentication Mechanism schemes shall be removed.	



	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Verify the removed extension is enabled	
	Verify the removed extension has become enabled, meaning the enabled attribute is set to true.	
23.12.8.2-4 Exte	ension HTTPS Client-authentication Scheme	
Category	LXI API	
Test Type	Vendor Declaration	
Rule	Extension HTTPS Client-authentication Scheme	
Explanation	Any extension HTTPS client-authentication scheme is permitted with unsecure mode false.	
23.12.9-1 SCP	PIRaw Receive LXI Common Configuration	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	SCPIRaw Receive LXI Common Configuration	
Explanation	When the device receives an LXI Common Configuration, only those SCPIRaw ports indicated and enabled shall be available on the device.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mons for a single ixi service and retrieve its iP address	
	GET Common Conliguration	
	succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Get Capabilities	
	Get the Capabilities for this test case from the device via Common Configuration.	
	Fill SCPIRaw elements to size of capabilities	
	Depending on the test configuration, add to the Common Configuration as many SCPIRaw elements as possible.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	



GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Disable SCPIRaw		
	Disable SCPIRaw on the device by setting the Enabled attribute of the SCPIRaw element it in the Common Configuration	
PUT Common Config	juration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
Get current TCP/IP po	ort for SCPIRaw	
	Get current TCP/IP port for SCPIRaw from the Common Configuration.	
Create TCP/IP client of	connection, expect failure	
	Create a TCP/IP client connection, this is expected to fail.	
Ensure SCPIRaw port	is not active	
	Do a port scan to ensure SCPIRaw port is not active.	
Enable SCPIRaw		
	Enable SCPIRaw on the device by setting the Enabled attribute of the SCPIRaw element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and SCPIRaw not supported.	
PUT Common Config	juration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
Create TCP/IP client of	connection, expect success	
	Create TCP/IP client connection and expect success as the correct port is being used.	
Validate ScpiRaw con	nection	
	Validate ScpiRaw connection by querying the SCPI *IDN command.	
Modify SCPIRaw port	t	
	Modify SCPIRaw port by setting the attribute port value of the SCPIRaw element in the Commom Configuration	
PUT Common Config	juration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
Create TCP/IP client of	connection, expect success	
	Create TCP/IP client connection and expect success as the correct port is being used.	
Validate ScpiRaw con	nection	
	Validate ScpiRaw connection by querying the SCPI *IDN command.	
Create TCP/IP client o	connection through old port, expect failure Create a TCP/IP client connection using the old port, this is expected to fail as the port has been changed.	



	Ensure old port is r	not active.
		Ensure old port is not active by doing a port scan. This step depends on the test and may be for example the SCPIRaw, SCPITLS, Telnet or even HiSLIP port.
Post Condition	Enable SCPIRaw	
		Enable SCPIRaw on the device by setting the Enabled attribute of the SCPIRaw element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and SCPIRaw not supported.
23.12.9.1-1 Attri	bute SCPIRaw Enabled	d Required
Category	LXI API	
Test Type	Kerberos Test, auto	omated
Rule	Attribute SCPIRaw	Enabled Required
Explanation	The enabled attribu address.	ute shall be implemented. Enabled enables the SCPIRaw server at this
Test Procedure	Computed by othe	er tests
		This test is computed by the result of other tests.
Dependencies	23.12.9-1	
23.12.9.1-2 Oper	ating in unsecure mo	de if SCPIRaw is enabled
Category	LXI API	
Test Type	Kerberos Test, auto	omated
Rule	Operating in unsec	ure mode if SCPIRaw is enabled
Explanation	The device is opera	ating in unsecure mode if SCPIRaw is enabled
Pre Condition	Enable IPv4 DHCP	router
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	GET Common Con	figuration
		succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Set the DUT to No	n-Unsecure Mode
		Set all the Interface attributes value to Non-unsecure, which has impact on unsecure mode.
	PUT Common Con	figuration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Common Con	figuration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.



	Check unsecure indicator for false
	Check the unsecure indicator state through the Common Configuration and expect it to be false.
Test Procedure	Enable SCPIRaw
	Enable SCPIRaw on the device by setting the Enabled attribute of the SCPIRaw element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and SCPIRaw not supported.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check interface unsecure state for true
	Check the interface unsecure state value for true.
	Disable SCPIRaw
	Disable SCPIRaw on the device by setting the Enabled attribute of the SCPIRaw element it in the Common Configuration
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check interface unsecure state for false
	Check the interface unsecure state value for false.
23.12.9.1-3 Attr	ibute SCPIRaw Port Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute SCPIRaw Port Required
Explanation	The port attribute shall be implemented. The port attribute specifies the port of this SCPIRaw server
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.12.9-1
23.12.9-2 Repo	ort Configuration

Category LXI API

Test Type	Vendor Declaration
Rule	Report Configuration



Explanation	When the device reports its configuration, an instance of SCPIRaw shall be provided for each active SCPIRaw connection. Devices should permit multiple clients to connect to a single SCPIRaw port.	
23.12.9-3 Serv	ice SCPIRaw	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Service SCPIRaw	
Explanation	SCPIRaw is required if the device implements SCPIRaw connections.	
Pre Condition	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Check for at least one SCPIRaw instance	
	Depending on the test configuration, at least one SCPIRaw instance is required.	
23.12.10-1 SCP	TLS Receive LXI Common Configuration	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	SCPITLS Receive LXI Common Configuration	
Explanation	When the device receives an LXI Common Configuration, only those secure raw SCPI ports indicated and enabled shall be available on the device.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Get Capabilities	
	Get the Capabilities for this test case from the device via Common Configuration.	
	Fill SCPITLS elements to size of capabilities	
	Depending on the test configuration, add to the Common Configuration as many SCPITLS elements as possible.	n
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	



GET Common Co	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
Disable SCPITLS			
	Disable SCPITLS on the device by setting the Enabled attribute of the SCPITLS element it in the Common Configuration		
PUT Common Co	nfiguration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
Get current TCP/II	P port for SCPITLS		
	Get current TCP/IP port for SCPITLS from the Common Configuration.		
Create SCPITLS co	onnection, expect failure		
	Create a SCPITLS connection, expect the conenciton to fail.		
Ensure SCPITLS p	ort is not active		
	Do a port scan to ensure SCPITLS port is not active.		
Enable SCPITLS			
	Enable SCPITLS on the device by setting the Enabled attribute of the SCPITLS element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and SCPITLS not supported.		
PUT Common Co	nfiguration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
Create SCPITLS co	onnection, expect success		
	Create a SCPITLS connection, expect the connection to succeed		
Validate SCPITLS	connection		
	Validate SCPITLS connection by querying the SCPI *IDN command.		
Modify SCPITLS p	ort		
, , ,	Modify SCPITLS port by setting the attribute port value of the SCPITLS element in the Commom Configuration.		
PUT Common Co	nfiguration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
Create SCPITLS co	onnection, expect success		
	Create a SCPITLS connection, expect the connection to succeed		
Validate SCPITLS	connection		
	Validate SCPITLS connection by querying the SCPI *IDN command.		
Create SCPITLS co	onnection through old port, expect failure		
	Create a SCPITLS connection using the old port, this is expected to fail as the port has been changed.		
Ensure old port is	not active.		
	Ensure old port is not active by doing a port scan. This step depends on the test and may be for example the SCPIRaw, SCPITLS, Telnet or even HiSLIP port.		



Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute SCPITLS Enabled Required
Explanation	The enabled attribute shall be implemented. Enables the secure raw SCPI server at this port.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.12.10-1
23.12.10.1-2 Attri	bute SCPITLS Port Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute SCPITLS Port Required
Explanation	The port attribute shall be implemented. Port specifies the port of this secure raw SCPI server
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.12.10-1
23.12.10.1-3 Attri	bute SCPITLS ClientAuthenticationRequired Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute SCPITLS ClientAuthenticationRequired Required
Explanation	The client Authentication Required attribute shall be implemented. The ClientAuthenticationRequired attribute indicates if client authentication is required. Secure raw SCPI connections use mutual TLS (mTLS) for client authentication.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Disable ClientAuthentication
	Disable the ClientAuthentication of the SCPITLS connection.
	Create SCPITLS connection with unknown, self-signed certificate
	Create SCPITLS connection with a unknown, self-signed certificate and expect a valid connection as cleint authentication is disabld.
	Enable ClientAuthentication
	Enable the ClientAuthentication of the SCPITLS connection.
	Create SCPITLS connection with unknown, self-signed certificate, expect failure
	Create SCPITLS connection with an unknown, self-signed certificate and expect the connection to fail as client authentication is enabled.

23.12.10.1-1 Attribute SCPITLS Enabled Required



Create SCPITLS connection with known certificate

Create SCPITLS connection with a known certificate and expect a valid

conenction. 23.12.10.1-4 **Attribute SCPITLS Capability Required** Category LXI API Kerberos Test, automated Test Type Rule Attribute SCPITLS Capability Required Explanation The capability attribute shall be implemented. Capability is a read-only attribute. It indicates the approximate number of SCPITLS ports that the client may configure. Test Procedure Computed by other tests This test is computed by the result of other tests. **Dependencies** 23.12.10-1 23.12.10-2 **SCPITLS Configuration Device Report** Category LXI API Kerberos Test, automated Test Type Rule **SCPITLS Configuration Device Report** Explanation When the device reports its configuration, an instance of SCPITLS shall be included for each configured secure raw SCPI connection. If none are enabled, a single disabled SCPITLS element shall be returned to indicate to the client that the capability is available. Pre Condition Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address **GET** Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly. **Test Procedure** Ensure at least one SCPITLS element is available If the test configuration indicates SCPITLS to be supported, at least one SCPITLS element must be available. Disable all SCPITLS elements Disable all SCPITLS elements via the Common Configruation. **PUT Common Configuration** PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used. **GET** Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the

- device is setup correctly.
- Ensure one SCPITLS element is available with capabilities

Ensure one SCPITLS element is available with capabilities.



23.12.10-3	Requirements Raw SCPI connection
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Requirements Raw SCPI connection
Explanation	SCPITLS is required by LXI Security if the device implements secure raw SCPI connections.
Test Proced	ure Computed by other tests
	This test is computed by the result of other tests.
Dependenci	ies 23.12.10-2
23.12.11.1-1	Attribute Telnet Enabled Required
Category	LXI API
Test Type	Vendor Declaration
Rule	Attribute Telnet Enabled Required
Explanation	The enabled attribute shall be implemented. It indicates if the Telnet server is enabled.
23.12.11.1-2	Attribute Telnet Port Required
Category	LXI API
Test Type	Vendor Declaration
Rule	Attribute Telnet Port Required
Explanation	The port attribute shall be implemented. The port attribute specifies the Telnet server port.
23.12.11.1-3	Requirements TLS On Telnet
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Requirements TLS On Telnet
Explanation	If the device implements TLS on Telnet it shall include the TLSRequired attribute in the query response regardless of the state of Telnet/@enabled
Pre Conditio	on Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Proced	ure Check device supports Telnet
	Check device supports Telnet via Common Configuration.
	Disable Telnet
	Disable Telnet via Common Configuration
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DU A valid port is used, authorization is given and the correct URL is being used.



	GET Common Configuration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check availability of	TLSRequired
		Check availability of TLSRequired, this is a required attribute.
	Enable Telnet	
		Enable Telnet via Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and Telnet not supported.
	PUT Common Configuration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
GET Common Configuration		guration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check availability of	TLSRequired
		Check availability of TLSRequired, this is a required attribute.

23.12.11.1-4 Attribute Telnet TLSRequired Required

Category	LXI API
Test Type	Vendor Declaration
Rule Attribute Telnet TLSRequired Required	
Explanation	TLSRequired shall be implemented if the device Telnet implementation supports TLS.
23.12.11.1-5	Telnet MTLS Client Certificate Authentication
Category	LXI API
Test Type	Vendor Declaration
Rule	Telnet MTLS Client Certificate Authentication
Explanation	The mTLS client certificate authentication configured in Interface/ClientAuthentication/

ClientCertAuthentication shall be used.

23.12.11.1-6	Requirements mTLS
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Requirements mTLS
Explanation	If the device implements mTLS (client authentication) on telnet it shall include the clientAuthenticationRequired attribute in the query response regardless of the state of Telnet/ @enabled.
Pre Conditio	on Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.



Test Procedure	Check device suppo	Check device supports Telnet		
		Check device supports Telnet via Common Configuration.		
	Disable Telnet			
		Disable Telnet via Common Configuration		
	PUT Common Conf	PUT Common Configuration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	GET Common Configuration			
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Check the availability of clientAuthenticationRequired			
		Check the availability of the attribute clientAuthenticationRequired for this test case. This attribute is expected to be available.		
	Enable Telnet			
		Enable Telnet via Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and Telnet not supported.		
	PUT Common Configuration			
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	GET Common Conf	GET Common Configuration		
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Check the availabili	Check the availability of clientAuthenticationRequired		
		Check the availability of the attribute clientAuthenticationRequired for this test case. This attribute is expected to be available.		

23.12.11.1-7 Attribute Telnet ClientAuthenticationRequired Required

Category		LXI API	
Test Type		Kerberos Test, automated	
Rule		Attribute Telnet ClientAuthenticationRequired Required	
Explanation		The clientAuthenticationRequired attribute shall be implemented if the device Telnet implementation supports TLS.	
Test Procedure		Computed by other tests This test is computed by the result of other tests.	
Dependenci	ies	23.12.11.1-6	
23.12.11.1-8	Attribut	e Telnet Capability Required	
Category		LXI API	

5 ,	
Test Type	Vendor Declaration
Rule	Attribute Telnet Capability Required
Explanation	The capability attribute shall be implemented. Capability is a read-only attribute. It indicates the approximate number of Telnet ports that the client may configure.



Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	Telnet Devices Without additional Attributes		
Explanation	Devices that do not understand additional attributes shall ignore them.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
Test Procedure	Check the device supports TELNET		
	Check the device supports TELNET via Common Configuration.		
	Add unrecognized Telnet attribute		
	Add an unrecognized Telnet attribute via Common Configuration.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
23.12.12.1-1 Attrib	ute HiSLIP Enabled Required		
Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	Attribute HiSLIP Enabled Required		
Explanation	The enabled attribute shall be implemented. The enabled attribute indicates if the HiSLIP serve is enabled.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		

23.12.11.1-9 Telnet Devices Without additional Attributes

	is enabled.		
Pre Condition	Enable IPv4 DHCP router	Enable IPv4 DHCP router	
	Enable	e the dhcp router for IPv4	
	Connect DUT		
	Conne	ect the DUT to the test network	
	Get IP from mdns		
	Search	via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration		
	GET th succe device	e Common Configuration from the device. Expect the call to ed. Authentication is given, the correct URL is being used and the e is setup correctly.	
Test Procedure	Check the device supports HiSLIP		
	Check config	the device supports HiSLIP. This is validated by checking the test uration input from the Tester.	
	Check all HiSLIP elements for Enabled attribute		
	Check	all HiSLIP elements have an Enabled attribute available.	



Disable HiSLIP	
	Disable HiSLIP by setting the enabled attribute of the HiSLIP element to false via Common Configuration
PUT Common Config	guration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Get service name fro	m mdns
	Get the service name for the device under test from mDNS.
Wait HiSLIP service to	o disappear
	Wait for the HiSLIP mDNS service (_hisliptcp) to disappear from the mDNS system.
Get configured HiSLI	P port and expect failure response
	Try to get the configured HiSLIP port via mdns and expect a failure response as the HiSLIP service should not be advertised anymore.
Create HiSLIP conne	ction, expect failure
	Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.
Ensure HISLIP port is	not active
	Do a port scan of the device to ensure the HiSLIP port is not active.
Enable HiSLIP	
	Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIP element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.
Disable HiSLIP attrib	utes mustStartEncrypted and encryptionMandatory
	Disable the HiSLIP attribues mustStartEncrypted and encryptionMandatory attributes to establish HiSLIP connection without encryption. This may only be required if LXI Security is supported.
PUT Common Config	guration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Get HiSLIP Port	
	Get the HiSLIP port, which is advertised via the mDNS service.
Create HiSLIP connec	ction, expect success Create a HiSLIP connection to the device-under-test (DUT) and expect a valid connection.
HiSLIP guery *IDN	
	Query the SCPI *IDN command via HiSLIP and expect a valid response.
Modify HiSLIP port v	ia Common Configuration
	Modify the HisLIP port to something other than the dafult(4880) port.
PUT Common Confi	nuration
	PUT Common Configuration and expect a valid response from the DUT.
	A valid port is used, authorization is given and the correct URL is being used.



	Create HiSLIP conr	nection, expect success
		Create a HiSLIP connection to the device-under-test (DUT) and expect a valid connection.
	HiSLIP query *IDN	
		Query the SCPI *IDN command via HiSLIP and expect a valid response.
	Create HiSLIP conr	nection, expect failure
		Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.
	Ensure HiSLIP old	port is not active
		Do a port scan of the device to ensure the previous HiSLIP port is no more active after modifying the port.
23.12.12.1-2 HiS	LIP unsecureMode	
Category	LXI API	
Test Type	Kerberos Test, auto	omated
Rule	HiSLIP unsecureMo	ode
Explanation	The device is in un @encryptionMand	secure mode unless both HiSLIP/@mustStartEncrypted and HiSLIP/ atory are true.
Pre Condition	Enable IPv4 DHCP	router
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	GET Common Con	figuration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check the device s	upports HiSLIP
		Check the device supports HiSLIP. This is validated by checking the test configuration input from the Tester.
	Enable HiSLIP	
		Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIP element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.
	Set the DUT to No	n-Unsecure Mode
		Set all the Interface attributes value to Non-unsecure, which has impact on unsecure mode.
	PUT Common Con	figuration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Test Procedure	Get service name f	rom mdns
		Get the service name for the device under test from mDNS.
	Get HiSLIP Port	
		Get the HiSLIP port, which is advertised via the mDNS service.



Check availability of	f LXI defined Authentication mechanisms
	Check the availability of LXI defined Authentication mechanisms. At least one defined mechanism must be available such as ANONYMOUS, PLAIN, SCRAM, MTLS, etc.
Enable each authen	tication mechanism
	Enable each given authentication mechanism via Common Configuration. This could be ANONYMOUS, PLAIN, SCRAM, MTLS, etc.
Setup User/Passwor	rd with API-Access
	Setup User/Password with API-Access via Common Configuration.
Generate root certif	ïcate
	Generate a root certificate for testing. This certificate will be used for example to generate a derived certificate.
Add root certificate	
	Add root certificate to DUT via Common Configuration.
Set attribute mustSt	tartEncrypted
	Set the attribute mustStartEncrypted to true or false depending on the test case loop.
Set attribute encryp	tionMandatory
	Set the attribute encryptionMandatory to true or false depending on the test case loop.
PUT Common Conf	iguration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
GET Common Confi	iguration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Check unsecure ind	icator state
	Verify the unsecure indicator state through Common Configuration. It can be true/false as per expected result. If the MustStartEncrypted is set to true and EncryptionMandatory is set to false, the unsecure flag should be true and vice versa. In the case both attributes are true, the unsecure flag should be false
Create HiSLIP conne	ection without encryption
	Create successful HiSLIP connection without encryption. This succeeds if the mustStartEncrypted and encryptionMandatory are both disabled, otherwise the connection fails.
Establish HiSLIP sec	ure connection using specific authentication mechanism
	Establish HiSLIP secure connection using specific authentication mechanism. Depending on the current test case iteration, the apropriate mechanism PLAIN, SCRAM, MTLS, Anonymous shall be used.
Turn off HiSLIP encr	yption on client side
	Turn off the HiSLIP encryption on client side. If the DUT has encryptionMandatory disabled, the HiSLIP connection will not disconnect. HiSLIP connection should be disconnected when encryptionMandatory is enabled. A new HiSLIP connection will fail, if server has mustStartEncrypted enabled.



	Turn on HiSLIP encry	ption on client side	
		Turn on HiSLIP encryption on client side. Successfully establish a HiSLIP secure connection using an authentication mechanism except in the case where mustStartEncryption is set to false and encrytionMandatory is set to true.	
Post Condition	tion GET Common Config	GET Common Configuration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Remove User/Passwo	rd	
		Remove previously created Usernames and Passwords from the Common Configuration.	
	PUT Common Config	PUT Common Configuration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
23.12.12.1-3	Attribute HiSLIP Port Require	ed	
Category	LXI API		

category	
Test Type	Kerberos Test, automated
Rule	Attribute HiSLIP Port Required
Explanation	The port attribute shall be implemented. The port attribute indicates the TCP port from which the HiSLIP server is served.
Test Procedure	Computed by other tests This test is computed by the result of other tests.
Dependencies	23.12.12.1-2

23.12.12.1-4 Attribute HiSLIP MustStartEncrypted Required

.12.12.1-4	Attribute HISLIP Musistartencrypted Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute HiSLIP MustStartEncrypted Required
Explanation	The mustStartEncrypted attribute shall be implemented. mustStartEncrypted controls the initial encryption. If enabled, a secure connection must be initially made to this server. It can be subsequently stepped down to an unsecure connection if encryptionMandatory is not true.
Test Procedu	re Computed by other tests
	This test is computed by the result of other tests.
Dependenci	es 23.12.12.1-3

23.12.12.1-5 HiSLIP MustStartEncrypted unsecure Mode

Category	LXI API
Test Type	Kerberos Test, automated
Rule	HiSLIP MustStartEncrypted unsecure Mode
Explanation	The device is in unsecure mode if mustStartEncrypted is false.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.12.12.1-3



23.12.12.1-6	Attribute HiSLIP encryptionMandatory Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute HiSLIP encryptionMandatory Required
Explanation	The encryptionMandatory attribute shall be implemented. The encryptionMandatory attribute indicates that this HiSLIP Server must always have encryption on. That is, the connection must be started securely, and the encryption may not be subsequently turned off.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	GET Common Configuration
	GET common configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Proced	ure Check all HiSLIP elements for encryptionMandatory attribute Check all HiSLIP elements hae an encryptionMandatory attribute available.
23.12.12.1-7	HiSLIP EncryptionMandatory unsecure Mode
Category	LXI API
Test Type	Kerberos Test, automated
Rule	HiSLIP EncryptionMandatory unsecure Mode
Explanation	The device is in unsecure mode if encryptionMandatory is false for any enabled HiSLIP servers.
Test Proced	Line Computed by other tests
	This test is computed by the result of other tests.
Dependenci	es 23.12.12.1-3
23.12.12.2-1	Support of Client Authentication
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Support of Client Authentication
Explanation	Devices that support the LXI Security Extended Function and the LXI HiSLIP Extended function shall support Client Authentication.
Pre Conditio	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mons
	Search via muns for a single ixi service and retrieve its iP address



	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Test Procedure	Check all HiSLIP elements for 'ClientAuthenticationMechanisms' element Check all HiSLIP elements have a 'ClientAuthenticationMechanisms' element available.
23.12.13-1 Clier	ntAuthenticationMechanisms Includes In Response
Category	LXI API
Test Type	Kerberos Test, automated
Rule	ClientAuthenticationMechanisms Includes In Response
Explanation	The device shall include in its response each element that it implements, indicating a false enable attribute where disabled. Devices shall omit the elements that represent mechanisms they do not support.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.12.13.1-1 23.12.13.1-3 23.12.13.1-4 23.12.13.1-7
23.12.13.1-1 Auth	henticationMechanism Support Of ANONYMOUS
Category	LXI API
Test Type	Kerberos Test, automated
Rule	AuthenticationMechanism Support Of ANONYMOUS
Explanation	Devices that support LXI Security and the LXI HiSLIP Extended function shall support ANONYMOUS. The element ANONYMOUS indicates that clients can authenticate using the SASL anonymous mechanism.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mons for a single is service and refrieve its in address
	Charle the device even extendicular
	Check the device supports HiSLIP
	Check the device supports HiSLIP Check the device supports HiSLIP. This is validated by checking the test configuration input from the Tester.
	Check the device supports HiSLIP Check the device supports HiSLIP. This is validated by checking the test configuration input from the Tester. GET Common Configuration
	Check the device supports HiSLIP Check the device supports HiSLIP. This is validated by checking the test configuration input from the Tester. GET Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check the device supports HiSLIP Check the device supports HiSLIP. This is validated by checking the test configuration input from the Tester. GET Common Configuration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly. Set the DUT to Non-Unsecure Mode



	Enable HiSLIP	
		Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIP element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.
	PUT Common Confi	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Wait for DUT to sett	le
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
Test Procedure	Check ClientAuthen	tication mechanism ANONYMOUS is available Check the ClientAuthentication element for AONYMOUS authentication
		mechanism is available.
	Enable ANONYMOU	JS via Common Configuration
		Enable the authentication mechanism ANONYMOUS via Common Configuration.
	PUT Common Confi	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Wait for DUT to sett	le
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
	Check unsecure mod	de for interface is false
		Check the unsecure mode of the interface is set to false in the Common Configuration.
	Create HiSLIP conne	ection, expect failure
		Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.
	Establish secured co	nnection with ANONYMOUS
		Establish a secured connection using ANONYMOUS authentication mechanism.
	HiSLIP query *IDN	
		Query the SCPI *IDN command via HiSLIP and expect a valid response.
	Disable ANONYMO	US via Common Configuration
		Disable the authentication mechanism ANONYMOUS via Common Configuration
	Check unsecure mod	de for interface is false
		Check the unsecure mode of the interface is set to false in the Common Configuration.
	Create HiSLIP conne	ection, expect failure
		Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.



Establish secured connection with ANONYMOUS, expect failure Establish a secured connection using ANONYMOUS authentication mechanism and expect the connection to fail. 23.12.13.1-2 **ClientAuthenticationMechanisms ANONYMOUS IVI Device Requirements** Category LXI API Kerberos Test, automated Test Type Rule ClientAuthenticationMechanisms ANONYMOUS IVI Device Requirements **Explanation** The IVI-6.5 SASL Mechanism Specification details the specific device and client requirements for the generation of usernames and passwords. Devices shall comply with the IVI device requirements. Test Procedure Computed by other tests This test is computed by the result of other tests. **Dependencies** 23.12.17.1-2 23.12.13.1-3 **ClientAuthenticationMechanisms Plain IVI Device Requirements** Category I XI API Kerberos Test, automated Test Type Rule ClientAuthenticationMechanisms Plain IVI Device Requirements **Explanation** The IVI-6.5 SASL Mechanism Specification details the specific device and client requirements for the generation of usernames and passwords. Devices shall comply with the IVI device requirements. **Test Procedure** Computed by other tests This test is computed by the result of other tests. Dependencies 23.12.17.1-2 23.12.13.1-4 **ClientAuthenticationMechanisms Support Of PLAIN** Category LXI API Test Type Kerberos Test, automated Rule ClientAuthenticationMechanisms Support Of PLAIN Explanation Devices that support LXI Security and the LXI HiSLIP Extended function shall support PLAIN. Configuring PLAIN does not put the device into unsecure mode. Pre Condition Enable IPv4 DHCP router Enable the dhcp router for IPv4 Connect DUT Connect the DUT to the test network Get IP from mdns Search via mdns for a single lxi service and retrieve its IP address Check the device supports HiSLIP Check the device supports HiSLIP. This is validated by checking the test configuration input from the Tester. **GET Common Configuration** GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the

device is setup correctly.

Report bases on file: LxiConformanceTestSuite_1.6.json



	Set the DUT to Nor	n-Unsecure Mode	
		Set all the Interface attributes value to Non-unsecure, which has impact on unsecure mode.	
	Enable HiSLIP		
		Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIP element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.	
	Setup user/passwoi	rd with api access	
		Set a username and password with api access in the Common Configuration.	
	PUT Common Conf	iguration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Wait for DUT to set	tle	
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	
Test Procedure	Get service name fr	om mdns	
		Get the service name for the device under test from mDNS.	
	Get HiSLIP Port		
		Get the HiSLIP port, which is advertised via the mDNS service.	
	Check clientAuthen	tication PLAIN is available	
		Check the ClientAuthentication element for PLAIN is available in the Common Configuration.	
	Enable PLAIN		
		Enable PLAIN authentication mechanism via the Common Configuration.	
	PUT Common Conf	iguration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Wait for DUT to settle		
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	
	GET Common Conf	iguration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Check unsecure mode for interface is false		
		Check the unsecure mode of the interface is set to false in the Common Configuration.	
	Create HiSLIP conne	ection, expect failure	
		Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.	
	Establish secured co	onnection using PLAIN	
		Establish secured connection, using PLAIN Authentication	
	HiSLIP query *IDN		
		Query the SCPI *IDN command via HiSLIP and expect a valid response.	



	Disconnect HiSLIP	' connection		
		Disconnect the HiSLIP connection from DUT.		
	Disable PLAIN via	Common Configuration		
		Disable the authentication mechanism PLAIN via the Common Configuration.		
	PUT Common Co	nfiguration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Wait for DUT to se	ettle		
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.		
	GET Common Co	nfiguration		
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Check unsecure m	ode for interface is false		
		Check the unsecure mode of the interface is set to false in the Common Configuration.		
	Create HiSLIP con	nection, expect failure		
		Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.		
	Establish secure c	onnection using PLAIN, expect failure		
		Establish a secure connection using PLAIN Authentication and expect the connection to fail.		
Condition	GET Common Configuration			
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Remove User/Pas	Remove User/Password		
		Remove previously created Usernames and Passwords from the Common Configuration.		
	PUT Common Co	PUT Common Configuration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		

23.12.13.1-5 ClientAuthenticationMechanisms SCRAM IVI Device Requirements

Category	LXI API
Test Type	Kerberos Test, automated
Rule	ClientAuthenticationMechanisms SCRAM IVI Device Requirements
Explanation	The IVI 6.5 SASL Mechanism Specification details the specific device and client requirements for the use of the SASL SCRAM mechanism with HiSLIP. Devices shall comply with the IVI device requirements.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.12.16.1-2

Post



23.12.13.1-6	ClientAuthenticationMechanisms Support Of SCRAM
Category	LXI API
Test Type	Kerberos Test, automated
Rule	ClientAuthenticationMechanisms Support Of SCRAM
Explanation	Devices that support LXI Security and the LXI HiSLIP Extended function shall support SCRAM. Configuring SCRAM does not put the device into unsecure mode.
Pre Conditic	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	Check the device supports HiSLIP
	Check the device supports HiSLIP. This is validated by checking the test configuration input from the Tester.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Set the DUT to Non-Unsecure Mode
	Set all the Interface attributes value to Non-unsecure, which has impact on unsecure mode.
	Enable HiSLIP
	Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIP element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.
	Setup user/password with api access
	Set a username and password with api access in the Common Configuration.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Wait for DUT to settle
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
Test Procedu	Get service name from mdns
	Get the service name for the device under test from mDNS.
	Get HiSLIP Port
	Get the HiSLIP port, which is advertised via the mDNS service.
	Check clientAuthentication mechanism SCRAM is available
	Check the ClientAuthentication element for SCRAM authentication mechanism is available.
	Enable SCRAM
	Enable SCRAM authentication mechanism via Common Configuration.



PUT Common Con	figuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Wait for DUT to se	ttle
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
GET Common Con	figuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Check unsecure me	ode for interface is false
	Check the unsecure mode of the interface is set to false in the Common Configuration.
Create HiSLIP conr	nection, expect failure
	Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.
Establish secure co	nnection using SCRAM
	Establish a secure connection using SCRAM Authentication and expect the conenction to succeed.
HiSLIP query *IDN	
	Query the SCPI *IDN command via HiSLIP and expect a valid response.
Disconnect HiSLIP	connection
	Disconnect the HiSLIP connection from DUT.
Disable SCRAM via	a Common Configuration
	Disable the authentication mechanism SCRAM via the Common Configuration.
PUT Common Con	figuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Wait for DUT to se	ttle
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
GET Common Con	figuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Check unsecure me	ode for interface is false
	Check the unsecure mode of the interface is set to false in the Common Configuration.
Create HiSLIP conr	nection, expect failure
	Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.



	Establish secure connection using SCRAM, expect failure	
	Establish a secure connection using SCRAM Authentication and expe the connection to fail.	ect
Post Condition	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and t device is setup correctly.	:he
	Remove User/Password	
	Remove previously created Usernames and Passwords from the Com Configuration.	Imon
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the D A valid port is used, authorization is given and the correct URL is bei used.	UT. ng
23.12.13.1-7 Client	uthenticationMechanisms Not Implemented Mechanisms	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	ClientAuthenticationMechanisms Not Implemented Mechanisms	
Explanation	Devices shall ignore mechanisms that they do not implement.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	succeed. Authentication is given, the correct URL is being used and t device is setup correctly.	:he
Test Procedure	Add unknown element in ClientAuthenticationMechanisms	
	Add an unknown element in ClientAuthenticationMechanisms in the Common Configuration.	
	PUT Common Configuration	
	PUT Common Configuration and expect a valid response from the D A valid port is used, authorization is given and the correct URL is bei used.	UT. ng
23.12.13-2 Device	specific SASL Mechanisms	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Device-specific SASL Mechanisms	
Explanation	Devices that implement device-specific SASL mechanisms shall follow the pattern of defining	



Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test net	work	
	Get IP from mdns		
	Search via mdns for a single lxi	service and retrieve its IP address	
	GET Common Configuration		
	GET the Common Configuration succeed. Authentication is given device is setup correctly.	n from the device. Expect the call to n, the correct URL is being used and the	
Test Procedure	Check each AuthenticationMechanism element for en Check each AuthenticationMech	abled attribute anism element has an enabled attribute.	
23.12.14-1 Authe	enticationMechanism Client Authentication Capabilitio	es	
Category	I XI API		
Test Time	Vender Dederation		
Test Type	Authentiation Machanism Client Authentiation Cons		
Kule	Authentication Mechanism Client Authentication Capa	Dilities	
Explanation	Security Extended Function shall be created using this require additional configuration, they shall define the AuthenticationMechanism ComplexType.	r own type by extending the	
23.12.14.1-1 LCI En	nable mechanism		
Category	LXI API		
Test Type	Kerberos Test, manual		
Rule	LCI Enable mechanism		
Explanation	On LCI, the enabled mechanisms do not change.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test net	work	
	Get IP from mdns		
	Search via mdns for a single lxi s	service and retrieve its IP address	
	GET Common Configuration		
	GET the Common Configuration succeed. Authentication is given device is setup correctly.	n from the device. Expect the call to n, the correct URL is being used and the	
Test Procedure	Get all authentication mechanism values		
	Get all of the authentication me Configuration for further proces	chanism values from the Common sing.	
	Do LCI		
	The tester is prompted to do a r	nanual LAN reset on the DUT.	
	GET Common Configuration		
	GET the Common Configuration succeed. Authentication is given device is setup correctly.	i from the device. Expect the call to i, the correct URL is being used and the	



Get all authentication mechanism values		
	Get all of the authentication mechanism values from the Common Configuration for further processing.	
Match enabled mech	nanisms did not change	
	Check enabled mechanisms in the Common Configuration. Ensure the configured mechanisms did not change after a PUT Common Configuration.	
Invert enabled mech	anisms	
	Invert enabled mechanisms in the Common Configuration. Iterate through all mechanism and invert the enabled attribute.	
PUT Common Config	guration	
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
Do LCI		
	The tester is prompted to do a manual LAN reset on the DUT.	
GET Common Config	guration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Get all authenticatio	n mechanism values	
	Get all of the authentication mechanism values from the Common Configuration for further processing.	
Match enabled mech	nanisms did not change	
	Check enabled mechanisms in the Common Configuration. Ensure the configured mechanisms did not change after a PUT Common Configuration.	

23.12.14.1-2 Attribute AuthenticationMechanisms Enable Required

Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	Attribute AuthenticationMechanisms Enable Required		
Explanation	Attribute enabled shall be implemented. The enabled attribute indicates that the SASL mechanism or HTTP scheme is enabled.		
Test Procedure	Computed by other tests		
	This test is computed by the result of other tests.		
Dependencies	23.12.13.1-1		
	23.12.13.1-3		
	23.12.13.1-4		
	23.12.13.1-7		

23.12.15.1-1 Attribute VXI11 Enable Required

Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute VXI11 Enable Required
Explanation	Attribute enabled shall be implemented. The device is in unsecure mode if VXI-11 is enabled. Enabled state of the VXI11 server at this address.



Pre Condition	Enable IPv4 DHCP	router	
		Enable the dhcp router for IPv4	
	Connect DUT		
		Connect the DUT to the test network	
	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Cont	figuration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Check the availabili	ity of VXI-11 element	
		Check the availability of VXI-11 element in the Common Configuration	
	Set the DUT to No	n-Unsecure Mode	
		Set all the Interface attributes value to Non-unsecure, which has impact on unsecure mode.	
	PUT Common Con	figuration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Wait for DUT to set	ttle	
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	
	GET Common Cont	figuration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Check unsecure mo	ode for interface is false	
		Check the unsecure mode of the interface is set to false in the Common Configuration.	
Test Procedure	Enable VXI-11		
		Set VXI11 'enabled' attribute to true via Common Configuration.	
	PUT Common Con	figuration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Wait for DUT to settle		
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	
	GET Common Cont	figuration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Check unsecure mo	ode for interface is true	
		Check the unsecure mode of the interface is set to true in the Common Configuration.	
	Disable VXI-11		
		Set VXI11 'enabled' attribute to false via Common Configuration.	

23.12.16-1



	PUT Common Conf	- iguration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Wait for DUT to set	tle	
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	
	GET Common Conf	iguration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Check unsecure mo	de for interface is false Check the unsecure mode of the interface is set to false in the Common Configuration.	
.12.16-1 Clier	ntAuthentication Inform	mation	
Category	LXI API		
Test Type	Kerberos Test, auto	mated	
Rule	ClientAuthenticatio	n Information	
Explanation	Information in Clier authentication. For EXTERNAL authent	Information in ClientAuthentication shall be used by all protocols that provide client authentication. For instance, a certificate thumbprint that the device accepts for HiSLIP EXTERNAL authentication, will also be accepted for telnet mTLS.	
Pre Condition	Enable IPv4 DHCP	router	
		Enable the dhcp router for IPv4	
	Connect DUT		
		Connect the DUT to the test network	
	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Conf	iguration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
	Check device suppo	orts HISLIP	
		Check device supports HISLIP via test configuration.	
	Check device suppo	orts Telnet	
		Check device supports Telnet via Common Configuration.	
	Check device suppo	orts SCPITLS	
		Check device supports SCPITLS via Common Configuration.	
	Enable HiSLIP		
		Enable HiSLIP on the device by setting the Enabled attribute of the HiSLIP element it in the Common Configuration. A PUT Common Configuration may fail, if strict mode is enabled and HiSLIP not supported.	
	PUT Common Conf	ïguration	
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	



Test Procedure	Setup a root certificate and a thumbprint		
	Setup a root certificate and a thumbprint. Set a root certificate and a thumprint via the Common Configuration.		
	Add root certificate and thumbprint to device		
	Add a root certificate and a thumbprint to the device by sending this via Common Configuration.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Get service name from mdns		
	Get the service name for the device under test from mDNS.		
	Get HiSLIP Port		
	Get the HiSLIP port, which is advertised via the mDNS service.		
	Create HiSLIP connection, expect failure		
	Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.		
	Establish secure connection via HiSLIP with root certificate/thumbprint		
	Establish secure connection via HISLIP using a certificate derived from a root certificate or matches the thumbprint of a certificate on the device.		
	HiSLIP query *IDN		
	Query the SCPI *IDN command via HiSLIP and expect a valid response.		
	Disconnect HiSLIP connection		
	Disconnect the HiSLIP connection from DUT.		
	Create Telnet connection using root certificate/thumbprint		
	If supported, create a Telnet connection with the MTLS mechanism using a valid certificate to match against a root certificate or thumbprint.		
	Create SCPI-TLS connection using root certificate/thumbprint		
	If supported, create a SCPI-TLS connection with the MTLS mechanism using a valid certificate to match against a root certificate or thumbprint.		
Post Condition	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Delete Root certificates		
	Delete all Root certificates from the device via Common Configuration.		
	Delete CertThumbprint		
	Delete all CertThumbprint from the device via the Common Configuration.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
23 12 16 1-1 Δttri	hute ClientAuthentication ScramHashIterationCount Required		

23.12.1 6.1-1 Attribute ClientAuthentication ScramHashIterationCount Required

LXI API Category

Vendor Declaration Test Type



Rule	Attribute ClientAuthentication ScramHashIterationCount Required		
Explanation	Attribute scramHashIterationC scramHashIterationCount sets credentials. Required for device LXICommonConfiguration.	ite scramHashIterationCount shall be implemented. The attribute HashIterationCount sets the minimum iteration count that SCRAM uses to hash the client Itials. Required for devices that support the SCRAM SASL mechanism via the nmonConfiguration.	
23.12.16.1-2 Attri	bute ClientAuthentication Scram	ChannelBindingRequired	
Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	Attribute ClientAuthentication	ScramChannelBindingRequired	
Explanation	Attribute scramChannelBinding support the SCRAM SASL mec	Required shall be implemented. Required for devices that nanism via the LXICommonConfiguration.	
Pre Condition	Enable IPv4 DHCP router		
	Enable th	e dhcp router for IPv4	
	Connect DUT		
	Connect	the DUT to the test network	
	Get IP from mdns	- made - fam - single bit - mission and activity its ID - dalarse	
	Search V	a mans for a single IXI service and retrieve its IP address	
	GET Common Configuration GET the succeed. device is	Common Configuration from the device. Expect the call to Authentication is given, the correct URL is being used and the setup correctly.	
	Setup User/Password with API	Access	
	Setup Us	er/Password with API-Access via Common Configuration.	
	PUT Common Configuration		
	PUT Con A valid p used.	mon Configuration and expect a valid response from the DUT. ort is used, authorization is given and the correct URL is being	
	Wait for DUT to settle		
	Wait for neccessa	he dut to settle. Due to changes made in previous steps, this is ry to ensure a device is settled before continuing.	
Test Procedure	Get service name from mdns		
	Get the s	ervice name for the device under test from mDNS.	
	Get HiSLIP Port		
	Get the P	ISLIP port, which is advertised via the mDNS service.	
	Check SCRAM support	PAM is supported via Common Configuration	
	Enable SCRAM	RAM is supported via common configuration.	
	Enable SCICAM Fnable S	RAM authentication mechanism via Common Configuration	
	Modify ScramChannelBinding	attribute	
	Modify S is change	cramChannelBinding attribute. Dependign on the test case this ed between true and false.	
	PUT Common Configuration		
	PUT Con A valid p used.	mon Configuration and expect a valid response from the DUT. ort is used, authorization is given and the correct URL is being	



	Create HiSLIP conne	ction, expect failure
		Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.
	Establish secure con	nection using SCRAM without channel binding
		Establish secure connection using SCRAM authentication mechanism without channel binding. If ScramChannelBinding is false, then expect success response otherwise expect failure response
	Disconnect HiSLIP co	onnection
		Disconnect the HiSLIP connection from DUT.
	Create HiSLIP conne	ction, expect failure
		Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.
	Establish secure con	nection using SCRAM with channel binding, expect success Establish secure connection using SCRAM authentication mechanism with channel binding. The call is expected to succeed.
	Disconnect HiSLIP co	onnection
		Disconnect the HiSLIP connection from DUT.
Post Condition	GET Common Config	guration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Remove User/Passw	ord
		Remove previously created Usernames and Passwords from the Common Configuration.
	PUT Common Config	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23 12 16 2-1 Attribu	ite ClientAuthenticat	ion ClientCredential
Category		
Test Type	Karbaras Tast auton	aatad
lest lype	Attribute ClientAuth	
Rule	Attribute ClientAuth	
Explanation	with an optional pas	sword and an indication if this used has API Access rights.
Pre Condition	Enable IPv4 DHCP ro	buter
		Enable the dhcp router for IPv4
	Connect DUI	
	Cat ID feature and the	
	Get ip from mans	Search via mons for a single ly service and retrieve its IP address
	GET Common Confi	scarch via mans for a single in service and retrieve its in address
		CET the Common Configuration from the device Evenet the set!

GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.



Test Procedure	Check availability of ClientCredential		
	Check availability of ClientCredential via Common Configuration.		
23.12.16.2-2 Attrib	ute ClientAuthentication ClientCertAuthentication		
Category			
Test Tures	Kerbaras Tast automated		
lest lype	Attribute ClientAuthentication ClientCartAuthertication		
Kule			
Explanation	Element ClientCertAuthentication shall be implemented.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPV4		
	Connect DUI		
	Get IP from mans		
	CET Common Configuration		
	GET the Common Configuration from the device. Expect the call to		
	succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
Test Procedure	Check availability of ClientCertAuthentication		
	Check availability of ClientCertAuthentication via Common Configuration.		
23.12.17.1-1 Client	Credential User Name Rule		
Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	ClientCredential User Name Rule		
Explanation	IXI devices shall accent user names composed of alpha-numeric strings. User names shall be		
Explanation	case-sensitive.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Enable API-LXISecurity with basic authentication		
	Enable the service API-LXISecurity with basic authentication.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
Test Procedure	Setup User/Password with API-Access		
	Setup User/Password with API-Access via Common Configuration.		


	PUT Common Config	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Wait for DUT to settle	e
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
	GET Common Config	juration with username/password, expect success
		GET Common Configuration with valid username/password. Expect the call to succeed.
	GET Common Config	juration with username/password (wrong case), expect failure
		GET the Common Configuration with a username/password pair which is not setup on the device. Expect the call to fail.
	Check device suppor	ts HISLIP
		Check device supports HISLIP via test configuration.
	Get service name from	m mdns
		Get the service name for the device under test from mDNS.
	Get HiSLIP Port	
		Get the HiSLIP port, which is advertised via the mDNS service.
	Create HiSLIP connec	ction, expect failure
		Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.
	Establish HISLIP secu	re connection with username/password, expect success
		Establish HISLIP secure connection with username/password, expect success.
	Disconnect HiSLIP co	nnection
		Disconnect the HiSLIP connection from DUT.
	Create HiSLIP connec	ction, expect failure
		Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.
	Establish HISLIP secu	re connection with username/password (wrong case), expect failure
		Establish HISLIP secure connection with a username/password pair which is not setup on the device. Expect the connection to fail.
	Disconnect HiSLIP co	nnection
		Disconnect the HiSLIP connection from DUT.
Post Condition	GET Common Config	juration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Remove User/Passwo	ord
		Remove previously created Usernames and Passwords from the Common Configuration.
	PUT Common Config	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.



23.12.17.1-2 Client	teredential oser for Device Requirements		
Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	ClientCredential User IVI Device Requirements		
Explanation	The IVI-6.5 SASL Mechanism Specification details the specific device and client requirements for the generation of usernames and passwords. Devices shall comply with the IVI device requirements.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
Test Procedure	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Create the client credential		
	Create the client credential with empty user name/ user name larger than 255 octets/user name smaller than 255 octets/user name with @/user name with back slash		
	PUT Common Configuration with client credential		
	PUT Common Configuration with client credential. Expect failure response if empty user name/ user name larger than 255 octets otherwise expect success response		
23.12.17.1-3 Attrik	pute ClientCredential User		
Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	Attribute ClientCredential User		
Explanation	Attribute user shall be implemented. Attribute user that may be authenticated on the device.		
Test Procedure	Computed by other tests		
	This test is computed by the result of other tests.		
Dependencies	23.12.17.1-1		
23 12 17 1_/ Client	tCradential Password IVI Requirements		

23.12.17.1-2 **ClientCredential User IVI Device Requirements**

23.12.17.1-4 ClientCredential Password IVI Requirements

Category	LXI API
Test Type	Vendor Declaration
Rule	ClientCredential Password IVI Requirements
Explanation	The IVI-6.5 SASL Mechanism Specification details the specific device and client requirements for the generation of usernames and passwords. Devices shall comply with the IVI device requirements.

23.12.17.1-5 Attribute ClientCredential Password Required

gory
gory

Test Type Kerberos Test, automated

Report bases on file: LxiConformanceTestSuite_1.6.json



Rule	Attribute ClientCredential Password Required
Explanation	Attribute password shall be implemented. The attribute password contains the password associated with this user name.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.12.17.1-1
23.12.17.1-6 Attril	bute ClientCredential APIAccess Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute ClientCredential APIAccess Required
Explanation	Attribute APIAccess shall be implemented. The attribute APIAccess indicates if this user is authorized to use the API.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Enable API-LXISecurity with basic authentication
	Enable the service API-LXISecurity with basic authentication.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Test Procedure	Setup User/Password with API-Access
	Setup User/Password with API-Access via Common Configuration.
	Setup User/Password without API-Access
	Create client credential with user and password without API-Access.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Wait for DUT to settle
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
	GET Common Configuration with API-Access, expect success
	GET the Common Configuration with API-Access and expect a valid response XML.
	GET Common Configuration with username/password without API Access, expect failure
	GET Common Configuration with username/password without API Access and expect the call to fail as no API access for the username and password.



	Check device supports HISLIP
	Check device supports HISLIP via test configuration.
	Get service name from mdns
	Get the service name for the device under test from mDNS.
	Get HiSLIP Port
	Get the HiSLIP port, which is advertised via the mDNS service.
	Create HiSLIP connection, expect failure
	Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.
	Establish HISLIP secure connection with username/password, expect success
	Establish HISLIP secure connection with username/password, expect success.
	Disconnect HiSLIP connection
	Disconnect the HiSLIP connection from DUT.
	Create HiSLIP connection, expect failure
	Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.
	Establish HISLIP secure connection with username/password without API-Access, expect success
	Establish HISLIP secure connection with username/password without API- Access, expect success.
	Disconnect HiSLIP connection
	Disconnect the HiSLIP connection from DUT.
Post Condition	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Remove User/Password
	Remove previously created Usernames and Passwords from the Common Configuration.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23.12.18-1 Clien	tCertAuthentication Acceptance of Client Certificates
Category	LXI API
Test Type	Kerberos Test, automated
Rule	ClientCertAuthentication Acceptance of Client Certificates
Explanation	Devices shall accept client certificates as valid if they are signed by a root certificate specified in this element, or if they have a thumbprint that matches a thumbprint specified in this element.
Test Procedure	Computed by other tests

This test is computed by the result of other tests.

Dependencies 23.12.16-1



23.12.18.1-1 Clie	ntCertAuthentication R	oot certification PEMs	
Category	LXI API		
Test Type	Kerberos Test, auto	mated	
Rule	ClientCertAuthentic	ation Root certification PEMs	
Explanation	Root certification Pl shall not be used.	EMs shall be semantically validated. For instance, expired root certificates	
Pre Condition	Enable IPv4 DHCP r	outer	
		Enable the dhcp router for IPv4	
	Connect DUT		
		Connect the DUT to the test network	
	Get IP from mdns		
		Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Conf	iguration	
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Setup valid root ce	tificate	
		Setup valid root certificate. Set a valid root certificate via the Common Configuration.	
	PUT Common Configuration		
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.	
	Check device suppo	orts HISLIP	
		Check device supports HISLIP via test configuration.	
	Get service name fr	om mdns	
		Get the service name for the device under test from mDNS.	
	Get HiSLIP Port		
		Get the HiSLIP port, which is advertised via the mDNS service.	
	Create HiSLIP connection, expect failure		
		Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.	
	Establish HISLIP sec	ure connection using mTLS clientAuthentication, expect success	
		Establish a HISLIP secure connection using mTLS clientAuthentication, expect success.	
	Disconnect HiSLIP of	connection	
		Disconnect the HiSLIP connection from DUT.	
	Setup an expired ro	oot certificate	
		Setup an expired root certificate. Set an expired root certificate via the Common Configuration. The device may fail to accept an expired root certificate.	



	PUT Common Config	guration, expect failure
		PUT the Common Configuration to the device and expect failure response. Check previous step for better understanding. This may be due to incorrect data, no authentication or any other reason for the API call to fail.
	Create HiSLIP conne	ction, expect failure
		Connect to DUT via HiSLIP and expect the connection to fail. This could be because HiSLIP has been disabled, the wrong port is being used or encryption is required.
	Establish HISLIP secu	re connection using mTLS clientAuthentication, expect failure Establish a HISLIP secure connection using mTLS clientAuthentication and expect failure.
	Disconnect HiSLIP co	onnection Disconnect the HiSLIP connection from DUT.
23.12.18.1-2 Clien	tCertAuthentication Su	pport of RootCertPEM
Category	LXI API	
Test Type	Kerberos Test, auton	nated
Rule	ClientCertAuthentica	tion Support of RootCertPEM
Explanation	RootCertPEM shall b to validate client cer	e supported. RootCertPEM has a single root certificate the device shall use tificates
Pre Condition	Enable IPv4 DHCP ro	outer
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	GEI Common Config	guration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Delete Root certifica	tes
		Delete all Root certificates from the device via Common Configuration.
	PUT Common Config	guration
		PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Test Procedure	Check for RootCertP	EM element, expect absent
		Check for RootCertPEM element in the common-configuration, expect it to be absent.
	Generate self-signed	root certificate
		Generate self-signed root certificate to be added to the DUT as a root certificate.
	Add root certificate	
		Add root certificate to DUT via Common Configuration.



	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Wait for DUT to settle
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check for RootCertPEM element
	Check for RootCertPEM element. It is expected to be available.
Post Condition	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Delete Root certificates
	Delete all Root certificates from the device via Common Configuration.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23.12.18.1-3 Clien	ntCertAuthentication Support of CertThumbprint
Category	LXI API
Test Type	Kerberos Test, automated
Rule	ClientCertAuthentication Support of CertThumbprint
Explanation	CertThumbprint shall be supported. Each instance of this element has the thumbprint of a client certificate.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Delete CertThumbprint
	Delete all CertThumbprint from the device via the Common Configuration.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.



Test Procedure	Check for CertThumbprint element, expect absent		
	Check for CertThumbprint element. It is expected to be missing/absent.		
	Generate Thumbprint certificate		
	Generate a Thumbprint of a certificate. This may be used to set to the DUT for MLS authentication.		
	Add Thumbprint to the device		
	Add Thumbprint to the device via Common Configuration.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Wait for DUT to settle		
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.		
	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Check for CertThumbprint element		
	Check for CertThumbprint element and expect it to be available in the Common Configuration.		
Post Condition	GET Common Configuration		
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.		
	Delete CertThumbprint		
	Delete all CertThumbprint from the device via the Common Configuration.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
23.12.19.1-1 Attri	bute CertThumbprint Hash Required		
Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	Attribute CertThumbprint Hash Required		
Explanation	Attribute hash shall be implemented. The attribute hash indicates the hash function used to create this thumbPrint.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		

Get IP from mdns

Search via mdns for a single lxi service and retrieve its IP address



	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Check availability of Hash in all CertThumbprint elements	
	Check the availability of Hash in all CertThumbprint elements.	
23.12.19.1-2 Attri	ibute CertThumbprint ThumbPrint Required	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Attribute CertThumbprint ThumbPrint Required	
Explanation	Attribute thumbPrint shall be implemented. The attribute thumbPrint contains the certificate thumbPrint.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	
Test Procedure	Check availability of thumbPrint in all CertThumbprint elements	
	Check the availability of a thumbPrint in all CertThumbprint elements of the Common Configuration.	
23.13-1 LXID	DeviceSpecificConfigurationSchema LXI Device Specific Configuration	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	LXIDeviceSpecificConfigurationSchema LXI Device Specific Configuration	
Explanation	Devices shall retain the LXI Device Specific configuration and only utilize it when automatic configuration is disabled. Thus, writing the LXI Device Specific Configuration while automatic configuration is active then disabling automatic configuration will result in the device using the configuration specified in LXI Device Specific Configuration.	
Pre Condition	Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
	Search via mdns for a single lxi service and retrieve its IP address	
	GET Common Configuration	
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.	



	Ensure DHCP and AutoIP are enabled for IPv4		
	Ensure DHCP and AutoIP are enabled for IPv4. Use the Common Configuration for automated configuration.		
	Enable IPv6 via Common Configuration		
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	GET Device Specific Configuration		
	GET the Device Specific Configuration from device via API /lxi/api/device- specific-configuration using API-Key.		
Test Procedure	Setup IPv4 static address		
	Setup IPv4 static addressby putting the Device Specific Configuration to the DUT with a valid IPv4 static configuration.		
	Setup IPv6 static address		
	Setup IPv6 static address by putting the Device Specific Configuration to the DUT with a valid IPv6 static configuration.		
	PUT Device Specific Configuration		
	PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.		
	Ping IPv4 static address for failure		
	Ping the DUT via IPv4 static address and expect it to fail.		
	Check advertisement of IPv4 static address via mDNS stopped		
	Check the advertisement of the IPv4 static address via mDNS has stopped.		
	Enable IPv6 staticAddressEnabled attribute via Common Configuration		
	Use the Common Configuration from the DUT and set the IPv6 attribute staticAddressEnabled to enabled.		
	Disable IPv6 DHCPEnabled and RAEnabled attributes via Common Configuration		
	Use the Common Configuration from the DUT and disable the IPv6 attributes DHCPEnabled and RAEnabled.		
	PUT Common Configuration		
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.		
	Check advertisement of IPv6 static address via mDNS		
	Ensure the IPv6 static address is being advertised via mDNS. Look for single lxi service, get the IPv6 address from the service and ensure it is the expected static IPv6 address.		
	Ping IPv6 static address for success		
	Ping the DUT's IPv6 static address and expect a successful ping.		
	GET Device Specific Configuration		
	GET the Device Specific Configuration from device via API /lxi/api/device- specific-configuration using API-Key.		



Ensure IPv4 values a	are not the configured static values
	Get the IPv4 values from the Device Spcific Configuration and ensure the values are not the expected static values.
Ensure IPv6 values a	are the configured static values
	Ensure the given IPv6 values match the previously configured static values.
Enable IPv4 static b	y disabling DHCP and AutoIP
	Enable IPv4 static addressing by disabling DHCP and AutoIP via the Common Configuration.
PUT Common Confi	iguration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Ping IPv4 static add	ress for expect success
	Check the device is using IPv4 static address by pinging the static address and expect success
Check advertisemer	nt of IPv4 static address via mDNS
	Ensure the IPv4 static address is being advertised via mDNS. Look for single lxi service, get the IP address from this service and ensure it is the expected static IPv4 address.
GET Device Specific	Configuration
	GET the Device Specific Configuration from device via API /lxi/api/device- specific-configuration using API-Key.
Ensure IPv4 values a	are the configured static values
	Get the IPv4 values from the Device Spcific Configuration and ensure the values are the expected and configured static values.
Disable IPv4 static b	y enabling DHCP and AutoIP
	Disable IPv4 static by enabling DHCP and AutoIP via the Common Configuration.
PUT Common Confi	iguration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
Remove IPv6 Static	IP address from Device
	Remove IPv6 Static IP address from Device by sending the Device Specific Configuration without IPv6 static address assigned.
PUT Device Specific	Configuration
	PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.
Ping IPv4 static add	ress for failure
	Ping the DUT via IPv4 static address and expect it to fail.
Ping IPv6 static add	ress for failure
	Ping the DUT via IPv6 static address and expect it to fail.
Check advertisemer	nt of IPv4 static address via mDNS stopped
	Check the advertisement of the IPv4 static address via mDNS has stopped.



	Check advertisemen	t of IPv6 static address via mDNS stopped Check the advertisement of the IPv6 static address via mDNS has stopped.
	GET Device Specific	Configuration
		GET the Device Specific Configuration from device via API /lxi/api/device-specific-configuration using API-Key.
	Ensure IPv4 values a	re not the configured static values
		Get the IPv4 values from the Device Spcific Configuration and ensure the values are not the expected static values.
	Ensure IPv6 values a	re not the configured static values
		Get the IPv6 values from the Device Spcific Configuration and ensure the values are not the expected static values.
23.13.1.1-1 Attrib	ute LXIDeviceSpecific	Configuration Name Required
Category	LXI API	
Test Type	Kerberos Test, autor	nated
Rule	Attribute LXIDevices	SpecificConfiguration Name Required
Explanation	Attribute name shal described by this do the interface in the l interface shall use th	be implemented. The attribute name indicates the name of the interface ocument. name is required on a GET and shall indicate the name used for XICommonConfiguration Interface/@name attribute. Devices with a single ne name LXI.
Pre Condition	Enable IPv4 DHCP re	puter
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mons for a single lxi service and retrieve its IP address
	GET Common Conti	guration GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Check number of in	terfaces
		Ensure the Device Specific Configuration has at least one interface available.
Test Procedure	GET Device Specific	Configuration
		GET the Device Specific Configuration from device via API /lxi/api/device- specific-configuration using API-Key.
	Ensure name attribu	te is available
		Ensure the name attribute is available in the Device Specific Configuration
	Ensure name attribu	te value is 'LXI'
		If the device has a single interface, the name attribute value is 'LXI'. If multiple interfaces available, then the main LXI interface should be declared as 'LXI'.
23.13.1.2-1 Accep	tance of IPv4	

Category LXI API

Test Type Kerberos Test, automated



Rule	Acceptance of IPv4
Explanation	LXI Devices shall accept IPv4Device. The element IPv4Device contains the device-specific configuration related to IPv4.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.13-1
23.13.1.2-2 Abse	nt IPv4
Category	LXI API
Test Type	Kerberos Test, manual
Rule	Absent IPv4
Explanation	If IPv4Device is absent, and the LXI Common Configuration does not specify automatic configuration, the IPv4 capability is disabled.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	Enable IPv6 via Common Configuration
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCPEnabled attribute
	Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnabled attribute
	Enable IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticAddressEnabled
	Disable IPv6 staticAddressEnabled attribute via Common Configuration.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Enable IPv6 DHCP router
	Enable IPv6 DHCP address assignment on the router. Ensure the DUT has no RA address any more. Ensure the DUT has a DHCP address.
	Get DHCP IPv6 from mdns
	Get the DHCP address only via mDNS.
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	GET Device Specific Configuration
	GET the Device Specific Configuration from device via API /lxi/api/device- specific-configuration using API-Key.



	Setup IPv4 static address
	Setup IPv4 static addressby putting the Device Specific Configuration to the DUT with a valid IPv4 static configuration.
	PUT Device Specific Configuration
	PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.
	Ensure IPv4 is enabled
	Ensure IPv4 is enabled. This may be by enabling the stack on the webpage, via the frontpanel or via Common Configuraion.
	Disable IPv4 DHCP and AutoIP via Common Configuration
	Disable the DHCP and AutoIP attributes of the IPv4 element in the Common Configuration and put the Common Configuration to the DUT.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
Test Procedure	Remove IPv4 Device element
	Remove IPv4 Device element from the Device Specific Configuration
	PUT Device Specific Configuration
	PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.
	Ping the DUT for failure
	Ping the DUT via IPv4 which is expected to fail.
	Check the mdns advertisement has stopped
	Ensure the mdns advertisement has stopped, this means no _lxitcp services are available in the network anymore.
Post Condition	Reenable IPv4 stack
	Reenable IPv4 stack. If IPv6 is supported, this may be done automated via IPv6, otherwise an LCI is required.
23.13.1.2-3 Accep	ptance Of IPv6

Category	LXI API
Test Type	Kerberos Test, automated
Rule	Acceptance Of IPv6
Explanation	LXI Devices shall accept IPv6Device. IPv6Device contains the device-specific configuration related to IPv6.
Test Procedure	Computed by other tests This test is computed by the result of other tests.
Dependencies	23.13-1

Dependencies

23.13.1.2-4 Absent IPv6

Category	LXI API
Test Type	Kerberos Test, automated
Rule	Absent IPv6



Explanation	If IPv6Device is absent, and the LXI Common Configuration does not specify any automatic configuration, the IPv6 capability is disabled.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
	GET Common Configuration
	GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	Enable IPv6 via Common Configuration
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	Enable IPv6 DHCPEnabled attribute
	Enable IPv6 DHCPEnabled attribute via Common Configuration.
	Enable IPv6 RAEnabled attribute
	Enable IPv6 RAEnabled attribute via Common Configuration.
	Disable IPv6 staticAddressEnabled
	Disable IPv6 staticAddressEnabled attribute via Common Configuration.
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	GET Device Specific Configuration
	GET the Device Specific Configuration from device via API /lxi/api/device- specific-configuration using API-Key.
	Setup IPv6 static address
	Setup IPv6 static address by putting the Device Specific Configuration to the DUT with a valid IPv6 static configuration.
	PUT Device Specific Configuration
	PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.
	Disable IPv6 DHCPEnabled and RAEnabled via Common Configuration Disable the IPv6 attributes DHCPEnabled and RAEnabled via the Common Configuration
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
	Get IPv6 from mdns
	Get all available IPv6 addresses via mDNS. It is possible for a device to have several IPv6 addresses, at a minimum the link-local address will be returned.
Test Procedure	Remove IPv6 Device element
	Remove the IPv6 Device element from the Device Specific Configuration.



	PUT Device Specific Configuration PUT the valid Device Specific Configuration to the device via /lxi/api/
	device-specific-configuration using API-Key. Expect a valid response.
	Ping the DUT via IPv6 for failure
	Ping the DUT via IPv6 using the gloabal IPv6 address and expect it to fail.
	Check the mdns advertisement has stopped
	Ensure the mdns advertisement has stopped, this means no _lxitcp services are available in the network anymore.
Post Condition	Enable IPv6 via Common Configuration
	Connect via IPv4 and enable IPv6 via the Common Configuration. (If IPv6 is supported)
	PUT Common Configuration
	PUT Common Configuration and expect a valid response from the DUT. A valid port is used, authorization is given and the correct URL is being used.
23.13.2.1-1 Attri	bute IPv4Device Address Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute IPv4Device Address Required
Explanation	Attribute address shall be implemented. The attribute address contains the IPv4 address of the device.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.13-1
23.13.2.1-2 Attri	bute IPv4Device SubnetMask Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute IPv4Device SubnetMask Required
Explanation	Attribute subnetMask shall be implemented. The attribute subnetMask contains the subnet mask to use.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.13-1
23.13.2.1-3 Attri	bute IPv4Device Gateway Required
Category	LXI API
Test Type	Kerberos Test, automated
Rule	Attribute IPv4Device Gateway Required
Explanation	Attribute gateway shall be implemented. The attribute gateway contains the gateway address.
Test Procedure	Computed by other tests
Dependencies	23 13-1
Dependencies	

Report bases on file: LxiConformanceTestSuite_1.6.json



Category	LXI AF	
Test Type	Kerbe	ros Test, automated
Rule	Attrib	ute IPv4Device DNS1 Required
Explanatic	on Attrib server	ute dns1 shall be implemented. The attribute dns1 contains the address of the first DNS
Test Proce	edure Comp	uted by other tests
		This test is computed by the result of other tests.
Depender	ncies 23.13	-1
23.13.2.1-5	Attribute IPv4	Device DNS2 Required
Category	LXI AF	
Test Type	Kerbe	ros Test, automated
Rule	Attrib	ute IPv4Device DNS2 Required
Explanatic	on Attrib (alterr	ute dns2 shall be implemented. The attribute dns2 dns2 is the address of the second nate) DNS server.
Test Proce	edure Comp	uted by other tests
		This test is computed by the result of other tests.
Depender	ncies 23.13	-1
23.13.2.1-6	IPv4Device Un	recognized Extensions
Category	LXI AF	
Test Type	Kerbe	ros Test, automated
Rule	IPv4D	evice Unrecognized Extensions
Explanatic	on LXI de	evices shall ignore extension attributes they do not recognize.
Pre Condi	tion Enable	e IPv4 DHCP router
		Enable the dhcp router for IPv4
	Conne	ect DUT
		Connect the DUT to the test network
	Get IP	from mdns
		Search via mons for a single ixi service and retrieve its iP address
	GETL	GET the Device Specific Configuration GET the Device Specific Configuration from device via API /lxi/api/device- specific-configuration using API-Key.
Test Proce	dure Add u	Inknown attribute to IPv4 element
		Add an unknown attribute to IPv4 element in the Device Specific Configuration
	PUT D	Device Specific Configuration
		PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.
23.13.3.1-1	IPv6Device Un	recognized Extensions

23.13.2.1-4 **Attribute IPv4Device DNS1 Required**

23.13.3.1-1 IPv6Device Unrecognized Extensions

Category	LXI API
Test Type	Kerberos Test, automated
Rule	IPv6Device Unrecognized Extensions



Explanation	LXI devices shall ignore extension attributes they do not recognize.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single IXI service and retrieve its IP address
	GET Device Specific Configuration GET the Device Specific Configuration from device via API /lxi/api/device- specific-configuration using API-Key.
Test Procedure	Add unknown attribute to IPv6 element
	Add an unknown attribute to IPv6 element. Unknown attributes shall be ignored, if not recognized.
	PUT Device Specific Configuration
	PUT the valid Device Specific Configuration to the device via /lxi/api/ device-specific-configuration using API-Key. Expect a valid response.
23.13.3.2-1 IPv6	StaticAddress
Category	LXI API
Test Type	Kerberos Test, automated
Rule	IPv6 StaticAddress
Explanation	Devices shall accept at least one StaticAddress. Element StaticAddress is optional and contains the device static address
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.13-1
23.13.3.2-2 IPv6	LinkLocalAddress In Response
Category	LXI API
Test Type	Kerberos Test, automated
Rule	IPv6 LinkLocalAddress In Response
Explanation	LXI Devices shall include the link local address in responses. Element LinkLocalAddress is a read-only field that contains the devices current link local address.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.

Dependencies 23.13-1

23.13.3.2-3 IPv6 GlobalAddress In Response

Category	LXI API
Test Type	Kerberos Test, automated
Rule	IPv6 GlobalAddress In Response
Explanation	GlobalAddress element shall be included in the response for every device global address. Element GlobalAddress is a read-only element that contains the addresses provided to the device via router advertisement or DHCP.
Test Procedure	Computed by other tests

This test is computed by the result of other tests.



Dependencies 23.13-1 23.13.4.1-1 **Attribute IPv6 Address Required** Category LXI API Kerberos Test, automated Test Type Rule Attribute IPv6 Address Required Explanation The address attribute shall be implemented. The attribute address contains the IPv6 address in CIDR notation. Test Procedure Computed by other tests This test is computed by the result of other tests. **Dependencies** 23.13-1 23.13.4.1-2 **Attribute IPv6 Router Required** Category LXI API Kerberos Test, automated Test Type Rule Attribute IPv6 Router Required **Explanation** The router attribute shall be implemented. The attribute router contains the router IPv6 address if this IPv6Address has an associated router. The address is in CIDR notation. Test Procedure Computed by other tests This test is computed by the result of other tests. **Dependencies** 23.13-1 23.13.4.1-3 **Attribute IPv6 DNS Required** Category LXI API Kerberos Test, automated Test Type Rule Attribute IPv6 DNS Required Explanation The dns attribute shall be implemented. The attribute dns contains the address of the IPv6 domain name server if this IPv6Address has an associated dns. The address is in CIDR notation. **Test Procedure** Computed by other tests This test is computed by the result of other tests. Dependencies 23.13-1 23.14.1.1-1 Attribute LXICertificateRef GUID Required Category LXI API Kerberos Test, automated Test Type Rule Attribute LXICertificateRef GUID Required **Explanation** The GUID attribute shall be implemented. The GUID identifies the certificate, certificate list, or CSR. The GUID is returned by the Certificate List API. **Test Procedure** Computed by other tests This test is computed by the result of other tests. **Dependencies** 23.10.13 23.10.17 23.15.2.1-1 **Attribute CertificateInfo GUID Required** I XI API Category Kerberos Test, automated Test Type

Report bases on file: LxiConformanceTestSuite_1.6.json



Rule	Attribute Certificate	Info GUID Required
Explanation	The GUID attribute shall be implemented. GUID is a Globally Unique Identifier generated by the device to represent this certificate.	
Test Procedure	Computed by other	tests
		This test is computed by the result of other tests.
Dependencies	23.10.12	
23.15.2.1-2 Attri	bute CertificateInfo Ty	pe Required
Category	LXI API	
Test Type	Kerberos Test, autor	nated
Rule	Attribute CertificateInfo Type Required	
Explanation	The Type attribute s	hall be implemented. Type indicates the kind of entity.
Pre Condition	Enable IPv4 DHCP r	outer
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
	Get certificates	
		Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS
	Remove all LDevID a	and CSR certificates
		Iterate over the certificates list and delete all certificates which match the types LDevID and CSR from the dut, using the DELETE /lxi/api/ certificates/ <guid> API.</guid>
	Create self-signed c	ertificate
	-	Request the DUT to create a self-signed certificate via API. The created self-signed certificate is used as an LDevID for the device.
	Get CSR	
		Get CSR certificate via the /lxi/api/get-csr API.
Test Procedure	Get certificates	
		Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS
	Check certificate Info	os values for each type
		Check the Certificate Information values match for the given type.
	Identify IDevID, LDe	vID and CSR
		Expect 3 Certificate Infos, one for IDevID, LDevID and CSR. Through the previous steps it ensures that exactly three certificate informations is available. One for each type.
	Verify the expiration	a date attribute for LDevID/CSR certificate
		Verify the expiration date attribute for LDevID/CSR certificate in the certificate list received from the DUT.
	Verify the Enabled a	ttribute for LDevID/CSR certificate Verify the Enabled attribute for LDevID/CSR certificate in the certificates
		list received from the DUT.



23.15.2.1-3	Attribute CertificateInfo DNSName Required	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Attribute CertificateInfo DNSName Required	
Explanation	The DNSName attribute shall be implemented. DNSName is the DNS Name from the certificate.	
Test Proced	Computed by other tests	
	This test is computed by the result of other tests.	
Dependenc	es 23.15.2.1-2	
23.15.2.1-4	Attribute CertificateInfo Enabled Required	
Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	Attribute CertificateInfo Enabled Required	
Explanatior	The Enabled attribute shall be implemented. DNSName is the DNS Name from the certificate. Enabled indicates if the corresponding certificate or certificate chain is enabled for use by the device. Enabled is meaningless for Certificate Signing Requests. Enabled shall be returned true for CSRs.	e
Pre Conditi	n Enable IPv4 DHCP router	
	Enable the dhcp router for IPv4	
	Connect DUT	
	Connect the DUT to the test network	
	Get IP from mdns	
Test Proced	Ire Create self-signed certificate	
	Request the DUT to create a self-signed certificate via API. The created self-signed certificate via API. The created	
	Wait for DUT to settle	
	Wait for the dut to settle. Due to changes made in previous steps, this i neccessary to ensure a device is settled before continuing.	is
	Get certificates	
	Get the certificates list from device via API /lxi/api/certificates using API Key, to extract all GUIDS	-
	Get certificate Info matching GUID	
	Check the certificate list contains the required GUID and get the certificate Info from the list.	
	Expect enabled attribute is true	
	Check the enabled attribute for the certificate is set to true and therefor enabled.	re
	Get active certificate	
	Get the currently used certificate (LDevID) for MTLS authentication and for the webpage.	
	Disable certificate	
	Disable the certificate via the API /lxi/api/certificates/ <guid>/enabled using the apropriate GUID and the boolean value false.</guid>	



Get certificates	
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS
Get certificate Info m	atching GUID
	Check the certificate list contains the required GUID and get the certificate Info from the list.
Expect enabled attrib	oute is false
	Check the enabled attribute for the certificate is set to false and therefore disabled.
Enable certificate	
	Enable the certificate via the API /lxi/api/certificates/ <guid>/enabled and the apropriate GUID and the boolean value true.</guid>
Get certificates	
	Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS
Get certificate Info m	atching GUID
	Check the certificate list contains the required GUID and get the certificate Info from the list.
Expect enabled attrib	pute is true
	Check the enabled attribute for the certificate is set to true and therefore enabled.

23.15.2.1-5 CertificateInfo Expiration Of Date And Time

Category	LXI API	
Test Type	Kerberos Test, automated	
Rule	CertificateInfo Expiration Of Date And Time	
Explanation	The expiration date and time shall be expressed in ASN.1 format using ASN.1 GeneralizedTime per RFC5280.	
Pre Condition	Enable IPv4 DHCP router	
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
Test Procedure	Create certificate via	certificate-request with ASN.1 GerneralizedTime before 2050 Get a certificate via a certificate-request with ASN.1 GerneralizedTime before 2050. Expect a valid response.
	Create certificate via certificate-request with ASN.1 GerneralizedTime after 2050	
		Get a certificate via a certificate-request with ASN.1 GerneralizedTime after 2050. Expect a valid response.
	Wait for DUT to settle	
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.
	Get certificates	
		Get the certificates list from device via API /lxi/api/certificates using API- Key, to extract all GUIDS



	Get certificate Info	matching GUID	
		Check the certificate list contains the required GUID and get the certificate Info from the list.	
	Validate expiration	DateTime	
		Validate the expirationDateTime for ASN.1 GeneralizedTime, and check it matches the known time.	
23.15.2.1-6 Attri	bute CertificateInfo E	<pre>cpirationDateTime Required</pre>	
Category	LXI API		
Test Type	Kerberos Test, auto	mated	
Rule	Attribute Certificate	Info ExpirationDateTime Required	
Explanation	The expirationDate contains the expira contain the request ExpirationDateTime	The expirationDateTime attribute shall be implemented. The attribute expirationDateTime contains the expiration date and time of the certificate. For a CSR, expirationDateTime shall contain the requested expiration time from the CSR. If the CSR LXICertificateRequest/ ExpirationDateTime was absent an empty string shall be returned.	
Test Procedure	Computed by othe	r tests	
		This test is computed by the result of other tests.	
Dependencies	23.15.2.1-2 23.15.2.1-5		
23.16.1.1-1 LXIC	ertificateRequest Expi	ration Of Date And Time	
Category	LXI API		
Test Type	Kerberos Test, auto	mated	
Rule	LXICertificateReque	st Expiration Of Date And Time	
Explanation	The expiration date per RFC5280.	and time shall be expressed in ASN.1 format using ASN.1 GeneralizedTime	
Pre Condition Enable IPv4 DHCP router		router	
		Enable the dhcp router for IPv4	
	Connect DUT		
		Connect the DUT to the test network	
	Get IP from mdns		
Taat Dua aa duua		Search via mons for a single ixi service and retrieve its IP address	
lest Procedure	Get CSR via certific	Get a csr via a certificate-request with ASN.1 Gerneralized Time before 2050 2050. Expect a valid response.	
	Get CSR via certific	ate-request with ASN.1 GerneralizedTime after 2050	
		Get a csr via a certificate-request with ASN.1 GerneralizedTime after 2050. Expect a valid response.	
	Get CSR via certific	ate-request with incorrect date and time format, expect failure	
		Get a CSR via a certificate-request with an incorrect date and time format. Expect an error as response.	
	Create certificate vi	a certificate-request with ASN.1 GerneralizedTime before 2050	
		Get a certificate via a certificate-request with ASN.1 GerneralizedTime before 2050. Expect a valid response.	
	Create certificate vi	a certificate-request with ASN.1 GerneralizedTime after 2050	
		Get a certificate via a certificate-request with ASN.1 GerneralizedTime after 2050. Expect a valid response.	



Create certificate via certificate-request with incorrect date and time format, expect failure Create a certificate via a certificate-request with an incorrect date and time format. This will end in an error response due to incorrect date and format.

23.16.1.1-2	LXICertificateRequest SignatureAlgorithm Unsupported		
Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	LXICertificateRequest SignatureAlgorithm Unsupported		
Explanatior	If the device does not support the requested crypto suite, then the certificate request shall fail. The element SignatureAlgorithm specifies the cryptography suite that the certificate key set should use.		
Pre Conditi	on Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
Test Proced	ure Create simple certificate requests with unsupported SignatureAlgorithm		
	Create a certificate request xml with simple values and an unsupported SignatureAlgorithm.		
	GET CSR with unsupported SignatureAlgorithm		
	Get a CSR via a certificate-request with an unsupported signature algorithm. Expect an error as response.		
	Wait for DUT to settle		
	Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.		
	Create self-signed certificate, expect failure		
	Create a self signed certificate via a certificate-request with an incorrect SignatureAlgorithm format. Expect an error as response.		
23.16.2-1	Default Field Subjectname		
Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	Default Field Subjectname		
Explanatior	The default fields for the subject name shall be the values used in the device IDevID. SubjectName contains the various attributes of the requested certificate subject.		
Pre Conditi	on Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
Test Proced	ure Get certificates		
	Get the certificates list from device via API /lxi/api/certificates using API-		

Key, to extract all GUIDS



	Get IDevID Certificate from the device		
		Get the IDevID Certificate from the device via API. Use the identified GUID from the certificate list to receive the correct certificate.	
	Validate 'IDevId' cert	ificate	
		Validate 'IDevId' certificate. Ensure the given certificate is a valid certificate and that requried attributes are available.	
	Get CSR		
		Get CSR certificate via the /lxi/api/get-csr API.	
	Wait for DUT to sett	le	
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	
	Validate CSR attribut	es	
		Validate CSR attributes agains the expected and configured values in the CSR request.	
	Validate CSR Attribu	tes against IDevID attributes	
		Validate the attribute values in the received CSR against the IDevID attribute values.	
	Create self-signed ce	ertificate	
		Request the DUT to create a self-signed certificate via API. The created self-signed certificate is used as an LDevID for the device.	
	Wait for DUT to sett	le	
		Wait for the dut to settle. Due to changes made in previous steps, this is neccessary to ensure a device is settled before continuing.	
	Get LDevID Certificat	te from the device	
		Get an LDevID Certificate from the device using the API.	
	Validate LDevID certificate		
		Validate the LDevID certificate attributes against te expected and configured vlaues from the certificate request.	
	Validate LDevID Attri	ibutes against IDevID attributes	
		Validate the LDevID Attributes against the DUT's IDevID attributes.	
ExtraSu	bjectAttribute Objec	tID	
	ΙΧΙΔΡΙ		

23.16.3.1-1 E

Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	ExtraSubjectAttribute ObjectID		
Explanation	ObjectID shall be included. ObjectID is the object ID that indicates the subject attribute as specified by the OpenGroup.		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
Test Procedure	Create simple certificate requests with ExtraSubjectAttribute 'ObjectID'		
	Create simple certificate requests with ExtraSubjectAttribute 'ObjectID'. One request with a valid ObejctID and an empty ObjectID value.		



	GET CSR with ObjectID
	GET a CSR with ObjectID from the DUT and expect a success response with a valid CSR.
	Create self-signed certificate with ObjectID
	Request the DUT to create a self-signed certificate with ObjectID and expect a valid self-signed certificate.
	Create simple certificate requests without ObjectID
	Create simple certificate requests without ObjectID to send to the DUT.
	GET CSR without ObjectID and expect failure response
	GET a CSR without ObjectID from the DUT and expect a failure response
	Create self-signed certificate without ObjectID and expect failure response Request the DUT to create a self-signed certificate without ObjectID and expect a failure response
23.16.3.1-2 Extra	SubjectAttribute ObjectValue
Category	LXI API
Test Type	Kerberos Test, automated
Rule	ExtraSubjectAttribute ObjectValue
Explanation	ObjectValue shall be included. ObjectValue is the subject value associated with the specified attribute.
Pre Condition	Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
Test Procedure	Create simple certificate requests with ExtraSubjectAttribute 'ObjectValue' Create simple certificate requests with ExtraSubjectAttribute 'ObjectValue' to send to the DUT.
	GET CSR with ObjectValue
	GET a CSR with ObjectValue and expect success response with a valid CSR.
	Create self-signed certificate with ObjectValue
	Request the DUT to create a self-signed certificate with ObjectValue and expect a valid self-signed certificate.
	Create simple certificate requests without ObjectValue
	Create simple certificate requests without ObjectValue to send to the DUT.
	GET CSR without ObjectValue and expect failure response
	GET a CSR without ObjectValue from the DUT and expect the request to fail.
	Create self-signed certificate without ObjectValue and expect failure response
	Request the DUT to create a self-signed certificate without ObjectValue and expect a failure response



Category	LXI API
Test Type	Kerberos Test, automated
Rule	CertificateExtension ObjectID
Explanation	ObjectID shall be included. ObjectID is the object ID that indicates the certificate extension as specified by the OpenGroup.
Pre Condition	n Enable IPv4 DHCP router
	Enable the dhcp router for IPv4
	Connect DUT
	Connect the DUT to the test network
	Get IP from mdns
	Search via mdns for a single lxi service and retrieve its IP address
Test Procedu	re Create simple certificate requests with CertificateExtension 'ObjectID'
	Create simple certificate requests with CertificateExtension 'ObjectID'. One request with a valid ObejctID and an empty ObjectID value.
	GET CSR with ObjectID
	GET a CSR with ObjectID from the DUT and expect a success response with a valid CSR.
	Create self-signed certificate with ObjectID
	Request the DUT to create a self-signed certificate with ObjectID and expect a valid self-signed certificate.
	Create simple certificate requests without ObjectID
	Create simple certificate requests without ObjectID to send to the DUT.
	GET CSR without ObjectID and expect failure response
	GET a CSR without ObjectID from the DUT and expect a failure response
	Create self-signed certificate without ObjectID and expect failure response
	Request the DUT to create a self-signed certificate without ObjectID and expect a failure response
23.16.4.1-2	CertificateExtension ObjectValue

23.16.4.1-1 CertificateExtension ObjectID

Category	LXI API		
Test Type	Kerberos Test, automated		
Rule	CertificateExtension ObjectValue		
Explanation	ObjectValue shall be included. ObjectValue is the subject value associated with the certificate field		
Pre Condition	Enable IPv4 DHCP router		
	Enable the dhcp router for IPv4		
	Connect DUT		
	Connect the DUT to the test network		
	Get IP from mdns		
	Search via mdns for a single lxi service and retrieve its IP address		
Test Procedure	Create simple certificate requests with CertifcateExtension 'ObjectValue' Create simple certificate requests with CertifcateExtension 'ObjectValue' to send to the DUT.		



	GET CSR with Object	tValue
		GET a CSR with ObjectValue and expect success response with a valid CSR.
	Create self-signed o	ertificate with ObjectValue
		Request the DUT to create a self-signed certificate with ObjectValue and expect a valid self-signed certificate.
	Create simple certif	icate requests without ObjectValue
		Create simple certificate requests without ObjectValue to send to the DUT.
	GET CSR without O	bjectValue and expect failure response
		GET a CSR without ObjectValue from the DUT and expect the request to fail.
	Create self-signed c	ertificate without ObjectValue and expect failure response Request the DUT to create a self-signed certificate without ObjectValue and expect a failure response
23.18-1 LXI	Problem Details Schem	a 40X errors
Category	LXI API	
Test Type	Kerberos Test, auto	mated
Rule	LXI Problem Details	Schema 40X errors
Explanation	Devices shall return	the LXIProblemDetails when the LXI API generates 40X errors.
Pre Condition	Enable IPv4 DHCP router	
		Enable the dhcp router for IPv4
	Connect DUT	
		Connect the DUT to the test network
	Get IP from mdns	
		Search via mdns for a single lxi service and retrieve its IP address
Test Procedure	GET Common Conf	iguration
		GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
	POST Common Cor	ıfiguration
		POST common configuration instead of PUT. This call is expected to fail due to invalid endpoint.
	Validate Xml agains	t local schema Validate the response Xml against the appropriate local schema.
	Check Problem Det	ails title
		Check the title of the problem details.
	GET Device Specific	Configuration
		GET the Device Specific Configuration from device via API /lxi/api/device- specific-configuration using API-Key.
	PUT Common Conf	iguration with incorrect xml
		PUT the Common Configuration with an incorrect xml (e.g. use Xml for Device specific Configuration) and expect the PUT to fail.
	Validate Xml agains	t local schema
		Validate the response Xml against the appropriate local schema.



Check Problem Details title
Check the title of the problem details.
GET Common Configuration
GET the Common Configuration from the device. Expect the call to succeed. Authentication is given, the correct URL is being used and the device is setup correctly.
Modify Common Configuration for syntax error
Modify the Common Configuration xml received from the DUT in a way to ge a syntax error.
PUT Common Configuration with incorrect syntax
PUT the Common Configuration xml with incorrect syntax and expect failure response due to incorrect syntax.
Validate Xml against local schema
Validate the response Xml against the appropriate local schema.
Check Problem Details title
Check the title of the problem details.

23.18.1.1-1 LXIProblemDetailsElement Title

Category	LXI API
Test Type	Kerberos Test, automated
Rule	LXIProblemDetailsElement Title
Explanation	Title shall be included. Title is a high level description of the method result, consistent with the HTTP status code returned.
Test Procedure	Computed by other tests
	This test is computed by the result of other tests.
Dependencies	23.18-1

23.19-1 LXI Pending Details Schema Schema-valid XML Responses

Category	LXI API
Test Type	Vendor Declaration
Rule	LXI Pending Details Schema Schema-valid XML Responses
Explanation	Schema-valid XML responses, as defined by this schema, shall be returned by devices to indicate pending operations.

23.19.1.1-1 LXIPendingDetails URL

Category	LXI API
Test Type	Vendor Declaration
Rule	LXIPendingDetails URL
Explanation	URL shall be included. URL provides a URL at which the client can perform a GET to determine the status of the pending operation.